Coleman

PRESSURE-GAS

PARTS CATALOG

No. 22

Effective September 1, 1930

Prices Subject to Change Without Notice

Containing Price Lists of Repair Parts

for

Coleman Gas-Pressure Lamps and Lanterns
Coleman Self-Heating Irons
Coleman Folding Camp Stoves
Coleman Radiant Heaters
Coleman Air-O-Gas Ranges and Cook Stoves
Coleman Water Heaters
Coleman Special Utility Burners
Coleman Outdoor Fuel Tanks

Published by

The Coleman Lamp & Stove Co.

General Offices
WICHITA, KANSAS

Branches
Chicago, Ill. Philadelphia, Pa.

Factories
Wichita, Kans. Chicago, Ill.

INDEX

Parts Lists

	Page
Numerically Arranged by New Numbers	77-112
Numerically Arranged by Old Numbers	113-119
Double Number List (For Cross Reference)	120-123

Products

Burners:	
Urn Burners	70- 71
Urn Burner Generators	72- 73
Utility Burner	69
Camp Stoves:	21- 23
Camp Stove High Stand	22
Funnels (Filtering)	76
Handy Gas Plants	68
Heaters:	
Hot Ray	30
Radiant	24- 29
Water	67
Irons (Self Heating)	17- 20
Lamps:	
Instant-Lite	4- 5
Quick-Lite	6- 9
System	15- 16
Lanterns:	
Instant-Lite	10
Quick-Lite	11- 13
Torch-Lite	14
Preheaters (For Ranges & Stoves):	
Instant-Lite	66
Match-Lite	65
Pumps:	
Stove	65
Suction	76
Tank	74
Ranges (Air-O-Gas)	32- 39
Siphons	76
Soldering Furnaces	69
Stoves (Air-O-Gas)	40- 63
Tanks:	
Stove	64- 65
Outside Fuel	74
Wire Connections	75- 76

Introductory

THIS catalog is prepared especially for your convenience in ordering parts and supplies for Coleman Lamps, Lanterns, Camp Stoves, Irons, Heaters, Burners and Air-O-Gas Stoves. It gives a complete list of parts with net retail prices for the different models made by The Coleman Lamp and Stove Company.

When Ordering always be sure you have given the correct number and description of the part or parts ordered. This insures prompt handling and quick delivery of your order.

Repair Service—It is the policy of The Coleman Lamp and Stove Company to co-operate with users of Coleman products in assisting them to secure the largest measure of satisfaction from their purchases. We therefore maintain a Repair and Service Department at each of our branch houses, located at Second and St. Francis, Wichita, Kansas; 352 South Los Angeles St., Los Angeles, Calif.; 7 Walnut St., Philadelphia, Penna.; and 5133 West 65th St., Chicago, Ill. It is the duty of these departments to furnish operative and handling suggestions and to supply the necessary parts for all Coleman products at reasonable prices.

How to Ship Packages—When sending in goods for repairs, service or credit, please observe the following points:

1. See that goods are securely packed to prevent damage in transit.
2. Address package to the Coleman office nearest you and mark it "Attention Repair and Service Department."
3. Be sure to put your name and return address on the package, also.
4. Send package by **insured** parcel post, (insured parcels are traceable), express, or freight.
5. **Prepay all transportation charges.** We do not pay incoming transportation charges, except by special agreement.
6. On the same day that you send the package, write a letter to The Coleman Lamp and Stove Company, Attention Repair and Service Department, and give instructions as to what you wish done. Tell us how the shipment is being sent — by insured parcel post, express or freight. Mail your letter separately — do not send it inside the package.

It is the intention of each Repair and Service Department to handle all items the same day received. By making shipments as outlined above, you will materially assist us in speeding up the service and the attention your orders will receive.

Returns and Allowances—Please do not return merchandise to the factory for credit without first having obtained permission for its return. Otherwise this merchandise will be held at owner's risk.

Parts List for

Coleman Instant-Lite Lamp, Model No. 117

(WITHOUT BUILT-IN PUMP)

Parts No.	Name of Part	Net Retail Price
Q77	Straight Generator (Gas Tip Marked "J") (199-299)	.20
T656	Valve Stem Complete (118-653)	.45
T657	Valve & Generator Complete (118-657)	1.05
101-522	Pump	.75
104-210	Jamb Nut	.03
104-469	Hanger	.09
104-905	Gas Tip Cleaning Needle	.06
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen 2 for	.06
115-136	Filler Plug Gasket 2 for	.06
115-138	Filler Plug Core & Gasket	.30
117-132	Filler Plug Air Stem	.18
*117-144	Tip Protector & Screen	.15
117-145	Lamp Handle	.36
117-147	Handle Lock Nut	.18
117-148	Fuel Wire Complete (Fuel Tip Marked "P")	.54
117-160	Fuel Tube	.60
117-164	Filler Plug Complete	.60
117-165	Fount Complete	5.40
117-341	Shade Holder Screw	.06
117-342	Shade Holder	.30
117-361	Air Intake & Bracket	.90
118B324	Burner Tube	.15
118-399	Burner, Generator & Valve Complete Assembled	3.45
155-218	Gas Tip (Marked "J")	.06
216-326	Mixing Chamber	.90
216-327	Valve Set Screw	.03
216-328	Valve Bracket Wedge	.03
216-509	Pump Leather 2 for	.09
216-654	Valve Body	.36
217-118	Fuel Tip (Marked "P")	.06
*217-144	Tip Protector & Screen	.09
605-950	Wrench	.15



Tip Protector & Screen



*NOTE—Tip Protector & Screen Nos. 217-144 and 117-144 are both used on Instant-Lite Lamps and Lanterns, but are not interchangeable. So before ordering, check the Tip Protector & Screen on your Instant-Lite Lamp or Lantern with the illustrations above. Then order by correct number the one that corresponds to Tip Protector & Screen you are now using.

Parts List for

Coleman Instant-Lite Lamps, Model Nos. 118, 119

(WITH BUILT-IN PUMPS)

Parts No.	Name of Part	Net Retail Price
Q77	Straight Generator (Gas Tip Marked "J") (199-299)	.20
T656	Valve Stem Complete (118-653)	.45
T657	Valve & Generator Complete (118-657)	1.05
104-210	Jamb Nut	.03
104-469	Hanger	.09
104-905	Gas Tip Cleaning Needle	.06
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen....2 for	.06
115-136	Filler Plug Gasket....2 for	.06
*117-144	Tip Protector & Screen	.15
117-148	Fuel Wire Complete (Fuel Tip Marked "P")	.54
117-160	Fuel Tube	.60
117-341	Shade Holder Screw	.06
117-342	Shade Holder	.30
117-361	Air Intake & Bracket	.90
118-140	Filler Plug Complete	.48
118-145	Lamp Handle	.36
118-147	Handle Lock Nut	.18
118-165	Fount Complete	7.50
118B324	Burner Tube	.15
118-399	Burner, Generator & Valve Complete Assembled	3.45
118-520	Pump Plunger Complete (Less Air Stem)	.60
155-218	Gas Tip (Marked "J")	.06
204-139	Filler Plug Disc, Gasket & Screw	.15
216-326	Mixing Chamber	.90
216-327	Valve Set Screw	.03
216-328	Valve Bracket Wedge	.03
216-509	Pump Leather....2 for	.09
216-532	Air Stem	.15
216-538	Check Valve	.15
216-654	Valve Body	.36
217-118	Fuel Tip (Marked "P")	.06
*217-144	Tip Protector & Screen	.09
605-950	Wrench	.15





Tip Protector & Screen



*NOTE—Tip Protector & Screen Nos. 217-144 and 117-144 are both used on Instant-Lite Lamps and Lanterns, but are not interchangeable. So before ordering, check the Tip Protector & Screen on your Instant-Lite Lamp or Lantern with the illustrations above. Then order by correct number the one that corresponds to Tip Protector & Screen you are now using.

Parts List for

Coleman Quick-Lite Lamps, "C" Models

Nos. C317, C318, C321, C322, C324, C329, C329A, C329B, C331, C333, C334, C335A, C335C, C335D



"C" MODEL QUICK-LITE LAMPS

(WITH SEPARATE PUMP)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
101-363	Shade Holder	.30
101-522	Pump	.75
101-653	Valve Stem Complete	.30
101-935	Handle Metal Washer ..... 2 for	.06
101-946	Handle Fibre Washer	.06
104-105	Finishing Shell	.36
104-132	Filler Plug Air Stem	.18
104-136	Filler Plug Gasket ..... 2 for	.06
104-145	Fibre Lamp Handle	.30
104-147	Lock Nut	.06
104-164	Filler Plug Complete	.60
104-165	Fount Complete	5.40
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-341	Shade Holder Screw	.06
104-399	Burner, Generator & Valve Complete Assembled	3.00
104-469	Hanger	.09
104-657	Fuel Valve Complete	.75
104-905	Gas Tip Cleaning Needle	.06
104-950	Wrench	.15
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen ..... 2 for	.06
216-509	Pump Leather ..... 2 for	.09



MODEL NO. C331 QUICK-LITE LAMP

(WITH BUILT-IN-PUMP)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
101-363	Shade Holder	.30
101-653	Valve Stem Complete	.30
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-341	Shade Holder Screw	.06
104-399	Burner, Generator & Valve Complete Assembled	3.00
104-469	Hanger	.09
104-657	Fuel Valve Complete	.75
104-905	Gas Tip Cleaning Needle	.06
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen ..... 2 for	.06
115-136	Filler Plug Gasket ..... 2 for	.06
120-145	Lamp Handle	.36
120-147	Handle Lock Nut	.15
120-160	Fuel Wire With Fuel Tube	.45
120-165	Fount Complete	7.50
204-139	Filler Plug Disc, Gasket & Screw	.15
204-140	Filler Plug Complete	.48
216-509	Pump Leather ..... 2 for	.09
216-520	Pump Plunger Complete (Less Air Stem)	.60
216-532	Air Stem	.15
216-538	Check Valve	.15
605-913	Alcohol Torch (Only)	.15
605-920	Alcohol Torch & Bottle Complete	.24
605-950	Wrench	.15

Parts List for

Coleman Quick-Lite Chandelier Lamp, Model "P"



QUICK-LITE CHANDELIER LAMP MODEL "P"

(With Separate Pump)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
101-363	Shade Holder	.30
101-522	Pump	.75
101-653	Valve Stem Complete	.30
104-132	Filler Plug Air Stem	.18
104-136	Filler Plug Gasket	2 for .06
104-164	Filler Plug Complete	.60
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-341	Shade Holder Screw	.06
104-399	Burner, Generator & Valve Complete Assembled	3.00
104-657	Fuel Valve Complete	.75
104-905	Gas Tip Cleaning Needle	.06
104-950	Wrench	.15
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen	2 for .05
112-437	Hanger (17" Long)	.36
112-440	Hanger Casing (16¼" Long)	.36
113-165	Fount Complete	7.50
113-443	Hanger Ring	.30
113-449	Fuel Wire	.15
113-450	Ornamental Shell Complete	.60
113-475	Arms & Fuel Wire	3.60
216-509	Pump Leather	2 for .09

Parts List for

Coleman Quick-Lite Bracket Lamp, Model "B"



MODEL "B" QUICK-LITE BRACKET LAMP

(With Separate Pump)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
101-363	Shade Holder	.30
101-522	Pump	.75
101-653	Valve Stem Complete	.30
102-117	Screw & Foot	.15
102-165	Fount Complete	6.60
102-446	Hanger Ring & Nuts	.18
104-132	Filler Plug Air Stem	.18
104-136	Filler Plug Gasket	2 for .06
104-164	Filler Plug Complete	.60
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-341	Shade Holder Screw	.06
104-399	Burner, Generator & Valve Complete Assembled	3.00
104-657	Fuel Valve Complete	.75
104-905	Gas Tip Cleaning Needle	.06
104-950	Wrench	.15
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen	2 for .06
216-509	Pump Leather	2 for .09

Parts List for

Coleman Air-O-Lite Lamp, Model 'A' and 'AA'



Old Parts No.	New Parts No.	Name of Part	Net Retail Price
A65		E—Fount Complete	6.00
NA	101-299	—Valve, Handle & Generator Complete	2.25
NA	101-522	—Pump	.75
NA	101-950	—Wrench	.18
NA	104-469	—Hanger	.09
NA	104-905	—Gas Tip Cleaning Needle	.06
NA	140-903	—Alcohol Torch	.15
NA	216-509	—Pump Leather	2 for .09
NA10	101-310	—Air Intake Coupling	.30
NA11		Air Intake Tube	.30
NA18	101-218	—Gas Tip	.24
NA22	101-322	—Bunsen Tube	.15
NA23-25	112-323	—Burner Cap & Screens	.15
NA24	101-324	—Burner Tube	.15
NA25	112-325	—Burner Cap Screen	2 for .06
NA26	104-326	—Mixing Chamber	.48
NA32 NA54A	101-154	—Filler Plug Air Stem	.18
NA34		Valve Cover	.60
NA35	101-935	—Handle Metal Washer	2 for .06
NA36	101-136	—Filler Plug Gasket	2 for .06
NA39		Heat Bell	.45
NA40		Heat Bell Stem	.09
NA41	104-341	—Shade Holder Screw	.06
NA45	101-145	—Fibre Lamp Handle	.30
NA46	101-946	—Handle Fibre Washer	.06
NA48		Set Collar & Screw	.12
NA55-16	101-653	—Valve Stem Complete	.30
NA57-16-55	101-657	—Fuel Valve Complete	.75
NA58	101-258	—Asbestos Wick (Tied)	2 for .15
NA59	101-259	—Gas Tip Screen	2 for .15
NA58-12	101-265	—Generator Barrel & Asbestos Wick	1.05
NA63	101-363	—Shade Holder	.30
NA64½	101-164	—Filler Plug Complete	.75
NA66		Heat Bell Plate & Spring	.15
NA70	101-370	—Burner Complete	3.00

Coleman Instant-Lite Lanterns, Model Nos. 220, 228

Parts No.	Name of Part	Net Retail Price
Q77	—Straight Generator (Gas Tip Marked "J") (199-299)	.20
T656	—Valve Stem Complete (118-653)	.45
T657	—Valve & Generator Complete (118-657)	1.05
104-210	—Jamb Nut	.03
104-905	—Gas Tip Cleaning Needle	.06
112-323	—Burner Cap & Screens	.15
112-325	—Burner Cap Screen.....2 for	.06
115-136	—Filler Plug Gasket .....2 for	.06
*117-144	—Tip Protector & Screen	.15
118B324	—Burner Tube	.15
155-218	—Gas Tip (Marked "J")	.06
203-441	—Ventilator Ball Nut	.06
204-139	—Filler Plug Disc, Gasket & Screw	.15
204-140	—Filler Plug Complete	.48
**204-485	—Ventilator (Porcelain—5¼" Base) (For No. 220)	1.50
216-319	—Base Lock Nut.....2 for	.09
216-326	—Mixing Chamber	.90
216-327	—Valve Set Screw	.03
216-328	—Valve Bracket Wedge	.03
216-340	—Ventilator Rod	.06
216-361	—Air Intake & Bracket	.90
216-429	—Globe Base Rest	.18
216-509	—Pump Leather.....2 for	.09
216-520	—Pump Plunger Complete (Less Air Stem)	.60
216-532	—Air Stem	.15
216-538	—Check Valve	.15
216-654	—Valve Body	.36
217-118	—Fuel Tip (Marked "P")	.06
*217-144	—Tip Protector & Screen	.09
217-148	—Fuel Wire Complete (Fuel Tip Marked "P")	.54
217-160	—Fuel Nipple	.24
217-165	—Fount Complete	5.70
**217-498	—Frame & Bail (For No. 220)	.90
220-399	—Burner, Generator & Valve Complete Assembled	3.45
**227-480	—Ventilator (Porcelain—8¾" Base) (For No. 228)	1.95
**228-498	—Frame & Bail (For No. 228)	.90
605-950	—Wrench	.15

**For use on Model indicated.



MODEL No. 220

INSTANT-LITE LANTERN

Tip Protector & Screen



*NOTE—Tip Protector & Screen Nos. 217-144 and 117-144 are both used on Instant-Lite Lamps and Lanterns, but are not interchangeable. So before ordering, check the Tip Protector & Screen on your Instant-Lite Lamp or Lantern with the illustrations above. Then order by correct number the one that corresponds to Tip Protector & Screen you are now using.

Parts List for

Coleman Quick-Lite Lanterns
Model Nos. L227, L427 (1927)



MODEL NO. L427 (1927) QUICK-LITE LANTERN

(With Fully Concealed Built-In-Pump)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-905	Gas Tip Cleaning Needle	.06
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen	2 for .06
115-136	Filler Plug Gasket	2 for .06
203-340	Ventilator Rod	.06
203-409	Burner Frame Washer	2 for .06
203-420	Baffle Plate	.15
203-441	Ventilator Ball Nut	.06
203-489	Globe Base Rest	.15
*203-498	Frame & Bail (For No. L427 (1927)	.90
203-653	Valve Stem Complete	.30
204-139	Filler Plug Disc, Gasket & Screw	.15
204-140	Filler Plug Complete	.48
204-399	Burner, Generator & Valve Complete Assembled	2.70
*204-485	Ventilator (Porcelain—5¼" Base) (For No. L427 (1927)	1.50
204-657	Fuel Valve Complete	.75
216-165	Fount Complete	5.70
216-509	Pump Leather	2 for .09
216-520	Pump Plunger Complete (Less Air Stem)	.60
216-532	Air Stem	.15
216-538	Check Valve	.15
*227-480	Ventilator (Porcelain—8¾" Base) (For No. L227)	1.95
*227-498	Frame & Bail (For No. L227)	.90
605-950	Wrench	.15

* For use on Model indicated.

Parts List for

Coleman Quick-Lite Lanterns, Model Nos. L327, L427 (1926)



MODEL No. L327 QUICK-LITE LANTERN

(With Separate Pump)

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q") (104-299)	.35
101-324	Burner Tube	.15
*101-522	Pump	.75
*104-132	Filler Plug Air Stem	.18
*104-136	Filler Plug Gasket—2 for	.06
*104-164	Filler Plug Complete	.60
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-905	Gas Tip Cleaning Needle	.06
*104-950	Wrench	.15
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen—2 for	.06
*203-165	Fount Complete	4.50
203-340	Ventilator Rod	.06
203-399	Burner, Generator & Valve Complete Assembled	2.70
203-409	Burner Frame Washer—2 for	.06
203-420	Baffle Plate	.15
203-441	Ventilator Ball Nut	.06
203-489	Globe Base Rest	.15
203-498	Frame & Bail	.90
203-653	Valve Stem Complete	.30
203-657	Fuel Valve Complete	.75
204-485	Ventilator (Porcelain 5¼" Base)	1.50
*216-509	Pump Leather—2 for	.09

*Parts cannot be used on Model No. L427 (1926), when equipped with No. 204-165 (L465) Fount Complete.



PARTS FOR MODEL No. L427 (1926) QUICK-LITE LANTERN

(With Semi-Concealed Built-In-Pump)

Parts No.	Name of Part	Net Retail Price
115-136	Filler Plug Gasket—2 for	.06
204-139	Filler Plug Disc, Gasket & Screw	.15
204-140 (L464B)	Filler Plug Complete	.48
*204-165 (L465)	Fount Complete	.....
204-520 (L401)	Pump Plunger Complete (Less Air Stem)	.60
204-524 (L400)	Pump Barrel Complete	.90
204-530 (L404)	Pump Complete	1.50
216-532 (L402)	Air Stem	15
409-509	Pump Leather—2 for	.09
605-950	Wrench	.15

All parts listed under Model No. L327 (except those starred) can be used on Model No. L427 (1926) when equipped with No. 204-165 (L465) Fount Complete.

*No. 204-165 (L465) Fount Complete is obsolete. Supply Nos. 204-657 and 216-165. See Page No. 11 for illustration Model No. L427 (1927).

Parts List for

Coleman Lantern, Model No. E20

(With Built-In-Pump)



QUICK-LITE LANTERN, MODEL No. E20

Parts No.	Name of Part	Net Retail Price
Q99	Coil Generator (Gas Tip Marked "Q" (104-299)	.35
101-324	Burner Tube	.15
*104-132	Filler Plug Air Stem	.18
104-218	Gas Tip (Marked "Q")	.06
104-317	Burner Support Coupling	.18
104-322	Air Intake Tube	.36
104-326	Mixing Chamber	.48
104-905	Gas Tip Cleaning Needle	.06
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen	2 for .06
115-136	Filler Plug Gasket	2 for .06
*115-164	Filler Plug Complete	.60
203-340	Ventilator Rod	.06
203-370	Burner (Less Generator & Valve)	1.65
203-409	Burner Frame Washer	2 for .06
203-420	Baffle Plate	.15
203-441	Ventilator Ball Nut	.06
203-498	Frame & Bail	.90
203-653	Valve Stem Complete	.30
**204-139	Filler Plug Disc, Gasket & Screw	.15
**204-140	Filler Plug Complete	.48
204-485	Ventilator (Porcelain—5¼" Base)	1.50
*212-189	Fount Complete (With Valve) (See Note No. 1)	.....
212-489	Globe Base Rest	.15
212-657	Fuel Valve Complete	.90
**213-189	Fount Complete (With Valve)	7.50
**213-520	Pump Plunger Complete (Less Air Stem)	.60
**213-530	Pump Complete	2.10
**213-532	Air Stem	.24
**409-509	Pump Leather	2 for .09
*451-504	Pump Barrel Top Plug	.09
*451-509	Pump Leather	.06
*451-522	Jumbo Pump (See Note No. 2)	1.35
605-950	Wrench	.15

*For Model No. E20 With Separate Pump. **For Model No. E20 With Built-In-Pump.

Note No. 1—No. 212-189 Fount Complete is obsolete. Order No. 213-189 Fount Complete.

Parts List for

Coleman Lantern, Model No. HV316

(With Separate Pump)



TORCH-LITE LANTERN, MODEL No. HV316

Parts No.	Name of Part	Net Retail Price
101-136	Filler Plug Gasket	2 for .06
101-154	Filler Plug Air Stem	.18
101-164	Filler Plug Complete	.75
101-522	Pump	.75
101-950	Wrench	.18
104-905	Gas Tip Cleaning Needle	.05
112-323	Burner Cap & Screens	.15
112-325	Burner Cap Screen	2 for .06
140-903	Alcohol Torch	.15
203-653	Valve Stem Complete	.30
208-165	Fount Complete	5.70
208-208	Asbestos Wick (Tied)	.06
208-218	Gas Tip (Marked "G")	.15
208-259	Gas Tip Screen	2 for .06
208-299	Generator (4½" Long) (Gas Tip Marked "G")	.45
208-324	Burner Tube	.15
208-326	Mixing Chamber	.45
208-338	Chimney	.90
208-370	Burner, Generator, Valve & Chimney Complete Assembled	3.45
208-441	Hanger Ring	.09
208-473	Bail & Handle	.30
208-482	Globe Spring	.06
208-486	Ventilator Dome (Less Handle)	4.80
208-489	Globe Base Rest	.24
208-493	Globe Base & Door	.90
208-613	Connection (Valve to Generator)	.30
208-657	Fuel Valve Complete	.90
216-509	Pump Leather	2 for .09

Parts List for

Coleman System Lamps, Model Nos. 1 and 11



LAMP MODEL No. 1

Parts No.	Name of Part	Net Retail Price
140-903	—Alcohol Torch	.15
102-3-13-16	—Fuel Valve Complete	1.05
103-16	—Valve Stem Complete	.30
107-8-9	—Generator Barrel & Asbestos Wick	1.20
108	—Asbestos Wick (Tied)	.18
118	—Gas Tip (Marked "1")	.30
122	—Burner Tube	.15
123-25	—Burner Cap & Screens	.30
199	—Generator Barrel, Wick, Fuel Valve & Gas Tip (Gas Tip Marked "1")	2.70



LAMP MODEL No. 11

Parts No.	Name of Part	Net Retail Price
140-903	—Alcohol Torch	.15
1103-16	—Valve Stem Complete	.30
1103-16-42	—Fuel Valve Complete	1.20
1107-8-9	—Generator Barrel & Asbestos Wick	1.20
1108	—Asbestos Wick (Tied)	.18
1118	—Gas Tip (Marked "11")	.30
1123-25	—Burner Cap & Screens	.24
1124	—Burner Tube	.15
1126	—Globe Holder Complete	1.05
1129-19	—Mixing Chamber	.75
1146-11	—Air Intake Complete	.75
1199	—Generator Barrel, Wick, Fuel Valve & Gas Tip (Gas Tip Marked "11")	2.70

Coleman System Lamps, Model Nos. 25 and 27

LAMP MODEL No. 25

Parts No.	Name of Part	Net Retail Price
140-903	Alcohol Torch	.15
2501	Connecting Ring (140-401)	.30
2504	Heat Baffle (140-904)	.36
2508	Asbestos Wick (Tied) (140-208)	.15
2518	Gas Tip (Marked "25") (140-218)	.15
2523R	Burner Cap & Screens (112-323)	.15
2524	Burner Tube (140-324)	.24
2526	Mixing Chamber (208-326)	.45
2535	Pipe Hanger (5" Long) (112-438)	.12
2540	Casing (4½" Long) (112-444)	.18
2543	Ceiling Plate (112-443)	.36
2547	Canopy & Screw (112-419)	.45
2553	Chain & Ring (6" Long) (140-953)	.12
2555	Valve Stem Complete (140-651)	.30
2557R	Fuel Valve Complete (With Lever) (140-660)	.90
2599	Generator (6¼" Long) (Gas Tip Marked "25") (140-299)	.45



LAMP MODEL No. 27

Parts No.	Name of Part	Net Retail Price
140-903	Alcohol Torch	.15
2701	Connecting Ring (140-401)	.30
2704	Heat Baffle (140-904)	.36
2708	Asbestos Wick (Tied) (142-208)	.15
2718	Gas Tip (Marked "27") (142-218)	.15
2723R	Burner Cap & Screens (142-323)	.18
2724	Burner Tube (142-324)	.24
2726	Mixing Chamber (142-326)	.60
2735	Pipe Hanger (5" Long) (112-438)	.12
2740	Casing (4½" Long) (112-444)	.18
2743	Ceiling Plate (112-443)	.36
2747	Canopy & Screw (112-419)	.45
2753	Chain & Ring (18" Long) (142-953)	.18
2755	Valve Stem Complete (140-651)	.30
2757R	Fuel Valve Complete (With Lever) (140-660)	.90
2799	Generator (7⅜" Long) (Gas Tip Marked "27") (142-299)	.48



No. 27 is made on the same principle as No. 25 except it uses two No. 40 Senior Mantles, has a 6-inch Globe fitter and is heavier throughout.

Parts List for

Coleman Iron, Model No. 4

(INSTANT LIGHTING)



Parts No.	Name of Part	Net Retail Price
104-210	Jamb Nut	.03
216-509	Pump Leather	2 for .09
409-327	Stove Bolt ($\frac{3}{16}$"x$\frac{3}{8}$" R. H.)	.03
410-585	Pump	.45
603-132	Filler Plug Air Stem	.18
603-136	Filler Plug Gasket	2 for .06
603-139	Filler Plug Core & Gasket	.18
603-147	Lock Nut	.06
603-164	Filler Plug Complete	.48
603-218	Gas Tip (Marked "I")	.06
603-299	Generator, Cleaning Needle & Holder (Gas Tip Marked "I")	.36
603-326	Burner Manifold (Less Plug)	.90
603-329	Burner Plug	.06
603-365	Burner Manifold & Plug	.96
603-401	Base	1.20
603-406	Lid Plate (Lower)	.36
603-407	Lid Plate (Upper)	.45
603-410	Fount Bracket	.12
603-415	Locator Pin	2 for .06
603-439	Pilot Flame Baffle Plate	.09
603-440	Stand	.24
603-451	Handle Bolt ($\frac{3}{16}$"x5" Carriage)	.06
603-455	Lid Plate to Base Screw (1$\frac{3}{4}$"—No. 12 O. H. M. S.)	.06
603-457	Stove Bolt ($\frac{1}{4}$"x$\frac{11}{16}$" R. H.	.03
603-638	Cleaning Needle & Holder	.15
603-653	Generator Valve Stem & Pack Nut (Less Needle & Holder)	.45
604-159	Fount (Less Filler Plug)	1.35
604-189	Fount, Valve & Generator Complete Assembled	3.00
604-402	Body (Blue Porcelain)	.90
604-445	Iron Handle	.21
604-446	Handle Bracket	.15
604-604	Air Wire	2 for .09
604-618	Fuel Intake (Marked AZ")	.09
604-648	Fuel Intake & Air Wire (Fuel Intake Marked "AZ")	.30
604-654	Valve Body	.54
604-657	Generator, Valve, Fuel Intake & Air Wire Complete Assembled	1.50
604-659	Fuel Intake Protector & Screen	.15
604-930	Fuel Measuring Cup	.45
605-950	Wrench	.15

Parts List for

Coleman Iron, Model No. 5

(TORCH GENERATING)



Parts No.	Name of Part	Net Retail Price
216-509	Pump Leather	2 for .09
409-327	Stove Bolt ($\frac{3}{16}$"x$\frac{3}{8}$" R. H.)	.03
410-585	Pump	.45
603-132	Filler Plug Air Stem	.18
603-136	Filler Plug Gasket	2 for .06
603-139	Filler Plug Core & Gasket	.18
603-147	Lock Nut	.06
603-159	Fount (Less Filler Plug)	1.26
603-164	Filler Plug Complete	.48
603-401	Base	1.20
603-406	Lid Plate (Lower)	.36
603-407	Lid Plate (Upper)	.45
603-410	Fount Bracket	.12
603-415	Locator Pin	2 for .06
603-439	Pilot Flame Baffle Plate	.09
603-440	Stand	.24
603-451	Handle Bolt ($\frac{3}{16}$"x5" Carriage)	.06
603-455	Lid Plate to Base Screw (1$\frac{3}{4}$"—No. 12 O. H. M. S.)	.06
603-457	Stove Bolt ($\frac{1}{4}$"x$\frac{11}{16}$" R. H.)	.03
603-940	Funnel	.18
605-189	Fount, Valve & Generator Complete Assembled	2.85
605-210	Jamb Nut	.03
605-218	Gas Tip (Marked "D")	.12
605-299	Generator, Cleaning Needle & Holder (Gas Tip Marked "D")	.39
605-370	Burner Manifold & Burner Tube Complete Assembled	.90
605-402	Body (Green Porcelain)	.90
605-445	Iron Handle	.21
605-446	Handle Bracket	.15
605-638	Cleaning Needle & Holder	.15
605-653	Generator Valve Stem Complete (Less Cleaning Needle & Holder)	.60
605-654	Valve Body	.60
605-657	Valve & Generator Complete Assembled	1.50
605-904	Alcohol Bottle (Only)	.09
605-913	Alcohol Torch (Only)	.15
605-920	Alcohol Torch & Bottle Complete	.24
605-950	Wrench	.15

Parts List for

Coleman Iron, Model No. 3

(INSTANT LIGHTING)



Parts No.	Name of Part	Net Retail Price
104-210	Jamb Nut	.03
216-509	Pump Leather	2 for .09
409-327	Stove Bolt (5/16"x3/8" R. H.)	.03
410-585	Pump	.45
603-132	Filler Plug Air Stem	.18
603-136	Filler Plug Gasket	2 for .06
603-139	Filler Plug Core & Gasket	.18
603-147	Lock Nut	.06
603-159	Fount (Less Filler Plug)	1.26
603-164	Filler Plug Complete	.48
*603-189	Fount, Valve & Generator Complete Assembled (See Note 4)	----
603-218	Gas Tip (Marked "I")	.06
603-299	Generator, Cleaning Needle & Holder (Gas Tip Marked "I")	.36
603-326	Burner Manifold (Less Plug)	.90
603-329	Burner Plug	.06
603-365	Burner Manifold & Plug	.96
603-401	Base	1.20
*603-402	Body (See Note 1)	----
603-406	Lid Plate (Lower)	.36
603-407	Lid Plate (Upper)	.45
603-410	Fount Bracket	.12
603-415	Locator Pin	2 for .06
603-439	Pilot Flame Baffle Plate	.09
603-440	Stand	.24
*603-445	Iron Handle (See Note 2)	----
603-446	Handle Bracket	.15
603-451	Handle Bolt (5/16"x5" Carriage)	.06
603-455	Lid Plate to Base Screw (1¾"—No. 12 O. H. M. S.)	.06
603-457	Stove Bolt (¼"x11/16" R. H.)	.03
*603-605	Air Wire (See Note 3)	----
603-638	Cleaning Needle & Holder	.15
603-644	Fuel Intake & Screen	.09
603-653	Generator Valve Stem & Pack Nut (Less Needle & Holder)	.45
*603-657	Generator, Valve, Fuel Intake & Air Wire Complete Assembled (See Note 5)	----
603-940	Funnel	.18
604-190	Assembly (Includes 604-189 Fount, Valve & Generator Complete Assembled, 604-930 Fuel Measuring Cup and Directions For Model No. 4 Iron)	3.45
604-402	Body (Blue Porcelain)	.90
604-445	Iron Handle	.21
604-604	Air Wire	2 for .09
604-657	Generator, Valve, Fuel Intake & Air Wire Complete Assembled	1.50
605-950	Wrench	.15

Note 1—Supply No. 604-402. Note 3—Supply No. 604-604. Note 5—Supply No. 604-657
Note 2—Supply No. 604-445. Note 4—Supply No. 604-190 * Obsolete.

Coleman Irons, Model Nos. 1 and 2



PARTS FOR COLEMAN IRON, MODEL No. 2

Parts Nos. No. 1 New No.	Parts Nos. No. 1 Old No	Parts Nos. No. 2 New No.	Parts Nos. No. 2 Old No.	Name of Part	Net Retail Price
210	6	210		210—Lid Set Screw	.12
600-399	.....	.....		.....—Burner, Valve, Genertor & Fount Complete Assembled	3.45
600-657	2	.....		.....—Valve & Generator Complete Assembled	1.50
601-136	7	601-136		236—Filler Plug Gasket, 2 for	.06
601-159	14	601-159		244—Fount (Less Filler Plug)	1.26
601-164	8	601-164		231—Filler Plug Complete	.24
601-370	12	601-370		270—Burner	.60
.....	.....	601-399		222—Burner, Valve, Generator & Fount Complete Assembled	3.45
601-614	5	601-614		214—Valve Stem	.24
601-616	4	601-616		216—Pack Nut	.24
601-620	3	601-620		2120—Valve Stem Packing, 2 for	.09
601-653	.....	601-653		.....—Valve Stem Complete	.60
.....	.....	601-657		299—Valve & Generator Complete Assembled	1.50
601-950	11	601-950		2WJ—Wrench	.15
603-440	.....	603-440		220—Stand	.24
603-446	15	603-446		25—Handle Bracket	.15
603-451	13	603-451		26—Handle Bolt ($\frac{3}{16}$"x5" Carriage)	.06
603-940	19	603-940		219—Funnel	.18
604-445	10	604-445		212—Iron Handle	.21
.....	1	.....		266—Body Base	1.32
.....	9	.....		21—Deflector Plate	.30
.....	16B	.....		22—Lid Plate (Lower)	.45
.....	16T	.....		24—Lid Plate (Upper)	.36
.....	17	.....		23—Lid Plate Asbestos Liner	.18
.....	18	.....		28—Bolt (Handle Bracket to Lid Plate (Lower) ($\frac{1}{4}$"x$\frac{5}{8}$" U. S. S. R. H.)	.12
.....	.....	.....		27—Lid Extension Arm	.12

Model No. 1 was equipped with black Handle and without holes in the side of the Body Base. All parts listed under New Nos., both for Model Nos. 1 and 2, are interchangeable with the following exceptions: Model No. 1, Part Nos. 600-399 and 600-657; Model No. 2, Part Nos. 601-399 and 601-657. All parts listed under Old Nos., both for Model Nos. 1 and 2, only, are not interchangeable, with following exceptions: Model No. 1, Part No. 18 Model No. 2, Part No. 28.

Parts List for

Coleman Camp Stoves, Model Nos. 2D and 9D

Parts No.	Name of Part	Net Retail Price
104-136	Filler Plug Gasket 2 for	.06
216-509	Pump Leather 2 for	.09
216-520	Pump Plunger Complete (Less Air Stem)	.60
216-532	Air Stem	.15
216-538	Check Valve	.15
401-164	Filler Plug Complete	.36
*401-457	Oven Baffle (2D)	.15
401-489	Key & Ring (Only)	.09
402-259	Generator Screen	.06
402-459	Key Chain (Only)	.09
402-490	Key, Ring & Chain	.15
402-656	Generator Valve Stem Complete	.45
*403-489	Lid, Baffles & Support Assembled (9D)	1.80
405-118	Generator Clamp, (With Bolt & Nut)	.18
405-170	Fuel Tube (5⅜" Long)	.36
405-175	Tank & Generator Complete Assembled	6.00
405-239	Gas Tip & Holder (Gas Tip Marked "B")	.15
405-262	Generator (Gas Tip Marked "B")	1.20
405-315	Rocker Arm Pin	.06
405-326	Burner Manifold	1.80
405-357	Auxiliary Burner Valve Stem Complete	.75
405-361	Rocker Arm	.36
405-365	Burner Cap (2 Piece, Bolt & Nut)	.30
405-370	Burner Complete Assembled (Manifold, Caps, Auxiliary Valve, Rocker Arm & Pin)	3.00
*405-434	Grate (9D)	.75
*406-434	Grate (2D)	1.05
*406-489	Oven Complete (Less Oven Rack & Baffle) (2D)	3.00
*406-492	Oven Rack (2D)	.60
471-238	Cleaning Needle & Holder 2 for	.09

*For use on Model indicated.



Parts List for

Coleman Camp Stoves, Model Nos. 2C and 9C

Parts No.	Name of Part		Net Retail Price
104-136	Filler Plug Gasket	2 for	.06
216-532	Air Stem		.15
401-164	Filler Plug Complete		.36
*401-457	Oven Baffle (2C)		.15
401-489	Key & Ring (Only)		.09
402-259	Generator Screen		.06
402-328	Auxiliary Valve Core		.24
402-329	Auxiliary Valve Shift		.18
402-459	Key Chain (Only)		.09
402-490	Key, Ring & Chain		.15
402-656	Generator Valve Stem Complete		.45
403-170	Fuel Tube (8 13/16" Long)		.36
403-175	Tank & Generator Complete Assembled		6.00
403-321	Adapter Ring (For Burner)		.30
403-326	Burner Manifold		1.80
403-365	Burner Cap (3 Piece, Bolt & Nut)		.60
*403-489	Lid, Baffles & Support Assembled (9C)		1.80
*404-434	Grate (2C)		1.20
405-239	Gas Tip & Holder (Gas Tip Marked "B")		.15
405-262	Generator (Gas Tip Marked "B")		1.20
*406-489	Oven Complete (Less Oven Rack & Baffle) (2C)		3.00
*406-492	Oven Rack (2C)		.60
409-118	Generator Clamp (With Bolt & Nut)		.18
*409-434	Grate (9C)		.48
409-509	Pump Leather	2 for	.09
409-520	Pump Plunger Complete (Less Air Stem)		.45
471-238	Cleaning Needle & Holder	2 for	.09

*For use on Model indicated.

Camp Stove Folding High Stand

The Coleman Camp Stove Folding High Stand is a Universal High Stand that can be used for practically every type of Camp Stove. It is of single - unit all - steel construction. When **set up** all folding joints lock automatically thus insuring a positive rigid support. Folds up to 2½ x 2 x 26½ inches. **Weight**, net, 7½ pounds.

No. 10—Camp Stove High Stand (591-499) 2.40









Parts List for

Coleman Gypsy Camp Stove, Model No. 10



Parts No.	Name of Part	Net Retail Price
102-143	Stove Bolt ($\frac{3}{16}$"x$\frac{1}{2}$" R. H.)	.03
104-132	Filler Plug Air Stem	.18
104-136	Filler Plug Gasket	2 for .06
216-509	Pump Leather	2 for .09
305-443	Stove Bolt ($\frac{3}{16}$"x$\frac{3}{8}$" O. H.)	.03
401-164	Filler Plug Complete	.36
405-365	Burner Cap (2 Piece, Bolt & Nut)	.30
410-171	Fuel Tube ($3\frac{13}{16}$" Long)	.24
410-175	Tank (With Filler Plug, Air Stem & Tank Bracket)	3.00
410-218	Gas Tip (Marked "GS")	.15
410-256	Generator Valve Stem Complete	.60
410-262	Generator (Gas Tip Marked "GS")	1.20
410-309	Hot-Blast Deflector	.12
410-313	Hot-Blast Deflector Lever	.12
410-314	Auxiliary Burner Control Lever	.12
410-322	Mixing Chamber Shield	.15
410-324	Stove Bolt ($\frac{3}{16}$"x$\frac{1}{4}$" R. H.)	.03
410-326	Burner Manifold	1.80
410-328	Auxiliary Burner Control	.09
410-370	Burner Complete Assembled (Manifold, Caps & Auxiliary Burner Control)	2.70
410-488	Cabinet, Lid, Baffles & Grate	3.00
410-585	Pump	.45
471-238	Cleaning Needle & Holder	2 for .09
545-329	Stove Bolt ($\frac{3}{16}$"x$\frac{1}{2}$" F. H.)	2 for .06

Coleman Radiant Heater, Model No. 5A

Parts No.	Name of Part	Net Retail Price
104 - 905	Gas Tip Cleaning Needle	.06
117 - 144	Tip Protector & Screen	.15
216 - 538	Check Valve	.15
471 - 322	Sub-flame Burner Cap (5/8") 2 for	.09
472 - 128	Stove Bolt (3/16"x16" R. H.)	.09
472 - 233	Generator Clamps, Bolt & Nut	.12
472 - 435	Top Tie Rod	.09
472 - 436	Top Tie Rod Nut	.03
474 - 109	Air Stem Spring	.03
474 - 218	Gas Tip (Marked "4H")	.12
474 - 503	Hexagon Brass Nut (3/8"—No. 27)	.06
474 - 509	Pump Leather 2 for	.09
474 - 510	Pump Plunger Lower Washer	.03
474 - 512	Pump Handle	.09
474 - 515	Air Stem	.30
474 - 517	Handle Nut	.06
474 - 555	Pump Plunger Complete (Less Air Stem)	1.20
475 - 115	Combination Fuel & Air Gauge	1.80
475 - 118	Fuel Tip (Marked "E")	.06
475A126	Tank Bracket (Right)	.15
475A127	Tank Bracket (Left)	.15
475A170	Drip Pan (Only)	.60
475 - 171	Fuel Tube (3 3/8" Long)	.30
475A191	Tank Complete (With Fittings)	9.30
475 - 193	Tank, Drip Pan & Generator Complete Assembled	12.60
475 - 262	Thermo Safety Generator (Gas Tip Marked "4H")	3.30
475 - 303	Radiant	.30
475 - 310	Preheater Pan	.45
475 - 318	Gas Tip (Marked "S")	.06
475 - 323	Main Burner Cap (7/8") 2 for	.09
475A357	Preheater Tank Valve Complete (Fuel Tip Marked "E")	1.20
475 - 370	Burner Manifold (With Main & Sub-flame Burner Caps)	3.00
475 - 389	Preheater Generator (Gas Tip Marked "S")	.30
475 - 403	Radiant Back (Aluminum)	1.05
475A404	Foot (Right)	.75
475A405	Foot (Left)	.75
475A407	Post Top	.24
475A408	Frame Trim (Right)	.45
475A409	Frame Trim (Left)	.45
475 - 410	Post Bolt	.09
475 - 415	Door Trim	.60
475 - 417	Top (Porcelain)	1.20
475A418	Top Trim (Right)	.45
475A419	Top Trim (Left)	.45





Parts No.	Name of Part	Net Retail Price
475 - 420	Radiant Holder (Top)	.36
475 - 473	Bail	.30
475 - 480	Guard	1.05
475A491	Door Complete	2.25
475A648	Indicator Handle & Screw	.15
475A653	Valve Stem (Less Indicator Handle & Screw)	.30
475A657	Tank Fuel Valve Complete	1.05
605 - 950	Wrench	.15
650 - 131	Filler Plug Cap (Only)	.45
650 - 135	Filler Plug Disc, Gasket & Screw	.30
650 - 136	Filler Plug Gasket 2 for	.09
650 - 140	Filler Plug Complete	.75

Coleman Radiant Heater, Model No. 7

Parts No.	Name of Part	Net Retail Price
104 - 905	Gas Tip Cleaning Needle	.06
117 - 144	Tip Protector & Screen	.15
216 - 538	Check Valve	.15
471 - 322	Sub-flame Burner Cap (5/8") 2 for	.09
472 - 128	Stove Bolt (3/16"x16" R. H.)	.09
472 - 233	Generator Clamps, Bolt & Nut	.12
472 - 238	Cleaning Needle & Holder 2 for	.09
472 - 420	Radiant Holder (Top)	.36
472 - 435	Top Tie Rod	.09
472 - 436	Top Tie Rod Nut	.03
472 - 480	Guard	1.05
474 - 109	Air Stem Spring	.03
474 - 218	Gas Tip (Marked "4H")	.12
474 - 262	Generator (Gas Tip Marked "4H")	2.40
474 - 503	Hexagon Brass Nut (3/8"—No. 27)	.06
474 - 509	Pump Leather 2 for	.09
474 - 510	Pump Plunger Lower Washer	.03
474 - 512	Pump Handle	.09
474 - 515	Air Stem	.30
474 - 517	Handle Nut	.06
474 - 555	Pump Plunger Complete (Less Air Stem)	1.20
475 - 118	Fuel Tip (Marked "E")	.06
475A126	Tank Bracket (Right)	.15
475A127	Tank Bracket (Left)	.15
475A170	Drip Pan (Only)	.60
475 - 171	Fuel Tube (3 3/8" Long)	.30
475 - 303	Radiant	.30
475 - 310	Preheater Pan	.45
475 - 318	Gas Tip (Marked "S")	.06
475 - 323	Main Burner Cap (7/8") 2 for	.09
475A357	Preheater Tank Valve Complete (Fuel Tip Marked "E")	1.20
475 - 370	Burner Manifold (With Main & Sub-flame Burner Caps)	3.00
475 - 389	Preheater Generator (Gas Tip Marked "S")	.30
475 - 403	Radiant Back (Aluminum)	1.05
475A407	Post Top	.24
475A408	Frame Trim (Right)	.45
475A409	Frame Trim (Left)	.45
475 - 415	Door Trim	.60
475 - 473	Bail	.30
475A648	Indicator Handle & Screw	.15
475A653	Valve Stem (Less Indicator Handle & Screw)	.30
475A657	Tank Fuel Valve Complete	1.05
477 - 125	Air Gauge	1.20



Parts No.	Name of Part	Net Retail Price
477 - 191	Tank Complete (With Fittings)	9.30
477 - 193	Tank, Drip Pan & Generator Complete Assembled	12.60
477 - 405	Front Foot	.30
477 - 410	Post Bolt	.09
477 - 417	Top (Porcelain)	1.20
477 - 418	Top Trim (Right)	.45
477 - 419	Top Trim (Left)	.45
477 - 491	Door Complete	2.40
605 - 950	Wrench	.15
650 - 131	Filler Plug Cap (Only)	.45
650 - 135	Filler Plug Disc, Gasket & Screw	.30
650 - 136	Filler Plug Gasket 2 for	.09
650 - 140	Filler Plug Complete	.75

Parts List for

Coleman Radiant Heater, Model No. 5

Parts No.	Name of Part	Net Retail Price
104-905	Gas Tip Cleaning Needle	.06
117-144	Tip Protector & Screen	.15
216-538	Check Valve	.15
324-353	Preheater Tank Valve Stem Complete	.30
471-322	Sub-flame Burner Cap (5/8") 2 for	.09
472-128	Stove Bolt (11/16"x16" R. H.)	.09
472-233	Generator Clamps, Bolt & Nut	.12
472-435	Top Tie Rod	.09
472-436	Top Tie Rod Nut	.03
474-109	Air Stem Spring	.03
474-218	Gas Tip (Marked "4H")	.12
474-503	Hexagon Brass Nut (3/8"—No. 27)	.06
474-509	Pump Leather 2 for	.09
474-510	Pump Plunger Lower Washer	.03
474-512	Pump Handle	.09
474-515	Air Stem	.30
474-517	Handle Nut	.06
474-555	Pump Plunger Complete (Less Air Stem)	1.20
475-115	Combination Fuel & Air Gauge	1.80
475-118	Fuel Tip (Marked "E")	.06
475-170	Drip Pan, Brackets, Gen. Clamps, Bolts & Nuts	1.80
475-171	Fuel Tube (3 3/8" Long)	.30
475-191	Tank Complete (With Fittings)	9.30
475-193	Tank, Drip Pan & Generator Complete Assembled	12.60
475-262	Thermo Safety Generator (Gas Tip Marked "4H")	3.30
475-303	Radiant	.30
475-310	Preheater Pan	.45
475-318	Gas Tip (Marked "S")	.06
475-323	Main Burner Cap (7/8") 2 for	.09
475-357	Preheater Tank Valve Complete (Fuel Tip Marked "E")	1.20
475-370	Burner Manifold (With Main & Sub-flame Burner Caps)	3.00
475-389	Preheater Generator (Gas Tip Marked "S")	.30
475-403	Radiant Back (Aluminum)	1.05
475-404	Foot (Right)	.75
475-405	Foot (Left)	.75
475-407	Post Top	.24
475-408	Frame Trim (Right)	.45
475-409	Frame Trim (Left)	.45
475-410	Post Bolt	.09



Parts No.	Name of Part	Net Retail Price
475-415	Door Trim	.60
475-417	Top (Porcelain)	1.20
475-418	Top Trim (Right)	.45
475-419	Top Trim (Left)	.45
475-420	Radiant Holder (Top)	.36
475-473	Bail	.30
475-480	Guard	1.05
475-491	Door Complete	2.25
475-653	Tank Fuel Valve Stem Complete	.30
475-657	Tank Fuel Valve Complete	.75
605-950	Wrench	.15
650-131	Filler Plug Cap (Only)	.45
650-135	Filler Plug Disc, Gasket & Screw	.30
650-136	Filler Plug Gasket 2 for	.09
650-140	Filler Plug Complete	.75

Parts List for

Coleman Radiant Heater, Model No. 4

Parts No.	Name of Part	Net Retail Price
101-653	Valve Stem Complete	.30
104-905	Gas Tip Cleaning Needle	.06
216-538	Check Valve	.15
471-322	Sub - flame Burner Cap (5/8") 2 for	.09
472-125	Air Gauge	1.20
472-128	Stove Bolt (3/16"x16" R. H.)	.09
472-233	Generator Clamps, Bolt & Nut	.12
472-238	Cleaning Needle & Holder 2 for	.09
472-303	Radiant	.24
472-403	Radiant Back (Aluminum)	2.10
472-405	Front Foot	.30
472-406	Post Top Cap	.18
472-407	Post Top	.18
472-408	Frame Trim (Right)	.60
472-409	Frame Trim (Left)	.60
472-410	Post Bolt	.09
472-415	Door Trim	1.50
472-417	Top (Porcelain)	1.20
472-418	Top Trim (Right)	.60
472-419	Top Trim (Left)	.60
472-420	Radiant Holder (Top)	.36
472-423	Door Handle Name Plate	.36
472-435	Top Tie Rod	.09
472-436	Top Tie Rod Nut	.03
472-473	Bail	.24
472-480	Guard	1.05
474-109	Air Stem Spring	.03
474-169	Drip Pan & Brackets	1.20
474-171	Fuel Tube (4 5/8" Long)	.30
474-191	Tank Complete (With Fittings)	9.30
474-193	Tank, Drip Pan & Generator Complete Assembled	12.60
474-218	Gas Tip (Marked "4H")	.12
474-262	Generator (Gas Tip Marked "4H")	2.40
474-310	Preheater Pan	.60
474-370	Burner Manifold (With Main & Sub-flame Burner Caps)	3.00
474-389	Preheater Generator (Gas Tip Marked "N")	.30
474-491	Door Complete	3.00





Parts No.	Name of Part	Net Retail Price
474-503	Hexagon Brass Nut (3/8"—No. 27)	.06
474-509	Pump Leather 2 for	.09
474-510	Pump Plunger Lower Washer	.03
414-512	Pump Handle	.09
474-515	Air Stem	.30
474-517	Handle Nut	.06
474-555	Pump Plunger Complete (Less Air Stem)	1.20
474-657	Tank Fuel & Preheater Valve Complete	1.35
475-323	Main Burner Cap (7/8") 2 for	.09
549-218	Gas Tip (Marked "N")	.06
605-950	Wrench	.15
650-131	Filler Plug Cap (Only)	.45
650-135	Filler Plug Disc, Gasket & Screw	.30
650-136	Filler Plug Gasket 2 for	.09
650-140	Filler Plug Complete	.75

Coleman Radiant Heater, Model No. 2

Parts No.	Name of Part	Net Retail Price
307-901	Alcohol Bottle (Only)	.12
451-131	Filler Plug Cap (Only)	.45
451-132	Filler Plug Air Stem	.18
451-139	Filler Plug Core & Gasket	.30
451-140	Filler Plug Complete	.75
451-504	Pump Barrel Top Plug	.09
451-509	Pump Leather	.06
451-522	Jumbo Pump	1.35
471-322	Sub-flame Burner Cap (5/8") 2 for	.09
471-906	Alcohol Torch Wick 2 for	.09
472-125	Air Gauge	1.20
472-128	Stove Bolt (13/16"x16" R. H.)	.09
472-169	Drip Pan & Brackets	1.20
472-170	Drip Pan, Brackets, Gen. Clamps, Bolts & Nuts	1.80
472-171	Fuel Tube (6½" Long)	.42
472-189	Tank Complete (With Fittings)	5.70
472-193	Tank, Drip Pan & Generator Complete Assembled	9.60
472-233	Generator Clamps, Bolt & Nut	.12
472-238	Cleaning Needle & Holder 2 for	.09
472-262	Generator (Gas Tip Marked "4B")	2.40
472-303	Radiant	.24
472-308	Drain Plug Stem	.09
472-367	Drain Plug Complete	.24
472-370	Burner Manifold (With Drain Plug, Main & Sub-flame Burner Caps)	3.00
472-403	Radiant Back (Aluminum)	2.10
472-405	Front Foot	.30
472-406	Post Top Cap	.18
472-407	Post Top	.18
472-408	Frame Trim (Right)	.60
472-409	Frame Trim (Left)	.60
472-410	Post Bolt	.09
472-415	Door Trim	1.50
472-417	Top (Porcelain)	1.20
472-418	Top Trim (Right)	.60
472-419	Top Trim (Left)	.60
472-420	Radiant Holder (Top)	.36
472-421	Key Chain (Only)	.12





Parts No.	Name of Part	Net Retail Price
472-423	Door Handle Name Plate	.36
472-435	Top Tie Rod	.09
472-436	Top Tie Rod Nut	.03
472-473	Bail	.24
472-480	Guard	1.05
472-489	Key & Ring	.12
472-491	Door Complete	3.00
472-651	Tank Fuel Valve Stem Complete	.30
472-657	Tank Fuel Valve Complete	.90
472-920	Alcohol Bottle Cap & Wicks	.75
472-925	Alcohol Torch Complete (Bottle, Cap, Wick, Chain & Snuffer)	.96
475-323	Main Burner Cap (7/8") 2 for	.09
502-218	Gas Tip (Marked "4B")	.12
605-950	Wrench	.15
650-136	Filler Plug Gasket 2 for	.09

Parts List for

Coleman Hot-Ray Heater, Model No. 48







Parts No.	Name of Part
R55	Rotary Generator (Gas Tip Marked "J") (155-299)
115-136	Filler Plug Gasket
120-145	Lamp Handle
120-147	Handle Lock Nut
120-160	Fuel Wire With Fuel Tube
120-165	Fount Complete
155-218	Gas Tip (Marked "J")
204-139	Filler Plug Disc, Gasket & Screw
204-140	Filler Plug Complete
216-509	Pump Leather
216-520	Pump Plunger Complete (Less Air Stem)
216-532	Air Stem
216-538	Check Valve
480-171	Fuel Tube (5" Long)
480-361	Vaporizing Tube
480-362	Burner Cap Complete
480-364	Filler Rod & Wick
480-374	Radiant
480-399	Burner Unit Complete (With Generator)
480-407	Reflector
480-450	Lock Wheel
480-480	Guard
480-490	Burner Unit, Radiant & Reflector Complete
480-653	Valve Stem Complete
480-654	Valve Body
480-657	Fuel Valve Complete
480-903	Alcohol Bottle (Only)
480-913	Alcohol Torch (Only)
480-920	Alcohol Torch & Bottle Complete
605-950	Wrench

Air-O-Gas Stove

Parts List
No. 22

See Pages 32 to 63

▼

Illustrations and Prices of Parts for all 1926, 1927, 1928 and 1929 Models of

Coleman Air-O-Gas
PRESSURE STOVES

Successor to Air-O-Gas
Parts Book No. 2A

Coleman Air-O-Gas Range, Model No. 322 (1929)

(Continued)

Parts No.	Name of Part	Net Retail Price
329-262	Main Generator (Gas Tip Marked "A4")	2.40
364A467	Tank Bracket (2 Piece) (Gray)	.30
366-172	Preheater Fuel Tube (26⅞" Long)	.36
366-174	Fuel Tube (6" Long)	.30
366-250	Wheel & Nut (Mahogany, Bake-Lite)	.30
*366-320	Mixing Chamber (R. H. Oven)	.90
*366-321	Mixing Chamber (L. H. Oven)	.90
366-323	Simmering Burner Cap	.60
*366-326	Burner Manifold (Casting Only) (R. H. Oven)	2.25
*366-327	Burner Manifold (Casting Only) (L. H. Oven)	2.25
366-332	Coupling Gasket	.06
*366-340	Mixing Chamber (R. H. Oven)	.96
*366-341	Mixing Chamber (L. H. Oven)	.96
366-344	Oven Burner Rear Bracket	.09
366-346	Oven Burner Ell	.45
366-347	Oven Burner Front Bracket	.09
*366 368	Sub-flame Burner & Drain Plug (R. H. Oven)	1.35
366-372	Oven Burner	2.40
366-373	Oven Burner Pilot Lighter	.36
*366-375	Sub-flame Burner & Drain Plug (L. H. Oven)	1.35
**366-383	Preheater Complete (Less Preheater Fuel Tube)	2.10
366-385	Auxiliary Burner Valve Stem Complete (Short)	.75
*366-439	Oven Burner Lighter Baffle (R. H. Oven)	.15
*366-440	Oven Burner Lighter Baffle (L. H. Oven)	.15
471-238	Cleaning Needle & Holder	2 for .09
472-308	Drain Plug Stem	.09
472-367	Drain Plug Complete	.24
599-936	Tee (⅛" S. A. E.)	.24
605-950	Wrench	.15
242	Oven Rack	.90
285	Broiler Pan Rack	.60
408	Oven Door Catch (Steel)	.09
535	Top Guard Holder	.06
645	Broiler Door Spring	.09
646	Oven Door Spring Hook	.15
647	Broiler Door Spring Hook	.15
661	Oven Door Spring	.09
1030	Broiler Pan	3.90
1193	White High Shelf	2.70
1575	Front Leg White (18" Over All)	1.80
1575	Rear Leg Black (18" Over All)	1.80
1744	Black Base Band	4.80
*1745	White Body Side	4.80
*1746	White Side Splasher	4.20
1749	Oven Body Back	2.10
1751	White Main Front	4.50
1754	Burner Box Bottom	2.10
1755	White Top Guard	2.10
*1756	Side Lining (Body Side)	5.40
1758	Top Lining	2.70
1759	White Service Drawer Front	1.80
1760	Back Lining	2.70
1761	Broiler Bottom	1.95
1762-63	Oven Bottom Complete	5.40
1765	White Broiler Drawer Panel	3.00
1767	Broiler Door Lining	1.50
1771	Service Drawer Body (Less Front)	3.75
1801	Oven Door Channel	.75
1802	Broiler Door Channel	.60

Coleman Air-O-Gas Range, Model No. 322 (1929)



Parts No.	Name of Part	Net Retail Price
307-930	Carbon Scraper	.15
308-218	Gas Tip (Marked "A4")	.12
308-238	Cleaning Needle & Holder	2 for .09
312-332	Manifold Gasket	.06
318-218	Gas Tip (Marked "AO")	.12
318-233	Generator Saddle, Clamp, Bolt & Nut (7/32" High)	.12
322-174	Fuel Tube (7½" Long)	.36
322-175	Fuel Tube (26½" Long)	.48
322-321	Master Burner Cap Stop	.15
322-323	Master Burner Cap	1.35
322-327	Main Burner Bracket	.54
322-342	Sub-flame Nipple (¼"x8" Long)	.24
322A345	Oven Burner Supply Pipe (½"x8¾" Long)	.36
322-377	Auxiliary Burner Valve Stem Complete	.90
*322A380	Oven Burner Assembly	6.75
*322A399	Main Burner Assembly	16.50
*322-406	End Rail	.45
*322-414	Valve Panel	.60
*324-191	Tank Complete (With Fittings) (Gray) (See Note 1)	9.90
324-323	Burner Cap	1.20
328-263	Oven Generator (Gas Tip Marked "AO")	2.40
328-460	Oven Thermometer	1.35
328-653	Valve Stem Complete	.30
328-657	Fuel Tube Fuel Valve Complete	.90

Coleman Air-O-Gas Range, Model No. 322 (1

(Continued)

Parts No.	Name of Part
1804	White Drip Pan
1842	Lining Support
1886	White Oven Top
*2016	White Back Splasher
*2082	Side Lining (Splasher Side)
2084	White Oven Door Panel
2085	Oven Door Lining
*2236	Burner Box Back
*2237	Burner Box Tank End
*2238	Burner Box Oven End
2363	Full Angle Frame
2476	Front Leg White (19½" Over All)
2476	Rear Leg Black (19½" Over All)
5488	White Door Handle
5489	Door Hinge (Right)
5490	Door Hinge (Left)
5494	Door Hinge Bar (Right)
5495	Door Hinge Bar (Left)
5498	Spring Bar
5533	Oven Door Catch (Casting)
5596	Black High Shelf Trim (R. H. Oven)
5597	Black High Shelf Trim (L. H. Oven)
5684	White End Shelf
5686	Grate
5756	White Front Strip

* Specify if Left Hand Oven, otherwise parts for Right Hand Oven shipped.

** For No. 366-383 Preheater Parts, See Page No. 66.

Note 1—For No. 324-191 Tank Parts, See Page 64.

eman Air-O-Gas Range, Model No. 322 (1929)

*322A399 MAIN BURNER ASSEMBLY



BURNER AND GENERATOR PARTS FOR RANGE MODEL No. 322 (1929)
(With Right Hand Oven)

*322A380 OVEN BURNER ASSEMBLY



BURNER AND GENERATOR PARTS FOR RANGE MODEL No. 322 (1929)
(With Right Hand Oven)

pecify if Left Hand Oven, otherwise parts for Right Hand Oven will be shipped.

Parts List for

Coleman Air-O-Gas Range, Model No. 322 (



Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
307-930	Carbon Scraper
308-218	Gas Tip (Marked "A4")
308-238	Cleaning Needle & Holder
310-215	White Porcelain Wheel
310-410	Tank Bracket (Gray)
312-332	Manifold Gasket
318-218	Gas Tip (Marked "AO")
318-233	Generator Saddle, Clamp, Bolt & Nut (7/32")
322-174	Fuel Tube (7½" Long)
322-175	Fuel Tube (26½" Long)
322-321	Master Burner Cap Stop
*322-322	Mixing Chamber
322-323	Master Burner Cap
*322-326	Burner Manifold (Casting Only)
322-327	Main Burner Bracket
322-335	Auxiliary Burner Extension
322-337	Oven Burner Side Bracket
322-339	Master Burner Extension
*322-340	Mixing Chamber
322-342	Sub-flame Nipple (¼"x8" Long)
322-343	Oven Burner Front Bracket

Parts List for

leman Air-O-Gas Range, Model No. 322 (1928)

(Continued)

	Name of Part	Net Retail Price
44	Oven Burner Rear Bracket	.12
45	Oven Burner Supply Pipe (½"x9¼" Long)	.30
49	Oven Burner Pilot Lighter	.60
68	Sub-flame Burner & Drain Plug	1.05
69	Oven Burner	2.10
77	Auxiliary Burner Valve Stem Complete	.90
80	Oven Burner Assembly	6.75
83	Preheater Complete (Less Preheater Fuel Tube)	....
99	Main Burner Assembly	16.50
06	End Rail	.45
14	Valve Panel	.60
56	Lock Nut	.06
91	Tank Complete (With Fittings) (Gray) (See Note 1)	9.90
23	Burner Cap	1.20
63	Oven Generator (Gas Tip Marked "AO")	2.40
60	Oven Thermometer	1.35
53	Valve Stem Complete	.30
57	Fuel Tube Fuel Valve Complete	.90
52	Main Generator (Gas Tip Marked "A4")	2.40
72	Preheater Fuel Tube (26⅞" Long)	.36
74	Fuel Tube (6" Long)	.30
38	Cleaning Needle & Holder	2 for .09
08	Drain Plug Stem	.09
37	Drain Plug Complete	.24
6	Tee (⅜" S. A. E.)	.24
0	Wrench	.15
2	Oven Rack	.90
5	Broiler Pan Rack	.60
8	Oven Door Catch (Steel)	.09
5	Top Guard Holder	.06
5	Broiler Door Spring	.09
6	Oven Door Spring Hook	.15
7	Broiler Door Spring Hook	.15
1	Oven Door Spring	.09
0	Broiler Pan	3.90
3	White High Shelf	2.70
6	White End Shelf	1.50
5	Front Leg White (18" Over All)	1.80
5	Rear Leg Black (18" Over All)	1.80
4	White Base Band	4.80
5	Black Body Side	4.80
5	White Side Splasher	4.20
9	Oven Body Back	2.10
1	White Main Front	4.50
4	Burner Box Bottom	2.10
5	White Top Guard	2.10
6	Side Lining (Body Side)	5.40
3	Top Lining	2.70
9	White Service Drawer Front	1.80
0	Back Lining	2.70
1	Broiler Bottom	1.95
3	Oven Bottom Complete	5.40
5	White Broiler Door Panel	3.00
7	Broiler Door Lining	1.5e
1	Service Drawer Body (Less Front)	3.75
1	Oven Door Channel	.75
2	Broiler Door Channel	.60
	White Drip Pan	2.70
3	Lining Support	.15

Coleman Air-O-Gas Range, Model No. 322 (19

(Continued)

Parts No.	Name of Part
1886	White Oven Top
2015	Semi-Angle Frame
*2016	White Back Splasher
*2017	Burner Box Back
*2080	Burner Box Tank End
*2081	Burner Box Oven End
*2082	Side Lining (Splasher Side)
2084	White Oven Door Panel
2085	Oven Door Lining
5488	White Door Handle
5489	Door Hinge (Right)
5490	Door Hinge (Left)
5494	Door Hinge Bar (Right)
5495	Door Hinge Bar (Left)
5498	Spring Bar
5533	Oven Door Catch (Casting)
5596	Black High Shelf Trim (R. H. Oven)
5597	Black High Shelf Trim (L. H. Oven)
5686	Grate

* Specify if Left Hand Oven; otherwise, parts for Right Hand Oven shipped.

** For No. 322-383 Preheater Parts, See Page No. 66.

Note 1—For No. 324-191 Tank Parts, See Page 64.

Parts List for

eman Air-O-Gas Range, Model No. 322 (1928)

*No. 322-399 MAIN BURNER ASSEMBLY



BURNER AND GENERATOR PARTS FOR RANGE, MODEL No. 322 (1928)
(With Right Hand Oven)

*No. 322-380 OVEN BURNER ASSEMBLY



BURNER AND GENERATOR PARTS FOR RANGE MODEL No. 322 (1928)
(With Right Hand Oven)

ecify if Left Hand Oven otherwise parts for Right Hand Oven will be shipped.

Coleman Air-O-Gas Stove, Model Nos. 323, 32



STOVE MODEL No. 327





BURNER AND GENERATOR PARTS FOR STOVE MODEL No. 32



STOVE MODEL No. 326

Stove Model No. 323 Same as No. 326 but is Zinc Plated and has No. 331-483 Ga



BURNER AND GENERATOR PARTS FOR STOVE MODEL No. 326

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 323, 326, 327

	Name of Part	Net Retail Price
32—	Filler Plug Air Stem	.18
05—	Gas Tip Cleaning Needle	.06
44—	Grate (Open Type)	.60
18—	Gas Tip (Marked "A3")	.12
38—	Cleaning Needle & Holder	2 for .09
59—	Burner Manifold Bracket (2 Piece)	.12
30—	Carbon Scraper	.15
71—	Fuel Tube (6½" Long)	.30
33—	Generator Saddle, Clamp, Bolt & Nut ($1\frac{3}{16}$" High)	.12
26—	Burner Manifold (Casting Only)	2.70
45—	Drain Plug Complete	.24
60—	Auxiliary Valve Core Complete	.30
66—	Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
26—	Burner Manifold (Casting Only)	2.40
13—	Manifold End Plate	.06
32—	Manifold Gasket	.06
10—	Tank Bracket (Black)	.15
18—	Leg (Low Stove)	.15
07—	Stove Top (Less Name Plate)	2.85
62—	Main Generator (Gas Tip Marked "A3")	2.40
23—	Burner Cap	1.20
26—	Burner Manifold (Casting Only)	2.70
83—	Preheater Complete (Less Preheater Fuel Tube)	.75
54—	Grate (No Burn Type)	1.20
91—	Tank Complete (With Fittings) (Black)	9.90
07—	Stove Top (Less Name Plate)	2.40
11—	Burner Manifold Bracket	.12
09—	Drip Pan (Porcelain)	2.10
72—	Preheater Fuel Tube (12" Long)	.36
91—	Tank Complete (With Fittings) (Zinc Plated)	9.90
08—	Drain Plug Stem	.09
67—	Drain Plug Complete	.24
50—	Wrench	.15

* For No. 324-383 Preheater Parts, See Page No. 66.
** For Nos. 326-191 and 331-191 Tank Parts, See Page No. 64.

Coleman Air-O-Gas Stove, Model Nos. 324



STOVE MODEL No. 324



STOVE MODEL No. 3





BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 324,

Parts List for

eman Air-O-Gas Stove, Model Nos. 324, 325

	Name of Part	Net Retail Price
-Filler Plug Air Stem		.18
-Gas Tip Cleaning Needle		.06
-Grate (Open Type)		.60
-Gas Tip (Marked "A3")		.12
-Cleaning Needle & Holder	2 for	.09
-Drip Pan (Porcelain)		2.40
-Burner Manifold Bracket (2 Piece)		.12
-Carbon Scraper		.15
-Fuel Tube (6½" Long)		.30
-Generator Saddle, Clamp, Bolt & Nut ($\frac{13}{16}$" High)		.12
-Burner Manifold (Casting Only)		2.70
-Drain Plug Complete		.24
-Auxiliary Valve Core Complete		.30
-Auxiliary Burner Valve Stem Complete (With Disc & Handle)		.75
-Tank Bracket (Gray)		.15
-High Leg		.60
-Cabinet Door Complete		1.20
-Cabinet Door Knob		.09
-Stove Top (Less Name Plate)		2.85
-Tank Complete (With Fittings) (Gray)		9.90
-Main Generator (Gas Tip Marked "A3")		2.40
-Burner Cap		1.20
-Burner Manifold (Casting Only)		2.70
-Preheater Complete (Less Preheater Fuel Tube)		.75
-Splasher		2.40
-High Shelf		1.50
-High Shelf Support (Right)		.75
-High Shelf Support (Left)		.75
-High Shelf Trim (Right)		.75
-High Shelf Trim (Left)		.75
-Grate (No Burn Type)		1.20
-Preheater Fuel Tube (12" Long)		.36
-Preheater Complete (Less Preheater Fuel Tube) (See Note No. 1)		2.10
-Drain Plug Stem		.09
-Drain Plug Complete		.24
-Wrench		.15

* For No. 324-191 Tank Parts, See Page No. 64.

** For Nos. 324-383 and 362-383 Preheater Parts, See Page No. 66.

Note No. 1—Used on Stove Model No. 324 Only.

Coleman Air-O-Gas Stove, Model No. 32



STOVE MODEL NO. 328





BURNER AND GENERATOR PARTS FOR STOVE MODEL No. 3

Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
305-444	Grate (Open Type)
307-218	Gas Tip (Marked "A3")
307-238	Cleaning Needle & Holder
307-409	Drip Pan (Porcelain)
307-459	Burner Manifold Bracket (2 Piece)
307-930	Carbon Scraper
310-233	Generator Saddle, Clamp, Bolt & Nut (1 3/8" High)
310-360	Auxiliary Valve Core Complete
310-366	Auxiliary Burner Valve Stem Complete (With Disc & Handle)
310-410	Tank Bracket (Gray)
314-440	Splasher (Porcelain)
316-345	Iron Pipe Nipple (½"x5¾")
318-218	Gas Tip (Marked "AO")
318-233	Generator Saddle, Clamp, Bolt & Nut (7/32" High)
318-340	Mixing Chamber
318-342	Master Sub-flame Burner Nipple
318-343	Flange Coupling

Parts List for

Coleman Air-O-Gas Stove, Model No. 328

	Name of Part	Net Retail Price
344—	Flange Packing	.06
346—	Iron Pipe Ell (90°—½" I. P. S. Threads)	.36
368—	Master Sub-flame Burner & Drain Plug	1.05
369—	Auxiliary Sub-flame Burner & Nipple	.45
376—	Oven Burner Pilot Lighter	.90
345—	Oven Burner Drop Supply Pipe (½" I. P. S. Threads)	.90
407—	Stove Top (Less Name Plate)	2.85
191—	Tank Complete (With Fittings) (Gray)	9.90
262—	Main Generator (Gas Tip Marked "A3")	2.40
323—	Burner Cap	1.20
383—	Preheater Complete (Less Preheater Fuel Tube)	.75
454—	Grate (No Burn Type)	1.20
172—	Preheater Fuel Tube (12" Long)	.36
173—	Fuel Tube (17" Long) (Tee to Oven Generator)	.30
175—	Fuel Tube (2½" Long) (Tank to Tee or Tee to Main Generator)	.21
263—	Oven Generator (Gas Tip Marked "AO")	2.40
326—	Burner Manifold (Casting Only)	2.70
327—	Hood For Oven Burner Pilot Lighter	.09
380—	Oven Burner Complete (With Drain Plug, Pilot Lighter, Hood, Bolt & Nuts)	3.30
417—	Oven Door Catch (Casting)	.12
423—	High Leg	.75
425—	Oven Back Lining	.90
431—	Oven Door Handle	.60
432—	Oven Door Spring	.09
434—	Oven Door Catch (Steel)	.15
435—	Oven Door Spring Bar	.15
436—	Oven Top Lining	.90
449—	Oven Rack	.60
455—	Floor Baffle	.60
456—	Oven Door Lining	1.50
457—	Oven Door Front	4.20
458—	Oven Door Hinge (Right)	.36
459—	Oven Door Hinge (Left)	.36
460—	Oven Thermometer	1.35
461—	Oven Door Hinge Bar (Right)	.45
462—	Oven Door Hinge Bar (Left)	.45
463—	Oven Door Spring Hook	.06
468—	Oven Drip Pan	.45
469—	Oven Floor Baffle Complete (Baffle, Drip Pan & Mirror)	1.35
470—	Oven Bottom Complete (With Liner & Baffle)	2.40
472—	Oven Door Complete	7.50
476—	Oven Side Lining	1.20
553—	Valve Stem Complete	.30
557—	Fuel Tube Fuel Valve Complete	.90
441—	High Shelf	2.10
442—	High Shelf Support (Right)	.75
443—	High Shelf Support (Left)	.75
444—	High Shelf Trim (Right)	.75
445—	High Shelf Trim (Left)	.75
340—	Mixing Chamber	1.50
345—	Oven Burner Drop Supply Tube (⅞"—No. 27)	.90
346—	Iron Pipe Ell With Lug (90° Outlets—½" I. P. S. Threads & ⅞" No. 27)	.36
383—	Preheater Complete (Less Preheater Fuel Tube)	2.10
238—	Cleaning Needle & Holder	2 for .09
308—	Drain Plug Stem	.09
367—	Drain Plug Complete	.24
936—	Tee (5/16" S. A. E.)	.24
950—	Wrench	.15

* For No. 324-191 Tank Parts, See Page No. 64.
** For Nos. 324-383 and 362-383 Preheater Parts, See Page No. 66.

Coleman Air-O-Gas Stove, Model No. 32



STOVE MODEL No. 329



BURNER AND GENERATOR PARTS FOR STOVE MODEL No. 3

Parts List for

Coleman Air-O-Gas Stove, Model No. 329

s	Name of Part	Net Retail Price
04-905	Gas Tip Cleaning Needle	.06
05-444	Grate (Open Type)	.60
07-459	Burner Manifold Bracket (2 Piece)	.12
07-930	Carbon Scraper	.15
08-218	Gas Tip (Marked "A4")	.12
08-238	Cleaning Needle & Holder	2 for .09
10-171	Fuel Tube (6½" Long)	.30
10-233	Generator Saddle, Clamp, Bolt & Nut (1 3/8" High)	.12
10-360	Auxiliary Valve Core Complete	.30
10-366	Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
10-410	Tank Bracket (Gray)	.15
10-423	High Leg	.60
10-473	Cabinet Door Complete	1.20
12-322	Burner Manifold Extension (Casting Only)	2.25
12-326	Burner Manifold (Casting Only)	2.40
12-332	Manifold Gasket	.06
12-409	Drip Pan (Porcelain)	3.60
18-407	Stove Top (Less Name Plate)	3.30
24-191	Tank Complete (With Fittings) (Gray)	9 90
24-323	Burner Cap	1.20
24-383	Preheater Complete (Less Preheater Fuel Tube)	.75
24-442	High Shelf Support (Right)	.75
24-443	High Shelf Support (Left)	.75
24-444	High Shelf Trim (Right)	.75
24-445	High Shelf Trim (Left)	.75
24-454	Grate (No Burn Type)	1.20
28-172	Preheater Fuel Tube (12" Long)	.36
29-262	Main Generator (Gas Tip Marked "A4")	2.40
29-440	Splasher	3.60
29-441	High Shelf	2.25
72-308	Drain Plug Stem	.09
72-367	Drain Plug Complete	.24
05-950	Wrench	.15

* For No. 324-191 Tank Parts, See Page No. 64.
** For No. 324-383 Preheater Parts, See Page No. 66.

Coleman Air-O-Gas Stove, Model No. 33



STOVE MODEL No. 330





BURNER AND GENERATOR PARTS FOR STOVE MODEL No.

Parts List for

Coleman Air-O-Gas Stove, Model No. 330

	Name of Part		Net Retail Price
2—	Filler Plug Air Stem		.18
5—	Gas Tip Cleaning Needle		.06
4—	Grate (Open Type)		.60
8—	Gas Tip (Marked "A3")		.12
8—	Cleaning Needle & Holder	2 for	.09
9—	Burner Manifold Bracket (2 Piece)		.12
0—	Carbon Scraper		.15
1—	Fuel Tube (6½" Long)		.30
3—	Generator Saddle, Clamp, Bolt & Nut ($\frac{13}{16}$" High)		.12
5—	Burner Manifold (Casting Only)		2.70
5—	Drain Plug Complete		.24
0—	Auxiliary Valve Core Complete		.30
5—	Auxiliary Burner Valve Stem Complete (With Disc & Handle)		.75
0—	Tank Bracket (Black)		.15
7—	Stove Top (Less Name Plate)		2.85
2—	Main Generator (Gas Tip Marked "A3")		2.40
3—	Burner Cap		1.20
5—	Burner Manifold (Casting Only)		2.70
3—	Preheater Complete (Less Preheater Fuel Tube)		.75
0—	Splasher		2.40
1—	High Shelf Trim (Right)		.75
—	High Shelf Trim (Left)		.75
1—	Grate (No Burn Type)		1.20
—	Tank Complete (With Fittings) (Black)		9.90
0—	Drip Pan (Porcelain)		2.10
2—	Preheater Fuel Tube (12" Long)		.36
3—	High Leg		.60
—	Low Shelf		1.80
—	High Shelf		1.35
2—	High Shelf Support (Right)		.75
—	High Shelf Support (Left)		.75
—	Drain Plug Stem		.09
—	Drain Plug Complete		.24
—	Wrench		.15

* For No. 324-383 Preheater Parts, See Page No. 66.

** For No. 326-191 Tank Parts, See Page No. 64.

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 210, 211, 212, 213, 214



STOVE MODEL No. 212

Stove Model No. 211, same as above less High Back



STOVE MODEL No.

Stove Model No. 213, same less High Back



STOVE MODEL No. 210



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 210, 211, 212, 213, 214

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 210, 211, 212, 213, 214

	Name of Part	Net Retail Price
2	Filler Plug Air Stem	.18
5	Gas Tip Cleaning Needle	.06
4	Grate (Open Type)	.60
8	Gas Tip (Marked "A3")	.12
8	Cleaning Needle & Holder	2 for .09
9	Drip Pan (Porcelain)	2.40
9	Burner Manifold Bracket (2 Piece)	.12
0	Carbon Scraper	.15
1	Fuel Tube (6½" Long)	.30
9	Tank Complete (With Fittings) (Gray)	7.50
3	Generator Saddle, Clamp, Bolt & Nut ($\frac{13}{16}$" High)	.12
5	Burner Manifold (Casting Only)	2.70
5	Drain Plug Complete	.24
0	Auxiliary Valve Core Complete	.30
5	Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
[illegible]	Preheater Fuel Tube (19½" Long)	.36
3	Preheater Complete (Less Fuel Tube)	1.80
[illegible]	Tank Bracket (Gray)	.15
[illegible]	Leg (Low Stove)	.24
[illegible]	High Leg	.60
0	Splasher	2.40
[illegible]	High Shelf	1.50
[illegible]	High Shelf Support (Right)	.75
[illegible]	High Shelf Support (Left)	.75
[illegible]	High Shelf Trim (Right)	.90
[illegible]	High Shelf Trim (Left)	.90
[illegible]	Cabinet Door Complete	1.20
[illegible]	Stove Top (Less Name Plate)	2.85
[illegible]	Main Generator (Gas Tip Marked "A3")	2.40
[illegible]	Burner Cap	1.20
[illegible]	Grate (No Burn Type)	1.20
[illegible]	Jumbo Pump	1.35
[illegible]	Wrench	.15

* For No. 310-189 Tank Parts, No. 451-522 Pump Parts and No. 310-383 Preheater Parts, See Page No. 65.

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 224,



STOVE MODEL No. 225

Stove Model No. 224 Same as Above less High Back



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 224

Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
305-444	Grate (Open Type)
307-218	Gas Tip (Marked "A3")
307-238	Cleaning Needle & Holder
307-409	Drip Pan (Porcelain)
307-459	Burner Manifold Bracket (2 Piece)
307-930	Carbon Scraper

Parts List for

eman Air-O-Gas Stove, Model Nos. 224, 225

Name of Part	Net Retail Price
—Fuel Tube (6½" Long)	.30
—Tank Complete (With Fittings) (Gray)	7.50
—Generator Saddle, Clamp, Bolt & Nut (1/16" High)	.12
—Auxiliary Valve Core Complete	.30
—Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
—Preheater Complete (Less Fuel Tube)	1.80
—Tank Bracket (Gray)	.15
—High Leg	.60
—Manifold Gasket	.06
—Splasher (Porcelain)	6.00
—High Shelf	1.50
—High Shelf Support (Right)	.75
—High Shelf Support (Left)	.75
—High Shelf Trim (Right)	1.35
—High Shelf Trim (Left)	1.35
—Fuel Tube (11" Long)	.36
—Iron Pipe Nipple (½"x5¾")	.18
—Fuel Tube (8" Long)	.30
—Gas Tip (Marked "AO")	.12
—Generator Saddle, Clamp, Bolt & Nut (7/32" High)	.12
—Burner Manifold (Casting Only)	3.60
—Mixing Chamber	1.50
—Master Sub-flame Burner Nipple	.30
—Flange Coupling	.12
—Flange Packing	.06
—Iron Pipe Ell (90°—½" I. P. S. Threads)	.36
—Master Sub-flame Burner & Drain Plug	1.05
—Auxiliary Sub-flame Burner & Nipple	.45
—Oven Burner Pilot Lighter	.90
—Oven Door Frame	5.40
—Oven Back Lining	.75
—Oven Door Handle	.36
—Oven Door Catch (Steel) 2 for	.09
—Oven Top Lining	.75
—Oven Rack	.60
—Oven Door Front Panel	2.10
—Oven Door Hinge (Right)	.60
—Oven Door Hinge (Left)	.60
—Oven Thermometer	1.35
—Oven Bottom Complete (With Liner & Baffle)	3.00
—Oven Door Complete	9 00
—Oven Side Lining	1.80
—Burner Manifold Extension (Casting Only)	.....
—Oven Burner Drop Supply Pipe (½" I. P. S. Threads)	.90
—Stove Top (Less Name Plate)	2.85
—Main Generator (Gas Tip Marked "A3")	2.40
—Burner Cap	1.20
—Grate (No Burn Type)	1 20
—Oven Generator (Gas Tip Marked "AO")	2 40
—Burner Manifold (Casting Only)	2 70
—Hood For Oven Burner Pilot Lighter	.09
—Oven Burner Complete (With Drain Plug, Pilot Lighter, Hood, Bolt & Nuts)	3.30
—Jumbo Pump	1.35
—Cleaning Needle & Holder 2 for	.09
—Drain Plug Stem	09
—Drain Plug Complete	24
—Tee (3/16" S. A. E.)	.21
—Wrench	.15

* For No. 310-189 Tank Parts, No. 451-522 Pump Parts and No. 310-383 Preheater Parts, see Page No. 65.

** No. 321-322 is obsolete on Stove Model Nos. 224, 225. Supply No. 328-326

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 620, 621, 622, 623



STOVE MODEL No. 623

Stove Model No. 622, same as above less High Back.
Stove Model No. 621, Skeleton Legs with High Back.
Stove Model No. 620, Skeleton Legs less High Back.



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 62

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 620, 621, 622, 623

	Name of Part	Net Retail Price
2—	Filler Plug Air Stem	.18
5—	Gas Tip Cleaning Needle	.06
1—	Grate (Open Type)	.60
9—	Burner Manifold Bracket (2 Piece)	.12
1—	Carbon Scraper	.15
3—	Gas Tip (Marked "A4")	.12
3—	Cleaning Needle & Holder	2 for .09
1—	Fuel Tube (6½" Long)	.30
1—	Tank Complete (With Fittings) (Gray)	7.50
3—	Generator Saddle, Clamp, Bolt & Nut ($1\frac{3}{16}$" High)	.12
1—	Drain Plug Complete	.24
1—	Auxiliary Valve Core Complete	.30
5—	Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
1—	Preheater Fuel Tube (19½" Long)	.36
1—	Preheater Complete (Less Fuel Tube)	1.80
1—	Tank Bracket (Gray)	.15
1—	High Leg	.60
1—	High Shelf Support (Right)	.75
1—	High Shelf Support (Left)	.75
1—	High Shelf Trim (Right)	.90
1—	High Shelf Trim (Left)	.90
1—	Cabinet Door Complete	1.20
1—	Burner Manifold Extension (Casting Only)	2.25
1—	Burner Manifold (Casting Only)	2.40
1—	Manifold Gasket	.06
1—	Drip Pan (Porcelain)	3.60
1—	Splasher	4.50
1—	High Shelf	1.50
1—	Stove Top (Less Name Plate)	3.30
1—	Burner Cap	1.20
1—	Grate (No Burn Type)	1.20
1—	Main Generator (Gas Tip Marked "A4")	2.40
1—	Jumbo Pump	1.35
1—	Drain Plug Stem	.09
1—	Drain Plug Complete	.24
1—	Wrench	.15

* For No. 310-189 Tank Parts, No. 451-522 Pump Parts and No. 310-383 Preheater Parts, See Page No. 65

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 624,



STOVE MODEL No. 625

Stove Model No. 624, same as above less High Back



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 6

Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
305-444	Grate (Open Type)
307-459	Burner Manifold Bracket (2 Piece)
307-930	Carbon Scraper
308-218	Gas Tip (Marked "A4")
308-238	Cleaning Needle & Holder
310-171	Fuel Tube (6½" Long)

Parts List for

oleman Air-O-Gas Stove, Model Nos. 624, 625

	Name of Part	Net Retail Price
89	Tank Complete (With Fittings) (Gray)	7.50
33	Generator Saddle, Clamp, Bolt & Nut ($\frac{13}{16}$" High)	.12
60	Auxiliary Valve Core Complete	.30
66	Auxiliary Burner Valve Stem Complete (With Disc & Handle)	.75
83	Preheater Complete (Less Fuel Tube)	1.80
10	Tank Bracket (Gray)	.15
23	High Leg	.60
22	Burner Manifold Extension (Casting Only)	2.25
32	Manifold Gasket	.06
09	Drip Pan (Porcelain)	3.60
42	High Shelf Support (Right)	.75
43	High Shelf Support (Left)	.75
44	High Shelf Trim (Right)	1.35
45	High Shelf Trim (Left)	1.35
40	Splasher (Porcelain)	7.80
41	High Shelf	2.10
75	Fuel Tube (11" Long)	.36
45	Iron Pipe Nipple (½"x5¾")	.18
73	Fuel Tube (8" Long)	.30
8	Gas Tip (Marked "AO")	.12
33	Generator Saddle, Clamp, Bolt & Nut ($\frac{7}{32}$" High)	.12
6	Burner Manifold (Casting Only)	3.60
0	Mixing Chamber	1.50
2	Master Sub-flame Burner Nipple	.30
3	Flange Coupling	.12
4	Flange Packing	.06
5	Oven Burner Drop Supply Pipe (½" I. P. S. Threads)	.60
6	Iron Pipe Ell (90°—½" I. P. S. Threads)	.36
8	Master Sub-flame Burner & Drain Plug	1.05
9	Auxiliary Sub-flame Burner & Nipple	.45
6	Oven Burner Pilot Lighter	.90
7	Stove Top (Less Name Plate)	3.30
2	Cabinet Door Knob	.09
7	Oven Door Frame	5.40
5	Oven Back Lining	.75
1	Oven Door Handle	.36
4	Oven Door Catch (Steel)	2 for .09
6	Oven Top Lining	.75
9	Oven Rack	.60
7	Oven Door Front Panel	2.10
8	Oven Door Hinge (Right)	.60
9	Oven Door Hinge (Left)	.60
0	Oven Thermometer	1.35
7	Oven Bottom Complete (With Liner & Baffle)	3.00
2	Oven Door Complete	9.00
8	Cabinet Door Complete	.90
5	Oven Side Lining	1.80
8	Burner Cap	1.20
4	Grate (No Burn Type)	1.20
8	Oven Generator (Gas Tip Marked "AO")	2.40
7	Hood For Oven Burner Pilot Lighter	.09
0	Oven Burner Complete (With Drain Plug, Pilot Lighter, Hood, Bolt & Nuts)	3.30
2	Main Generator (Gas Tip Marked "A4")	2.40
2	Jumbo Pump	1.35
3	Cleaning Needle & Holder	2 for .09
3	Drain Plug Stem	.09
7	Drain Plug Complete	.24
6	Tee ($\frac{3}{16}$" S. A. E.)	.24
0	Wrench	.15

* For No. 310-189 Tank Parts, No. 451-522 Pump Parts and No. 310-383 Preheater Parts, See Page No. 65.

Coleman Air-O-Gas Stove, Model Nos. 120,



STOVE MODEL No. 120

Stove Model No. 121, same as above with No. 313-483 Galley Rail



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 12

Parts List for

eman Air-O-Gas Stove, Model Nos. 120, 121

	Name of Part	Net Retail Price
—Gas Tip Cleaning Needle		.06
—Stove Grate (Open Type)		.60
—Gas Tip (Marked "A3")		.12
—Cleaning Needle & Holder	2 for	.09
—Carbon Scraper		.15
—Fuel Tube (6½" Long)		.30
—Generator Saddle, Clamp, Bolt & Nut ($1\frac{3}{16}$" High)		.12
—Auxiliary Valve Core Complete		.30
—Auxiliary Burner Valve Stem Complete (With Disc & Handle)		.75
—Preheater Fuel Tube (19½" Long)		.36
—Preheater Complete (Less Fuel Tube)		1.80
—Burner Manifold (Casting Only)		2.40
—Tank Complete (With Fittings) (Black)		7.50
—Manifold End Plate		.06
—Manifold Gasket		.06
—Stove Top (Less Name Plate)		2.40
—Tank Bracket (Black)		.15
—Burner Manifold Bracket		.24
—Leg (Low Stove)		.15
—Galley Rail		3.00
—Main Generator (Gas Tip Marked "A3")		2.40
—Burner Cap		1.20
—Grate (No Burn Type)		1.20
—Jumbo Pump		1.35
—Drain Plug Stem		.09
—Drain Plug Complete		.24
—Wrench		.15

* For No. 313-189 Tank Parts, No. 451-522 Pump Parts, and No. 310-383 Preheater Parts, See Page No. 65.

Coleman Air-O-Gas Stove, Model Nos. 200, 201, 202, 203, 204



STOVE MODEL No. 204

Stove Model No. 203, same as above less High Back



STOVE MODEL No

Stove Model No. 201, sam
less High Back

Stove Model No. 200, sam
less High Back and Skele



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 200, 201, 202, 203, 204

Parts List for

Coleman Air-O-Gas Stove, Model Nos. 200, 201, 202, 203, 204

	Name of Part	Net Retail Price
44—	Grate (Open Type)	.60
71—	Fuel Tube (5¾" Long)	..48
89—	Tank Complete (With Fittings) (Black)	7.50
18—	Gas Tip (Marked "A3"")	.12
33—	Generator Saddle, Clamp, Bolt & Nut (13/16" High)	.12
38—	Cleaning Needle & Holder	2 for .09
52—	Main Generator (Gas Tip Marked "A3")	2.40
25—	Auxiliary Valve Opener Knob	.09
76—	Burner Manifold (Casting Only)	2.55
15—	Drain Plug Complete	.45
10—	Auxiliary Burner Valve Core	.24
15—	Auxiliary Burner Valve Opener (Less Knob)	.30
19—	Drip Pan (Porcelain)	2.40
13—	High Leg	.60
10—	Splasher	2.40
11—	High Shelf	1.50
12—	High Shelf Support (Right)	.75
13—	High Shelf Support (Left)	.75
14—	High Shelf Trim (Right)	.90
15—	High Shelf Trim (Left)	.90
19—	Burner Manifold Bracket (2 Piece)	.12
——	Alcohol Bottle (Only)	.12
10—	Carbon Scraper	.15
10—	Tank Bracket (Black)	.15
7—	Stove Top (Less Name Plate)	2.85
——	Burner Cap	1.20
——	Jumbo Pump	1.35
——	Alcohol Torch Wick	2 for .09
——	Alcohol Bottle Cap & Wicks	.75
——	Alcohol Torch Complete (Bottle, Cap, Wick, Chain & Snuffer)	.96
—	Wrench	.15

* For No. 307-189 Tank Parts and No. 451-522 Pump Parts, See Page No. 65.

Coleman Air-O-Gas Stove, Model Nos. 600, 60



AIR-O-GAS STOVE, MODEL No. 602

Stove Model No. 601, same as above less High Back.
Stove Model No. 600, Same as above less High Back and Cabinet.



BURNER AND GENERATOR PARTS FOR STOVE MODEL Nos. 600, 601

Parts List for

nan Air-O-Gas Stove, Model Nos. 600, 601, 602

Name of Part	Net Retail Price
-Grate (Open Type)	.60
-Tank Complete (With Fittings) (Black)	7.50
-Generator Saddle, Clamp, Bolt & Nut ($1\frac{3}{16}$" High)	.12
-Auxiliary Valve Opener Knob	.09
-Drain Plug Complete	.45
-Auxiliary Burner Valve Core	.24
-Auxiliary Burner Valve Opener (Less Knob)	.30
-High Leg	.60
-High Shelf Support (Right)	.75
-High Shelf Support (Left)	.75
-High Shelf Trim (Right)	.90
-High Shelf Trim (Left)	.90
-Alcohol Bottle (Only)	.12
-Carbon Scraper	.15
-Fuel Tube (14¼" Long)	.60
-Gas Tip (Marked "A4")	.12
-Cleaning Needle & Holder — 2 for	.09
-Main Generator (Gas Tip Marked "A4")	2.40
Mixing Chamber	1.20
Burner Manifold (Casting Only)	3.00
Auxiliary Burner Valve Opener (Less Knob)	.45
Stove Top (Less Name Plate)	4.35
Drip Pan (Porcelain)	3.00
Burner Bracket	.15
Splasher	2.25
High Shelf	1.05
Tank Bracket (Black)	.15
Burner Cap	1.20
Jumbo Pump	1.35
Alcohol Torch Wick — 2 for	.09
Alcohol Bottle Cap & Wicks	.75
Alcohol Torch Complete (Bottle, Cap, Wick, Chain & Snuffer)	.96
Wrench	.15

* For No. 307-189 Tank Parts and No. 451-522 Pump Parts, See Page No. 65.

Coleman Air-O-Gas One Gallon Stove T
Nos. 324-191, 326-191, 331-191

Parts No.	Name of Part	Net Retail Price
117-144	Tip Protector & Screen	.15
216-538	Check Valve	.15
324-115	Combination Fuel & Air Gauge	1.80
†324-191	Tank Complete (With Fittings) (Gray)	9.90
324-353	Preheater Tank Valve Stem Complete	.30
324-357	Preheater Tank Valve Complete (Fuel Tip Marked "F")	.90
324-648	Indicator Handle & Screw (Right Hand Tank)	.15
324-649	Indicator Handle & Screw (Left Hand Tank)	.15
**324-653	Tank Fuel Valve Stem Complete	.30
324-657	Tank Fuel Valve Complete	.75
‡326-191	Tank Complete (With Fittings) (Black)	9.90
§331-191	Tank Complete (With Fittings) (Zinc Plated)	9.90
366-118	Fuel Tip (Marked "F")	.06
*366-379	Tank Preheater Ell Body Assembly	
474-109	Air Stem Spring	.03
474-503	Hex. Brass Nut (⅜", No. 27)	.06
474-509	Pump Leather ....2 for	.09
474-510	Pump Plunger Lower Washer	.03
474-512	Pump Handle	.09
474-515	Air Stem	.30
474-517	Handle Nut	.06
474-555	Pump Plunger Complete (Less Air Stem)	1.20
650-131	Filler Plug Cap (Only)	.45
650-135	Filler Plug Disc, Gasket & Screw	.30
650-136	Filler Plug Gasket....2 for	.09
650-140	Filler Plug Complete	.75

* Obsolete—Supply No. 324-357.

** No. 324-653 Valve Stem illustrated in Fig No. 3 cannot be used with No. 324-657 Tank Fuel Valve illustrated in Fig. Nos. 1 and 2.

† No. 324-191 Tank is used on Air-O-Gas Stove Model Nos. 324, 325, 328, 329 and Range Model No. 322. When ordering Tank for Range Model No. 322 specify if Left Hand Oven otherwise parts for Right Hand Oven will be shipped.

‡ No. 326-191 Tank for use on Air-O-Gas Stove Model Nos. 326, 327, 330.

§ No. 331-191 Tank for use on Air-O-Gas Stove Model No. 323.



Fig. No. 1



Fig. No. 2



Fig. No. 3

Note: Fig. Nos. 2 and 3 illus
style tanks which have been re
tank illustrated in Fig. No.
Stove Tanks have had several
cal changes in fuel and preheat
Study the illustrations and ch
bers carefully to avoid error in
parts, also state color of tank
gray, black or zinc plated, when
tank complete.

man Stove Tanks, Nos. 307-189, 310-189, 313-189
Jumbo Pump No. 451-522

VE TANK No. 307-189 (Black)



Name of Part	Net Retail Price
9—Tank Complete (With Fittings) (Black)	7.50
7—Tank Fuel Valve Complete	.75
0—Tank Bracket (Black)	.15
2—Filler Plug Air Stem	.18
9—Filler Plug Core & Gasket	.30
0—Filler Plug Complete	.75
4—Pump Barrel Top Plug	.09
9—Pump Leather	.06
2—Jumbo Pump	1.35
3—Tank Fuel Valve Stem Complete	.30
5—Air Gauge	1.20
6—Filler Plug Gasket 2 for	.09

7-189 Tank illustrated is obsolete. -189 Tank is made by using No. Tank (With 307-657 Tank Fuel Valve)

ir-O-Gas Stove Model Nos. 200, 201, 204, 600, 601, 602.

STOVE TANK Nos. 310-189 (Gray), 313-189 (Black)



Parts No.	Name of Part	Net Retail Price
310-115	Fuel Gauge	1.65
*310-189	Tank Complete (With Fittings) (Gray)	7.50
310-657	Tank Fuel Valve Complete	1.05
**313-189	Tank Complete (With Fittings) (Black)	7.50
451-132	Filler Plug Air Stem	.18
451-139	Filler Plug Core & Gasket	.30
451-140	Filler Plug Complete	.75
451-504	Pump Barrel Top Plug	.09
451-509	Pump Leather	.06
451-522	Jumbo Pump	1.35
471-653	Tank Fuel Valve Stem Complete	.30
472-125	Air Gauge	1.20
650-136	Filler Plug Gasket 2 for	.09

*For Air-O-Gas Stove Model Nos. 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625.

**For Air-O-Gas Stove Model Nos. 120, 121.

H-LITE EATER 10-383



Used on Stove Model Nos. 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625

Parts No.	Name of Part	Net Retail Price
310-305	Preheater Support Rod	.12
310-307	Preheater Valve Body (Only)	.60
310-310	Preheater Pan	.36
310-353	Preheater Valve Stem Complete	.30
310-357	Preheater Valve Complete	1.20
310-383	Preheater Complete (Less Fuel Tube)	1.80
310-389	Preheater Generator (Gas Tip Marked "N")	.36
549-218	Gas Tip (Marked "N")	.06

Parts List for

Coleman Air-O-Gas Stove & Range
Instant-Lite Preheaters

INSTANT-LITE PREHEATER No. 322-383
Used on Range Model No. 322



Parts No.	Name of Part	Net Retail Price
104-210	Jamb Nut	.03
104-905	Gas Tip Cleaning Needle	.06
140-617	Lock Nut	.03
322-304	Preheater Flame Spreader	.30
322-310	Preheater Pan	.60
322-376	Preheater Bracket	.60
*322-383	Preheater Complete (Less Preheater Fuel Tube)	.....
324-303	Connection (Preheater Fuel Tube to Preheater Generator)	.15
324-389	Preheater Generator (Less Jamb Nut) (Gas Tip Marked "S")	.24
475-318	Gas Tip (Marked "S")	.06

*No. 322-383 Preheater Complete is obsolete. Order No. 366-383.

INSTANT-LITE PREHEATER No. 324-383
Used on Stove Model Nos. 323, 324, 325, 326, 327, 328, 329, 330



Parts No.	Name of Part	Net Retail Price
104-210	Jamb Nut	.03
104-905	Gas Tip Cleaning Needle	.06
140-617	Lock Nut	.03
324-303	Connection (Preheater Fuel Tube to Preheater Generator)	.15
324-310	Preheater Pan	.30
324-319	Preheater Bracket	.12
324-383	Preheater Complete (Less Preheater Fuel Tube)	.75
324-389	Preheater Generator (Less Jamb Nut) (Gas Tip Marked "S")	.24
475-318	Gas Tip (Marked "S")	.06

INSTANT-LITE PREHEATER No. 3
Used on Range Model



Parts No.	Name of Part
104-210	Jamb Nut
322-304	Preheater Flame Spre
322-310	Preheater Pan
366-303	Flame Conductor
366-350	Preheater Valve Stem Extension
366-353	Preheater Valve Stem Complete (Less Ex
366-354	Preheater Valve Bod
366-357	Preheater Valve & G Complete (Less Ex
366-376	Preheater Bracket
366-383	Preheater Complete (Preheater Fuel Tub
366-399	Preheater Generator (Needle) (Less Jam (Gas Tip Marked "S
475-318	Gas Tip (Marked "S"

INSTANT-LITE PREHEATER No. 362
Used on Stove Model



Parts No.	Name of Part
104-210	Jamb Nut
324-310	Preheater Pan
362-350	Preheater Valve Stem Extension
362-376	Preheater Bracket
362-383	Preheater Complete (L Preheater Fuel Tube)
366-353	Preheater Valve Stem Complete (Less Exte
366-354	Preheater Valve Body
366-357	Preheater Valve & Ger Complete (Less Exte
366-399	Preheater Generator (W Needle) (Less Jamb (Gas Tip Marked "S"
475-318	Gas Tip (Marked "S")

Coleman Water Heater, Model No. 1

(WITH TWO OR FOUR COILS)



WATER HEATER, MODEL No. 1
(With Two Coils)

	Name of Part	Net Retail Price
143	Stove Bolt ($\frac{3}{16}$"x½" R. H.)	.03
905	Gas Tip Cleaning Needle	.06
653	Valve Stem Complete	.30
215	White Porcelain Wheel	.15
218	Gas Tip (Marked "AO")	.12
417	Stove Bolt Nut ($\frac{3}{16}$" Square)	.03
401	Water Heater Jacket Top	.60
402	Water Heater Jacket Door (With Latch)	3.00
403	Water Heater Jacket Back	2.40
404	Water Heater Jacket Door Latch	.30
405	Water Heater Jacket Complete	5.25
411	Water Heater Coil & Two Gaskets (⅜") (Takes 4)	2.10
415	Manifold, Four Gaskets & Lock Nut	1.50
427	Burner Bracket	.15
424	Coils & Manifolds (Two), Lock Nuts (Two) Assembled	8.25
538	Cleaning Needle & Holder — 2 for	.09
418	Gas Tip (Marked "S")	.06
403	Generator Clean-Out Plug	.09
423	Filler Coil & Asbestos Cord	.15
437	Generator Tee & Bushing	.30
411	Generator Valve Clean-Out Plug	.06
462	Generator (Gas Tip Marked "AO")	3.30
426	Burner Base	1.35
423	Burner Cap	1.50
489	Preheater Generator (Gas Tip Marked "S")	.42
429	Preheater Fuel Tube (10¼" Long)	.36
477	Preheater Pan (With Flame Deflector)	.90
483	Preheater Complete (Less Preheater Fuel Tube)	1.80
457	Preheater Valve Complete	.75
401	Hexagon Brass Stove Bolt Nut ($\frac{3}{16}$") (12-24) — 2 for	.06
402	Stove Bolt ($\frac{3}{16}$"x¾" R. H.) — 2 for	.06
424	Stove Bolt ($\frac{3}{16}$"x¾" F. H.) — 2 for	.06
450	Wrench	.15

* For Water Heater Model No. 1 with Four Coils.

Coleman Handy Gas Plant, Model No.



Parts No.	Name of Part
104 - 905	Gas Tip Cleaning Needle
305 - 653	Valve Stem Complete
310 - 215	White Porcelain Wheel
318 - 218	Gas Tip (Marked "AO")
451 - 104	Iron Pipe Nipple (3/8"x4")
451 - 112	Tank Fuel Valve Complete
451 - 132	Filler Plug Air Stem
451 - 139	Filler Plug Core & Gasket
451 - 140	Filler Plug Complete
451 - 326	Burner Base
451 - 373	Grate & Brackets
451 - 399	Burner, Generator & Grate
451 - 504	Pump Barrel Top Plug
451 - 509	Pump Leather
451 - 522	Jumbo Pump
452 - 171	Fuel Tube (7" Long)
452 - 189	Tank Complete (With Fittings)
471 - 238	Cleaning Needle & Holder
475 - 318	Gas Tip (Marked "S") (For Preheater Generator)
501 - 203	Generator Clean-Out Plug
501 - 223	Filler Coil & Asbestos Cord
501 - 237	Generator Tee & Bushing
514 - 211	Generator Valve Clean-Out Plug
514 - 262	Generator (Gas Tip Marked "AO")
543 - 323	Burner Cap
544 - 289	Preheater Generator (Gas Tip Marked "S")
544 - 329	Preheater Fuel Tube (10¼" Long)
544 - 377	Preheater Pan (With Flame Deflector)
544 - 383	Preheater Complete (Less Preheater Fuel Tube)
544 - 657	Preheater Valve Complete
545 - 301	Hexagon Brass Stove Bolt Nut (3/16") (12-24)
545 - 302	Stove Bolt (3/16"¾" R. H.)
545 - 324	Stove Bolt (3/16"x¾" F. H.)
605 - 950	Wrench
650 - 136	Filler Plug Gasket
650 - 651	Valve Stem Complete

Special Handy Gas Plants have been made by substituting some of the Co
Burners shown on pages 70-71. Burner and Generator Repairs for such special
Plants should be ordered from the parts list on pages 70-73.

Coleman Utility Burner, Model No. 454
Coleman Soldering Furnace, Model No. 456



COLEMAN UTILITY BURNER
MODEL No. 454

Parts No.	Name of Part	Net Retail Price
115-136—	Filler Plug Gasket ..... 2 for	.06
117-144—	Tip Protector & Screen	.15
216-509—	Pump Leather ..... 2 for	.09
216-532—	Air Stem	.15
216-538—	Check Valve	.15
405-365—	Burner Cap (2 Piece, Bolt & Nut)	.30
454-118—	Fuel Tip (Marked "Y")	.06
454-148—	Fuel Wire (Fuel Tip Marked "Y")	.54
454-158—	Connection (Fuel Wire to Fuel Tube)	.45
454-165—	Fount Complete	6.60
454-171—	Fuel Tube (3⅛" Long)	.30
454-218—	Gas Tip (Marked "T")	.15
454-238—	Cleaning Needle & Holder ..... 2 for	.09
454-256—	Generator Valve Stem Complete	.60
454-262—	Generator (Gas Tip Marked "T")	1.20
454-326—	Burner Manifold (Less Burner Cap)	1.20
454-370—	Burner Manifold & Burner Cap	1.50
454-404—	Baffle Brace	.09
454-413—	Generator Clamp	.06
454-423—	Bail	.09
454-427—	Base Lock Nut	.06
454-444—	Grate	.45
454-460—	Baffle	.60
476-140—	Filler Plug Complete	.48
476-520—	Pump Plunger Complete (Less Air Stem)	.60
605-950—	Wrench	.15



COLEMAN SOLDERING FURNACE
MODEL No. 456

Parts No.	Name of Part	Net Retail Price
101-522—	Pump	.75
115-136—	Filler Plug Gasket ..... 2 for	.06
115-138—	Filler Plug Core & Gasket	.30
117-144—	Tip Protector & Screen	.15
216-509—	Pump Leather ..... 2 for	.09
216-532—	Air Stem	.15
216-538—	Check Valve	.15
405-365—	Burner Cap (2 Piece, Bolt & Nut)	.30
454-118—	Fuel Tip (Marked "Y")	.06
454-148—	Fuel Wire (Fuel Tip Marked "Y")	.54
454-158—	Connection (Fuel Wire to Fuel Tube)	.45
454-171—	Fuel Tube (3⅛" Long)	.30
454-218—	Gas Tip (Marked "T")	.15
454-238—	Cleaning Needle & Holder ..... 2 for	.09
454-256—	Generator Valve Stem Complete	.60
454-262—	Generator (Gas Tip Marked "T")	1.20
454-326—	Burner Manifold (Less Burner Cap)	1.20
454-370—	Burner Manifold & Burner Cap	1.50
454-413—	Generator Clamp	.06
454-427—	Base Lock Nut	.06
456-132—	Filler Plug Air Stem	.18
456-164—	Filler Plug Complete	.60
456-165—	Fount Complete	6.60
456-462—	Iron Support Complete	.45
456-465—	Frame & Bail Complete	2.10
476-520—	Pump Plunger Complete (Less Air Stem)	.60
605-950—	Wrench	.15

Parts List for

Coleman Urn Burners, Model Nos. 404, 50



URN BURNER, MODEL No.
(Uses 4-inch Burner Cap)

Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
305-653	Valve Stem Complete
475-318	Gas Tip (Marked "S")
*514-263	Generator (Gas Tip Marked "4B")
540-923	Burner Cap
540-926	Burner Base
543-328	Generator Clamp
544-289	Preheater Generator (Gas Tip Marked "S")
544-329	Preheater Fuel Tube (10¼" Long)
544-375	Preheater Nipple & Screen
544-377	Preheater Pan (With Flame Deflector)
544-383	Preheater Complete (Less Preheater Fuel Tube)
544-657	Preheater Valve Complete
545-301	Hexagon Brass Stove Bolt Nut (3/16") (12-24)
545-302	Stove Bolt (3/16"x¾" R. H.)
545-303	Stand Base
545-304	Iron Pipe Nipple (⅜"x3")
545-324	Stove Bolt (3/16"x¾" F. H.)

* For Parts List for No. 514-263 Generator, See Page No. 72.



URN BURNER, MODEL No.
(Uses 5-inch Burner Cap)

Parts No.	Name of Part
104-905	Gas Tip Cleaning Needle
305-653	Valve Stem Complete
475-318	Gas Tip (Marked "S")
*514-262	Generator (Gas Tip Marked "AO")
540-326	Burner Base
543-323	Burner Cap
543-328	Generator Clamp
544-289	Preheater Generator (Gas Tip Marked "S")
544-329	Preheater Fuel Tube (10¼" Long)
544-375	Preheater Nipple & Screen
544-377	Preheater Pan (With Flame Deflector)
544-383	Preheater Complete (Less Preheater Fuel Tube)
544-657	Preheater Valve Complete
545-301	Hexagon Brass Stove Bolt Nut (3/16") (12-24)
545-302	Stove Bolt (3/16"x¾" R. H.)
545-303	Stand Base
545-304	Iron Pipe Nipple (⅜"x3")
545-324	Stove Bolt (3/16"x¾" F. H.)

* For Parts List for No. 514-262 Generator, See Page No. 72.

Coleman Urn Burners, Model Nos. 707, 4, 5



URN BURNER, MODEL No. 707
(Uses 7-inch Burner Cap)

Name of Part	Net Retail Price
905—Gas Tip Cleaning Needle	.06
653—Valve Stem Complete	.30
318—Gas Tip (Marked "S")	.06
262—Generator (Gas Tip Marked "MB")	3.60
323—Burner Cap	2.16
326—Burner Base	2.25
329—Preheater Fuel Tube (12¾" Long)	.36
328—Generator Clamp	.03
289—Preheater Generator (Gas Tip Marked "S")	.42
375—Preheater Nipple & Screen	.18
377—Preheater Pan (With Flame Deflector)	.90
383—Preheater Complete (Less Preheater Fuel Tube)	1.80
657—Preheater Valve Complete	.75
301—Hexagon Brass Stove Bolt Nut (3/16") (12-24)	2 for .06
302—Stove Bolt (3/16"x¾" R. H.)	2 for .06
303—Stand Base	.18
304—Iron Pipe Nipple (⅜"x3")	.12
324—Stove Bolt (3/16"x¾" F. H.)	2 for .06

* For Parts list for No. 515-262 Generator, See Page No. 72.



URN BURNER, MODEL No. 4
(Uses 4-inch Burner Cap)

Name of Part	Net Retail Price
262—Generator (Gas Tip Marked "4B")	3.30
301—Hexagon Brass Stove Bolt Nut (3/16") (12-24)	2 for .06
302—Stove Bolt (3/16"x¾" R. H.)	2 for .06
303—Stand Base	.18
304—Iron Pipe Nipple (⅜"x3")	.12
310—Preheater Pan	.18
323—Burner Cap	1.20
324—Stove Bolt (3/16"x¾" F. H.)	2 for .06
326—Burner Base	1.20

URN BURNER, MODEL No. 5
(Uses 5-inch Burner Cap)

Parts No.	Name of Part	Net Retail Price
*506-262	Generator (Gas Tip Marked "AO")	3.30
545-301	Hexagon Brass Stove Bolt Nut (3/16") (12-24)	2 for .06
545-302	Stove Bolt (3/16"x¾" R. H.)	2 for .06
545-303	Stand Base	.18
545-304	Iron Pipe Nipple (⅜"x3")	.12
545-310	Preheater Pan	.18
545-324	Stove Bolt (3/16"x¾" F. H.)	2 for .06
546-323	Burner Cap	1.50
546-326	Burner Base	1.35

* For Parts List for Nos. 506-262 and 507-262 Generators, See Page No. 73.

Parts List for

Coleman Generator, Nos. 514-262, 514-263,

GENERATOR No. 514-262
(Used on Urn Burner, Model Nos. 55, 505, 555)



Parts No.	Name of Part
310-215	White Porcelain Wheel
318-218	Gas Tip (Marked "AO")
471-238	Cleaning Needle & Holder
501-203	Generator Clean-Out Plug
501-223	Filler Coil & Asbestos Cord
501-237	Generator Tee & Bushing
514-211	Generator Valve Clean-Out Plug
514-262	Generator (Gas Tip Marked "AO")

GENERATOR No. 514-263
(Used on Urn Burner, Model Nos. 44, 404, 444)



Parts No.	Name of Part	Net Retail Price
310-215	White Porcelain Wheel	.15
472-238	Cleaning Needle & Holder 2 for	.09
501-203	Generator Clean-Out Plug	.09
501-223	Filler Coil & Asbestos Cord	.15
501-237	Generator Tee & Bushing	.30
502-218	Gas Tip (Marked "4B")	.12
514-211	Generator Valve Clean-Out Plug	.06
514-263	Generator (Gas Tip Marked "4B")	3.30

GENERATOR No. 51
(Used on Urn Burner, Mode



Parts No.	Name of Part
307-238	Cleaning Needle & Holder
310-215	White Porcelain Wh
501-203	Generator Clean-Out
501-237	Generator Tee & Bus
503-223	Filler Coil & Asbestos
504-218	Gas Tip (Marked "M
514-211	Generator Valve Clea Plug
515-262	Generator (Gas Tip Marked "MB")

Coleman Generator, Nos. 501-262, 502-262, 506-262, 507-262

GENERATOR No. 506-262
(Old No. 5"SB)

sed on Urn Burner, Model No. 5



Name of Part	Net Retail Price
218—Gas Tip (Marked "AO")	.12
203—Generator Clean-Out Plug	.09
223—Filler Coil & Asbestos Cord	.15
201—Generator Connection	.15
225—Tip Cleaner Complete	.48
238—Cleaning Needle & Holder	.09
262—Generator (Gas Tip Marked "AO")	3.30
653—Generator Valve Stem Complete	.48
211—Generator Valve Clean-Out Plug	.06

GENERATOR No. 507-262
(Old No. 4"SB)

Used on Urn Burner, Model No. 4

Name of Part	Net Retail Price
203—Generator Clean-Out Plug	.09
223—Filler Coil & Asbestos Cord	.15
218—Gas Tip (Marked "4B")	.12
201—Generator Connection	.15
225—Tip Cleaner Complete	.48
238—Cleaning Needle & Holder	.09
653—Generator Valve Stem Complete	.48
262—Generator (Gas Tip Marked "4B")	3.30
211—Generator Valve Clean-Out Plug	.06

GENERATOR No. 501-262
(Old No. 5BB-62)

Used on Urn Burners, Model Nos. 55, 505, 555



Parts No.	Name of Part	Net Retail Price
318-218	Gas Tip (Marked "AO")	.12
501-203	Generator Clean-Out Plug	.09
501-223	Filler Coil & Asbestos Cord	.15
501-225	Tip Cleaner Complete	.48
501-237	Generator Tee & Bushing	.30
501-238	Cleaning Needle & Holder	.09
501-262	Generator (Gas Tip Marked "AO")	3.30
506-653	Generator Valve Stem Complete	.48
514-211	Generator Valve Clean-Out Plug	.06

GENERATOR No. 502-262
(Old No. 4BB-62)

Used on Urn Burner, Model Nos. 44, 404, 444

Parts No.	Name of Part	Net Retail Price
501-203	Generator Clean-Out Plug	.09
501-223	Filler Coil & Asbestos Cord	.15
501-225	Tip Cleaner Complete	.48
501-237	Generator Tee & Bushing	.15
501-238	Cleaning Needle & Holder	.09
502-218	Gas Tip (Marked "4B")	.12
502-262	Generator (Gas Tip Marked "4B")	3.30
506-653	Generator Valve Stem Complete	.48
514-211	Generator Valve Clean-Out Plug	.06

Parts List for

Coleman Outside Fuel Tank No. 652C an Pumps Nos. 625 (2SP) and 628



PUMP No. 628, TANK No. 652C



PUMP No. 625 (2S

Parts No.	Name of Part	
451 - 504	Pump Barrel Top Plug	
451 - 509	Pump Leather	
605 - 950	Wrench	
625 - 501	Pump Base	
625 - 504	Pump Barrel Top Plug	
625 - 509	Pump Leather	
625 - 513	Connection (Hose to Pump Base)	
625 - 523	Hose Clamp	2
625 - 528	Connection (Hose to Air Valve)	
625 - 552	Check Valve	
625 - 555	Pump Handle, Clamp & Bushing	
625 - 562	Pump Plunger Complete	
625 - 580	Hose, Connections & Clamps	
*628 - 501	Pump Base (5/8" Center Hole)	
*628A501	Pump Base (1" Center Hole)	
628 - 512	Pump Handle	
628 - 526	Hose Connection Body	
628 - 538	Check Valve	
628 - 570	Pump Plunger Complete	
628 - 580	Hose, Connection, Check Valve & Clamps	
650 - 125	Air Gauge	
650 - 131	Filler Plug Cap (Only)	
650 - 135	Filler Plug Disc, Gasket & Screw	
650 - 136	Filler Plug Gasket	2
650 - 140	Filler Plug Complete	
650 - 157	Air Valve Complete	
650 - 651	Valve Stem Complete	
650 - 657	Tank Fuel Valve Complete	

*When ordering Nos. 628-501 or 628A501 Pump Base, specify diameter of Cent

Coleman Hollow Wire Connections

Special Connections, Fittings and Accessories



Parts No.	Name of Part		Net Retail Price
599-117	Filler Plug Gasket (Special Filler Plug)	2 for	.09
599-130	Hollow Wire (Only) (No. 2)	Per foot	.09
599-140	Special Filler Plug Complete (With Hollow Wire Connection)		1.05
599-653	Valve Stem Complete		.30
599-657	Wall Valve Complete		.75
599-901	Hollow Wire Male Plug (Open)		.06
599-902	Hollow Wire Male Plug (Blind)		.06
599-907	Hollow Wire Splicing Sleeve		.03
599-908	Hollow Wire Nipple		.12
599-911	Hollow Wire Jamb (Blind)		.03
599-912	Hollow Wire Jamb		.03
599-913	Hollow Wire Jamb Nut		.12
599-914	Hollow Wire Ell		.18
599-915	Hollow Wire Corner Tee		.24
599-916	Hollow Wire Tee (With Drop)		.18
599-917	Hollow Wire Tee		.18
599-920	Hollow Wire Ell (With Nail Plate)		.24
599-921	Hollow Wire Tee (With Nail Plate)		.30
599-923	Hollow Wire Cross (With Drop)		.24
599-924	Hollow Wire Cross		.24
599-925	Reducing Nipple ((⅛" I. P. S. Thread Male to Hollow Wire)		.24
599-926	Reducing Coupling-Nipple (⅛" I. P. S. Thread Female to Hollow Wire)		.24
599-927	Reducing Nipple (¼" I. P. S. Thread Male to Hollow Wire)		.24
599-928	Reducing Coupling-Nipple (¼" I. P. S. Thread Female to Hollow Wire)		.24
599-930	Reducing Coupling-Nipple (¼" S. A. E. Female to Hollow Wire Jamb Nut)		.24

(Continued on Next Page)

Parts List for

Coleman Hollow Wire Connections,

Special Connections, Fittings and Accessories

Parts No.	Name of Part
599-931	Reducing Coupling-Nipple (¼" S. A. E. Female to $\frac{3}{16}$" S. A. E. Male)
599-932	Jamb Nut ($\frac{3}{16}$" S. A. E.)
599-933	Hollow Wire Nipple (With Jamb & Nut Drop)
599-934	Reducing Coupling-Nipple ($\frac{3}{16}$" S. A. E. Female to Hollow Wire Jamb
599-935	Reducing Nipple (¼" S. A. E. Male to Hollow Wire Jamb Nut)
599-936	Tee ($\frac{3}{16}$" S. A. E.)
599-937	Reducing Nipple-Coupling (¼" S. A. E. Male to $\frac{3}{16}$" S. A. E. Female)
599-940	Tee ($\frac{3}{16}$" S. A. E. Nickel Plated)
T23	Filler Plug Complete (Male)
	—Silver Solder P

*When No. 599-130 Hollow Wire (No. 2) is wanted with Jamb Nuts and Jam used price per foot, and add 12c for each Jamb Nut and Jamb brazed

Parts List for
COLEMAN SUCTION PUMP

Parts No.	Name of Part
451-504	Pump Barrel Top Plug
451-509	Pump Leather
627-580	Pump Plunger Complete
627-587	Suction Tube & Jamb Nu
627-590	Suction Pump

Parts List for
COLEMAN LIQUID SIPHON



630-509	Pump Leather ..... 2 for	.09
630-545	Siphon	1.00

Parts List for
COLEMAN (SCHUYLER PA FILTERING FUNNEL

No. 0 Filter Funnel	....
No. 1 Filter Funnel	....
Pad for No. Funnel	....
Pad for No. Funnel	..

COMPLETE PARTS LIST

wing Coleman Products on Which Each Part Can Be Used

Numerically Arranged by New Numbers

Here is given in numerical order, a complete list of all the parts for all Coleman cts shown in this catalog.

Then there is also shown the corresponding old parts number or numbers. It will ed that in some instances under the old parts numbering system, the same item will wo or more different parts numbers. This confusion has been eliminated by the use new parts numbers which should always be used when ordering.

In addition, there is indicated the particular product or products on which each used and is interchangeable. For instance—when we look up parts number 216-538, Valve, we find that this same part is used on three Lamps, four Lanterns, nine , two Camp Stoves, Utility Burner, Soldering Furnace, and five Heaters. This nu- l list of parts will be a ready aid in servicing and repairing Coleman Products. By ng with this list, it is easily determined on what products each particular part is used.

by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
36	A36 HV36 NA36	Filler Plug Gasket	Lamp A, AA Lantern HV316 — 2 for	.06
45	NA45	Fibre Lamp Handle	Lamp A, AA	.30
54	NA32 NA54A	Filler Plug Air Stem	Lamp A, AA Lantern HV316	.18
64	A64½ HV64½ NA64½	Filler Plug Complete	Lamp A, AA Lantern HV316	.75
18	NA18	Gas Tip	Lamp A, AA	.24
58	NA58	Asbestos Wick (Tied)	Lamp A, AA — 2 for	.15
59	NA59	Gas Tip Screen	Lamp A, AA — 2 for	.15
65	NA58-12	Generator Barrel & Asbestos Wick	Lamp A, AA	1.05
99	NA	Valve, Handle & Generator Complete	Lamp A, AA	2.25
10	NA10	Air Intake Coupling	Lamp A, AA	.30
22	NA22	Bunsen Tube	Lamp A, AA	.15
24	NA24 Q24	Burner Tube	Lamp A, AA, B, C, C331, P Lantern E20, L227, L327, L427 ('26), L427 ('27)	.15
63	NA63 Q63	Shade Holder	Lamp A, AA, B, C, C331, P	.30
70	NA70	Burner Complete	Lamp A, AA	3.00
22	HV NA Q Q33	Pump	Lamp A, AA, B, C, P, 117 Lantern HV316, L327 Furnace 456	.75
53	NA55-16 Q56B	Valve Stem Complete	Lamp A, AA, B, C, C331, P Heater 4	.30
57	NA57-16-55	Fuel Valve Complete	Lamp A, AA	.75
35	C35 NA35	Handle Metal Washer	Lamp A, AA, C — 2 for	.06

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
101 - 946	C46 NA46	Handle Fibre Washer	Lamp A, AA, C
101 - 950	NA	Wrench	Lamp A, AA Lantern HV316
102 - 117	B17	Screw & Foot	Lamp B
102 - 143	B43	Stove Bolt ($\frac{3}{16}$"x½" R. H.)	Lamp B Camp Stove 10 Water Heater 1
102 - 165	B B65	Fount Complete	Lamp B
102 - 446	B42	Hanger Ring & Nuts	Lamp B
104 - 105	C5	Finishing Shell	Lamp C
104 - 132	A3046 A0246 Q32 R4046	Filler Plug Air Stem	Lamp B, C, P Lantern E20, L327 Stove 210, 211, 212, 21 324, 325, 327, 330, 62 622, 623 Camp Stove 10
104 - 136	CS36 Q36	Filler Plug Gasket	Lamp B, C, P Lantern L327 Camp Stove 2C, 2D 9D, 10
104 - 145	C45	Fibre Lamp Handle	Lamp C
104 - 147	C47	Lock Nut	Lamp C
104 - 164	Q64B	Filler Plug Complete	Lamp B, C, P Lantern L327
104 - 165	C65	Fount Complete	Lamp C
104 - 210	Q10	Jamb Nut	Lamp 117, 118, 119 Lantern 220, 228 Stove 322, 323, 324, 32 327, 328, 329, 330 Iron 3, 4
104 - 218	Q18	Gas Tip (Marked "Q")	Lamp B, C, C331, P Lantern E20, L227, L427 ('26), L427 ('27)
104 - 299	Q99	Coil Generator (Gas Tip Marked "Q")	Lamp B, C, C331, P Lantern E20, L227, L427 ('26), L427 ('27)
104 - 317	Q17	Burner Support Coupling	Lamp B, C, C331, P Lantern E20, L227, L427 ('26), L427 ('27)
104 - 322	Q11	Air Intake Tube	Lamp B, C, C331, P Lantern E20, L227, L427 ('26), L427 ('27)
104 - 326	LQ26 NA26 Q26	Mixing Chamber	Lamp A, AA, B, C, C3 Lantern E20, L227, L427 ('26), L427 ('27)

Complete Parts List

Numerically Arranged by New Numbers

r by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
341	NA41 Q41	Shade Holder Screw	Lamp A, AA, B, C, C331, P	.06
399	Q70	Burner, Generator & Valve Complete Assembled	Lamp B, C, C331, P	3.00
469	C69 NA Q69	Hanger	Lamp A, AA, C, C331, 117, 118, 119	.09
657	Q57	Fuel Valve Complete	Lamp B, C, C331, P	.75
905	HV NA Q .007	Gas Tip Cleaning Needle	Lamp A, AA, B, C, C331, P, 117, 118, 119 Lantern E20, HV316, L227, L327, L427, ('26), L427, ('27), 220, 228 Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 322, 323, 324, 325, 326, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625 H. G. P. 5052 Water Heater 1 Heater 4, 5, 5A, 7 Urn Burner 404, 505, 707	.06
950	Q QW	Wrench	Lamp B, C, P Lantern L327	.15
23	HV423-25 NA23-25 Q23 Q23-25 2523	Burner Cap & Screens	Lamp A, AA, B, C, C331, P, 25, 117, 118, 119 Lantern E20, HV316, L227, L327, L427 ('26), L427 ('27), 220, 228	.15
25	HV25 HV425 NA25 Q25	Burner Cap Screen	Lamp A, AA, B, C, C331, P, 117, 118, 119 Lantern E20, HV316, L227, L327, L427 ('26), L427 ('27), 220, 228 — 2 for	.06
19	2547 2747	Canopy & Screw	Lamp 25, 27	.45
37	J37 P37	Hanger (17" Long)	Lamp P	.36
38	2535 2735	Pipe Hanger (5" Long)	Lamp 25, 27	.12
40	J40 P45	Hanger Casing (16¼" Long)	Lamp P	.36
43	2543 2743	Ceiling Plate	Lamp 25, 27	.36
44	2540 2740	Casing (4½" Long)	Lamp 25, 27	.18
45	P65	Fount Complete	Lamp P	7.50
43	P43	Hanger Ring	Lamp P	.30
49	P49	Fuel Wire	Lamp P	.15

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
113 - 450	P42½ & P47	Ornamental Shell Complete	Lamp P
113 - 475	P74	Arms & Fuel Wire	Lamp P
115 - 136	L436 PL436 SS36	Filler Plug Gasket	Lamp C331, 117, 118, 1 Lantern E20, L227, ('26), L427 ('27), 220, Burner 454 Furnace 456 Heater 480
115 - 138	.....	Filler Plug Core & Gasket	Lamp 117 Furnace 456
115 - 164	SS64	Filler Plug Complete	Lantern E20 (Separate Pump)
117 - 132	.....	Filler Plug Air Stem	Lamp 117
117 - 144	.....	Tip Protector & Screen	Lamp 117, 118, 119 Lantern 220, 228 Stove 322, 323, 324, 325 327, 328, 329, 330 Burner 454, Furnace 456 Heater 5, 5A, 7
117 - 145	.....	Lamp Handle	Lamp 117
117 - 147	.....	Handle Lock Nut	Lamp 117
117 - 148	.....	Fuel Wire Complete (Fuel Tip Marked "P")	Lamp 117, 118, 119
117 - 160	.....	Fuel Tube	Lamp 117, 118, 119
117 - 164	.....	Filler Plug Complete	Lamp 117
117 - 165	.....	Fount Complete	Lamp 117
117 - 341	.....	Shade Holder Screw	Lamp 117, 118, 119
117 - 342	.....	Shade Holder	Lamp 117, 118, 119
117 - 361	.....	Air Intake & Bracket	Lamp 117, 118, 119
118 - 140	.....	Filler Plug Complete	Lamp 118 ,119
118 - 145	.....	Lamp Handle	Lamp 118, 119
118 - 147	.....	Handle Lock Nut	Lamp 118, 119
118 - 165	.....	Fount Complete	Lamp 118, 119
118 - 399	.....	Burner, Generator & Valve Assembled	Lamp 117, 118, 119
118 - 520	.....	Pump Plunger Complete (Less Air Stem)	Lamp 118, 119
118 - 653	T656	Valve Stem Complete	Lamp 117, 118, 119 Lantern 220, 228
118 - 657	T657	Valve & Generator Complete	Lamp 117, 118, 119 Lantern 220, 228
118B324	.....	Burner Tube	Lamp 117, 118, 119 Lantern 220, 228

er by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
- 145	.....	Lamp Handle	Lamp C331 Heater 480	.36
- 147	.....	Handle Lock Nut.....	Lamp C331 Heater 480	.15
- 160	.....	Fuel Wire With Fuel Tube.....	Lamp C331 Heater 480	.45
- 165	.....	Fount Complete	Lamp C331 Heater 480	7.50
- 208	2508	Asbestos Wick (Tied).....	Lamp 25	.15
- 218	2518	Gas Tip (Marked "25").....	Lamp 25	.15
- 299	2599	Generator (6¼" Long) (Gas Tip Marked "25").....	Lamp 25	.45
- 324	2524	Burner Tube	Lamp 25	.24
- 401	2501 2701	Connecting Ring	Lamp 25, 27.....	.30
- 617	2517	Lock Nut	Stove 322, 323, 324, 325, 326, 327, 328, 329, 330.....	.03
- 651	2555 2755	Valve Stem Complete.....	Lamp 25, 27.....	.30
- 660	2557R 2757R	Fuel Valve Complete (With Lever)	Lamp 25, 27.....	.90
- 903	NA	Alcohol Torch	Lamp A, AA, 1, 11, 25, 27 Lantern HV316	.15
- 904	2504 2704	Heat Baffle	Lamp 25, 27.....	.36
- 953	2553	Chain & Ring (6" Long).....	Lamp 25	.12
- 208	2708	Asbestos Wick (Tied).....	Lamp 27	.15
- 218	2718	Gas Tip (Marked "27").....	Lamp 27	.15
- 299	2799	Generator (7⅜" Long) (Gas Tip Marked "27").....	Lamp 27	.48
- 323	2723R	Burner Cap & Screens.....	Lamp 27	.18
- 324	2724	Burner Tube	Lamp 27	.24
- 326	2726	Mixing Chamber	Lamp 27	.60
- 953	2753	Chain & Ring (18" Long).....	Lamp 27	.18
- 218	.....	Gas Tip (Marked "J").....	Lamp 117, 118, 119 Lantern 220, 228 Heater 480	.06
- 299	R55	Rotary Generator (Gas Tip Marked "J")	Heater 480	.50
- 299	Q77	Straight Generator (Gas Tip Marked "J")	Lamp 117, 118, 119 Lantern 220, 228.....	.20
- 165	LQ65	Fount Complete	Lantern L327	4.50
- 340	LQ40	Ventilator Rod	Lantern E20, L227, L327, L427 ('26), L427 ('27).....	.06

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
203 - 370	.....	Burner (Less Generator & Valve)	Lantern E20 .....
203 - 399	LQ70	Burner, Generator & Valve Complete Assembled	Lantern L327, L427
203 - 409	LQ19	Burner Frame Washer.....	Lantern E20, L22 L427 ('26), L427 ('2 .....
203 - 420	LQ20	Baffle Plate	Lantern E20, L22 L427 ('26), L427 (
203 - 441	LQ41	Ventilator Ball Nut.....	Lantern E20, L22 ('26), L427 ('27), 22
203 - 489	LQ89	Globe Base Rest	Lantern L227, L32 ('26), L427 ('27).....
203 - 498	LQ98	Frame & Bail.....	Lantern E20, L32 ('26), L427 ('27).....
203 - 653	HV55-16 LQ55 LQ55-16	Valve Stem Complete	Lantern E20, HV31 L327, L427 ('26), L
203 - 657	LQ57	Fuel Valve Complete.....	Lantern L327, L427
204 - 139	L433 PL433	Filler Plug Disc, Gasket & Screw	Lamp C331, 118, 11 Lantern E20, L22 ('26), L427 ('27), 22 Heater 480 .....
204 - 140	L464B PL464	Filler Plug Complete.....	Lamp C331 Lantern E20, L22 ('26), L427 ('27), 22 Heater 480 .....
204 - 165	L465	Fount Complete	Lantern L427 ('26) lete. Supply Nos. and 216-165 .....
204 - 399	.....	Burner, Generator & Valve Complete Assembled	Lantern L227, L427
204 - 485	LQ85 LQ85V	Ventilator (Porcelain, 5¼" Base)	Lantern E20, L32 ('26), L427 ('27), 22
204 - 520	L401	Pump Plunger Complete (Less Air Stem)	Lantern L427 ('26)
204 - 524	L400	Pump Barrel Complete.....	Lantern L427 ('26)
204 - 530	L404	Pump Complete	Lantern L427 ('26)
204 - 657	....	Fuel Valve Complete.....	Lantern L227, L427
208 - 165	HV65	Fount Complete	Lantern HV316 .....
208 - 208	HV58	Asbestos Wick (Tied)....	Lantern HV316 .....
208 - 218	HV18	Gas Tip (Marked "G").....	Lantern HV316 .....
208 - 259	HV59	Gas Tip Screen.....	Lantern HV316 ...
208 - 299	HV99	Generator (4½" Long) (Gas Tip Marked "G").....	Lantern HV316 .....

Complete Parts List

Numerically Arranged by New Numbers

r by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
324	HV24	Burner Tube	Lantern HV316	.15
326	HV26 2526	Mixing Chamber	Lamp 25 Lantern HV316	.45
338	HV28B	Chimney	Lantern HV316	.90
370	HV	Burner, Generator, Valve & Chimney Complete Assembled	Lantern HV316	3.45
441	HV41	Hanger Ring	Lantern HV316	.09
473	HV73	Bail & Handle	Lantern HV316	.30
482	HV82	Globe Spring	Lantern HV316	.06
486	HV85	Ventilator Dome (Less Handle)	Lantern HV316	4.80
489	HV89	Globe Base Rest	Lantern HV316	.24
493	HV93	Globe Base & Door	Lantern HV316	.90
613	HV13	Connection (Valve to Generator)	Lantern HV316	.30
657	HV55-16-57	Fuel Valve Complete	Lantern HV316	.90
189	PL65	Fount Complete (With Valve)	Lantern E20. Obsolete Supply No. 213-189	.....
489	PL89	Globe Base Rest	Lantern E20	.15
657	PL57	Fuel Valve Complete	Lantern E20	.90
189	PL465	Fount Complete (With Valve)	Lantern E20	7.50
520	PL401	Pump Plunger Complete (Less Air Stem)	Lantern E20	.60
530	PL404	Pump Complete	Lantern E20	2.10
532	PL402	Air. Stem	Lantern E20	.24
165	.....	Fount Complete	Lantern L227, L427 ('27)	5.70
319	.....	Base Lock Nut	Lantern 220, 228 2 for	.09
326	.....	Mixing Chamber	Lamp 117, 118, 119 Lantern 220, 228	.90
327	.....	Valve Set Screw	Lamp 117, 118, 119 Lantern 220, 228	.03
328	.....	Valve Bracket Wedge	Lamp 117, 118, 119 Lantern 220, 228	.03
340	.....	Ventilator Rod	Lantern 220, 228	.06
361	.....	Air Intake & Bracket	Lantern 220, 228	.90
329	.....	Globe Base Rest	Lantern 220, 228	.18
309	HV NA Q	Pump Leather	Lamp A, AA, B, C, C331, P, 117, 118, 119 Lantern HV316, L227, L327, L427 ('27), 220, 228 Camp Stove 2D, 9D, 10 Burner 454 Furnace 456 Heater 480 Iron 3, 4, 5 2 for	.09

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
216 - 520	2D17	Pump Plunger Complete (Less Air Stem)	Lamp C331 Lantern L227, L427 220, 228 Camp Stove 2D, 9D Heater 480
216 - 532	L402 2CS32 9CS32	Air Stem	Lamp C331, 118, 119 Lantern L227, L427 L427 ('27), 220, 228 Camp Stove 2C, 2D, 9C Burner 454 Furnace 456 Heater 480
216 - 538	.....	Check Valve	Lamp C331, 118, 119 Lantern L227, L427 220, 228 Stove 322, 323, 324, 325, 327, 328, 329, 330 Camp Stove 2D, 9D Burner 454 Furnace 456 Heater 4, 5, 5A, 7, 480
216 - 654	.....	Valve Body	Lamp 117, 118, 119 Lantern 220, 228
217 - 118	.....	Fuel Tip (Marked "P")	Lamp 117, 118, 119 Lantern 220, 228
217 - 144	.....	Tip Protector & Screen	Lamp 117, 118, 119 Lantern 220, 228
217 - 148	.....	Fuel Wire Complete (Fuel Tip Marked "P")	Lantern 220, 228
217 - 160	.....	Fuel Nipple	Lantern 220, 228
217 - 165	.....	Fount Complete	Lantern 220, 228
217 - 498	.....	Frame & Bail	Lantern 220
220 - 399	.....	Burner, Generator & Valve Complete Assembled	Lantern 220, 228
227 - 480	.....	Ventilator (Porcelain, 8¾" Base)	Lantern L227, 228
227 - 498	.....	Frame & Bail	Lantern L227
228 - 498	.....	Frame & Bail	Lantern 228
305 - 443	.....	Stove Bolt ($\frac{3}{16}$"x⅜" O. H.)	Camp Stove 10
305 - 444	A0044 D3644 D4644 HS44	Grate (Open Type)	Stove 120, 121, 200, 201, 203, 204, 210, 211, 212, 214, 224, 225, 323, 324, 326, 327, 328, 329, 330, 601, 602, 620, 621, 624,
305 - 653	HB56B HST56 HST56B	Valve Stem Complete	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 7
307 - 171	AG271	Fuel Tube (5¾" Long)	Stove 200, 201, 202, 203

er by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
- 189	AG2	Tank Complete (With Fittings) (Black)	Stove 200, 201, 202, 203, 204, 600, 601, 602	7.50
- 218	A2018 AG218	Gas Tip (Marked "A3")	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 323, 324, 325, 326, 327, 328, 330	.12
- 233	AG18-15	Generator Saddle, Clamp, Bolt & Nut ($\frac{13}{16}$" High)	Stove 200, 201, 202, 203, 204, 600, 601, 602	.12
- 238	A2009 AG209	Cleaning Needle & Holder	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 323, 324, 325, 326, 327, 328, 330 Urn Burner 707 2 for	.09
- 262	AG262	Main Generator (Gas Tip Marked "A3")	Stove 200, 201, 202, 203, 204	2.40
- 325	AGX15	Auxiliary Valve Opener Knob	Stove 200, 201, 202, 203, 204, 600, 601, 602	.09
- 326	AG226	Burner Manifold (Casting Only)	Stove 200, 201, 202, 203, 204	2.55
- 345	AG45	Drain Plug Complete	Stove 200, 201, 202, 203, 204, 600, 601, 602	.45
- 350	AG28Z AGX28 AGX28Z	Auxiliary Burner Valve Core	Stove 200, 201, 202, 203, 204, 600, 601, 602	.24
- 355	AG255 AGX255 AG655F AGX655F	Auxiliary Burner Valve Opener (Less Knob)	Stove 200, 201, 202, 203, 204, 600, 601, 602	.30
- 409	AG253	Drip Pan (Porcelain)	Stove 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 324, 325, 328	2.40
- 423	AG202	High Leg	Stove 201, 202, 203, 204, 601, 602	.60
- 440	AG202	Splasher	Stove 202, 204	2.40
- 441	AG202	High Shelf	Stove 202, 204	1.50
- 442	AG202	High Shelf Support (Right)	Stove 202, 204, 602	.75
- 443	AG202	High Shelf Support (Left)	Stove 202, 204, 602	.75
- 444	AG202	High Shelf Trim (Right)	Stove 202, 204, 602	.90
- 445	AG202	High Shelf Trim (Left)	Stove 202, 204, 602	.90
- 459	A2027 AG227	Burner Manifold Bracket (2 Piece)	Stove 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 324, 325, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625	.12
- 657	AGT29	Tank Fuel Valve Complete	Stove 200, 201, 202, 203, 204, 600, 601, 602	.75

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
307 - 901	H101 TB	Alcohol Bottle (Only)	Stove 200, 201, 202, 203, 600, 601, 602 Heater 1, 2
307 - 930	A0011 2H11	Carbon Scraper	Stove 120, 121, 200, 201, 203, 204, 210, 211, 212, 214, 224, 225, 322, 323, 325, 326, 327, 328, 329, 600, 601, 602, 620, 621, 623, 624, 625
308 - 171	AG671	Fuel Tube (14¼" Long)	Stove 600, 601, 602
308 - 218	A6018 AG618 D0018 D3018 R4018 4AG618	Gas Tip (Marked "A4")	Stove 322, 329, 600, 601, 620, 621, 624, 625
308 - 238	A6009 AG609	Cleaning Needle & Holder	Stove 322, 329, 600, 601, 620, 621, 622, 623, 624, 2
308 - 262	AG662	Main Generator (Gas Tip Marked "A4")	Stove 600, 601, 602
308 - 322	AG626½	Mixing Chamber	Stove 600, 601, 602
308 - 326	AG626	Burner Manifold (Casting Only)	Stove 600, 601, 602
308 - 355	AG655B AGX655B	Auxiliary Burner Valve Opener (Less Knob)	Stove 600, 601, 602
308 - 407	AG600	Stove Top (Less Name Plate)	Stove 600, 601, 602
308 - 409	AG654	Drip Pan (Porcelain)	Stove 600, 601, 602
308 - 411	.....	Burner Bracket	Stove 600, 601, 602
308 - 440	AG602	Splasher	Stove 602
308 - 441	AG602	High Shelf	Stove 602
310 - 115	A0105 D0505	Fuel Gauge	Stove 120, 121, 210, 211, 2 213, 214, 224, 225, 620, 6 622, 623, 624, 625
310 - 171	A009 A0019 A0219	Fuel Tube (6½" Long)	Stove 120, 121, 210, 211, 2 213, 214, 224, 225, 323, 3 325, 326, 327, 329, 330, 6 621, 622, 623, 624, 625
310 - 189	A0102 D0502	Tank Complete (With Fittings) (Gray)	Stove 210, 211, 212, 213, 2 224, 225, 620, 621, 622, 6 624, 625
310 - 215	A0015	White Porcelain Wheel	Stove 322 ('28) H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 707
310 - 233	A0022	Generator Saddle, Clamp, Bolt & Nut (13/16" High)	Stove 120, 121, 210, 211, 21 213, 214, 224, 225, 323, 32 325, 326, 327, 328, 329, 33 620, 621, 622, 623, 624, 6

Complete Parts List

Numerically Arranged by New Numbers

by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
305	A0116	Preheater Support Rod	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	.12
307	A0114	Preheater Valve Body (Only)	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	.60
310	A0112 D0112	Preheater Pan	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	.36
326	A2026	Burner Manifold (Casting Only)	Stove 210, 211, 212, 213, 214, 324, 325, 327, 330	2.70
345	A0045 A3045 R4045	Drain Plug Complete	Stove 210, 211, 212, 213, 214, 324, 325, 327, 330, 620, 621, 622, 623	.24
353	A0113 D0113	Preheater Valve Stem Complete	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	.30
357	A0115 D0115	Preheater Valve Complete	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	1.20
360	A0111	Auxiliary Valve Core Complete	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 323, 324, 325, 326, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625	.30
366	.....	Auxiliary Burner Valve Stem Complete (With Disc & Handle	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 323, 324, 325, 326, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625	.75
371	A0121 A0221	Preheater Fuel Tube (19½" Long	Stove 120, 121, 210, 211, 212, 213, 214, 620, 621, 622, 623	.36
378	A0120 D0120 R4120	Preheater Complete (Less Fuel Tube)	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	1.80
379	A0119 D0119 R0119	Preheater Generator (Gas Tip Marked "N")	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625	.36
	A0027 D0527	Tank Bracket (Gray)	Stove 210, 211, 212, 213, 214, 224, 225, 322 ('28), 324, 325, 328, 329, 620, 621, 622, 623, 624, 625	.15
	A0008	Leg (Low Stove)	Stove 210	.24
	A0007	High Leg	Stove 211, 212, 213, 214, 224, 225, 324, 325, 329, 620, 621, 622, 623, 624, 625	.60
	A2005	Splasher	Stove 212, 214	2.40
	A2004	High Shelf	Stove 212, 214	1.50
	A0002R	High Shelf Support (Right)	Stove 212, 214, 621, 623	.75

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Product on Which Used
310 - 443	A0002L	High Shelf Support (Left)	Stove 212, 214, 621, 62
310 - 444	A0003R	High Shelf Trim (Right)	Stove 212, 214, 621, 62
310 - 445	A0003L	High Shelf Trim (Left)	Stove 212, 214, 621, 62
310 - 473	.....	Cabinet Door Complete	Stove 213, 214, 325, 329 623
310 - 657	A0029 D0529	Tank Fuel Valve Complete	Stove 120, 121, 210, 211 213, 214, 224, 225, 620 622, 623, 624, 625
312 - 322	A6671	Burner Manifold Extension (Casting Only)	Stove 329, 620, 621, 622 624, 625
312 - 326	A6072	Burner Manifold (Casting Only)	Stove 120, 121, 323, 326 620, 621, 622, 623
312 - 332	.....	Manifold Gasket	Stove 224, 225, 322, 329 621, 622, 623, 624, 625
312 - 409	A6054	Drip Pan (Porcelain)	Stove 329, 620, 621, 622 624, 625
312 - 440	A6005	Splasher	Stove 621, 623
312 - 441	A6004	High Shelf	Stove 621, 623
313 - 189	.....	Tank Complete (With Fittings) (Black)	Stove 120, 121
313 - 313	.....	Manifold End Plate	Stove 120, 121, 323, 32
313 - 332	.....	Manifold Gasket	Stove 120, 121, 323, 32
313 - 407	.....	Stove Top (Less Name Plate)	Stove 120, 121
313 - 410	A0027 AGT27	Tank Bracket (Black)	Stove 120, 121, 200, 201 203, 204, 323, 326, 327, 600, 601, 602
313 - 411	.....	Burner Manifold Bracket	Stove 120, 121
313 - 418	.....	Leg (Low Stove)	Stove 120, 121, 323, 326
313 - 483	.....	Galley Rail	Stove 121
314 - 440	A2605 D3605	Splasher (Porcelain)	Stove 225, 328
314 - 441	A2604 D3604	High Shelf	Stove 225
314 - 442	A0602 D3602	High Shelf Support (Right)	Stove 225, 625
314 - 443	A0602 D3602	High Shelf Support (Left)	Stove 225, 625
314 - 444	A0603R D3603 D4603	High Shelf Trim (Right)	Stove 225, 625
314 - 445	A0603L D3603 D4603	High Shelf Trim (Left)	Stove 225, 625

Numerically Arranged by New Numbers

py o.	Old No.	Name of Part	Products on Which Used	Net Retail Price
40	A6605 D4605	Splasher (Porcelain)	Stove 625	7.80
41	A6604 D4604	High Shelf	Stove 625	2.10
75	A0222 R4521	Fuel Tube (11" Long)	Stove 224, 225, 624, 625	.36
45	A6675 R4310	Iron Pipe Nipple (½"x5¾")	Stove 224, 225, 328, 624, 625	.18
73	A0220	Fuel Tube (8" Long)	Stove 224, 225, 624, 625	.30
18	A2318 A23-18 A6318 AO BB18-5 R4318 RH18 5BB18 5SB18	Gas Tip (Marked "AO")	Stove 224, 225, 322, 328, 624, 625 H. G. P. 5052 Water Heater 1 Heater 1 Urn Burner 505	.12
3	.....	Generator Saddle, Clamp, Bolt & Nut (7/32" High)	Stove 224, 225, 322, 328, 624, 625	.12
6	A6672	Burner Manifold (Casting Only)	Stove 224, 225, 624, 625	3.60
0	A6673	Mixing Chamber	Stove 224, 225, 328, 624, 625	1.50
2	.....	Master Sub-flame Burner Nipple	Stove 224, 225, 328, 624, 625	.30
3	A6676	Flange Coupling	Stove 224, 225, 328, 624, 625	.12
4	.....	Flange Packing	Stove 224, 225, 328, 624, 625	.06
5	A6674	Oven Burner Drop Supply Pipe (½" I. P. S. Threads)	Stove 624, 625	.60
5	A6678	Iron Pipe Ell (90°—½" I. P. S. Threads)	Stove 224, 225, 328, 624, 625	.36
3	.....	Master Sub-flame Burner & Drain Plug	Stove 224, 225, 328, 624, 625	1.05
9	A6623	Auxiliary Sub-flame Burner & Nipple	Stove 224, 225, 328, 624, 625	.45
5	A0224	Oven Burner Pilot Lighter	Stove 224, 225, 328, 624, 625	.90
	.....	Stove Top (Less Name Plate)	Stove 329, 620, 621, 622, 623, 624, 625	3.30
2	.....	Cabinet Door Knob	Stove 324, 325, 624, 625	.09
	.....	Oven Door Frame	Stove 224, 225, 624, 625	5.40
5	.....	Oven Back Lining	Stove 224, 225, 624, 625	.75
	.....	Oven Door Handle	Stove 224, 225, 624, 625	.36
	.....	Oven Door Catch (Steel)	Stove 224, 225, 624, 625	2 for .09
	.....	Oven Top Lining	Stove 224, 225, 624, 625	.75

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
318 - 449	.....	Oven Rack	Stove 224, 225, 624, 62
318 - 457	.....	Oven Door Front Panel	Stove 224, 225, 624, 62
318 - 458	.....	Oven Door Hinge (Right)	Stove 224, 225, 624, 62
318 - 459	.....	Oven Door Hinge (Left)	Stove 224, 225, 624, 62
318 - 460	.....	Oven Thermometer	Stove 224, 225, 624, 62
318 - 467	.....	Oven Bottom Complete (With Liner & Baffle)	Stove 224, 225, 624, 62
318 - 472	.....	Oven Door Complete	Stove 224, 225, 624, 62
318 - 473	318-427	Cabinet Door Complete	Stove 624, 625
318 - 476	.....	Oven Side Lining	Stove 224, 225, 624, 62
321 - 322	A2271	Burner Manifold Extension (Casting Only)	Stove 224, 225. Obsole Supply No. 328-326
321 - 345	A2674	Oven Burner Drop Supply Pipe (½" I. P. S. Threads)	Stove 224, 225, 328
321 - 407	A2001 310-407	Stove Top (Less Name Plate)	Stove 200, 201, 202, 203 210, 211, 212, 213, 214, 225, 324, 325, 327, 328
322 - 174	.....	Fuel Tube (7½" Long)	Stove 322
322 - 175	.....	Fuel Tube (26½" Long)	Stove 322
322 - 304	.....	Preheater Flame Spreader	Stove 322
322 - 310	.....	Preheater Pan	Stove 322
322 - 321	.....	Master Burner Cap Stop	Stove 322
322 - 322	.....	Mixing Chamber	Stove 322 ('28)
322 - 323	.....	Master Burner Cap	Stove 322
322 - 326	.....	Burner Manifold (Casting Only)	Stove 322 ('28)
322 - 327	.....	Main Burner Bracket	Stove 322
322 - 335	.....	Auxiliary Burner Extension	Stove 322 ('28)
322 - 337	.....	Oven Burner Side Bracket	Stove 322 ('28)
322 - 339	.....	Master Burner Extension	Stove 322 ('28)
322 - 340	.....	Mixing Chamber	Stove 322 ('28)
322 - 342	.....	Sub-flame Nipple (¼"x8" Long)	Stove 322
322 - 343	.....	Oven Burner Front Bracket	Stove 322 ('28)
322 - 344	.....	Oven Burner Rear Bracket	Stove 322 ('28)
322 - 345	.....	Oven Burner Supply Pipe (½"x9¼" Long)	Stove 322 ('28)
322 - 349	.....	Oven Burner Pilot Lighter	Stove 322 ('28)
322 - 368	.....	Sub-flame Burner & Drain Plug	Stove 322 ('28)
322 - 369	.....	Oven Burner	Stove 322 ('28)

...y ...o.	Old No.	Name of Part	Products on Which Used	Net Retail Price
76	.....	Preheater Bracket	Stove 322 ('28)	.60
77	.....	Auxiliary Burner Valve Stem Complete	Stove 322	.90
80	.....	Oven Burner Assembly.....	Stove 322 ('28).....	6.75
83	.....	Preheater Complete (Less Preheater Fuel Tube).....	Stove 322 ('28) Obsolete Supply No. 366-383.....	.....
99	.....	Main Burner Assembly.....	Stove 322 ('28)	16.50
06	.....	End Rail	Stove 322	.45
14	.....	Valve Panel	Stove 322	.60
56	.....	Lock Nut	Stove 322 ('28).....	.06
45	.....	Oven Burner Supply Pipe (½"x8¾" Long)	Stove 322 ('29).....	.36
80	.....	Oven Burner Assembly.....	Stove 322 ('29).....	6.75
99	.....	Main Burner Assembly.....	Stove 322 ('29).....	16.50
15	.....	Combination Fuel & Air Gauge	Stove 322, 323, 324, 325, 326, 327, 328, 329, 330	1.80
91	.....	Tank Complete (With Fittings) (Gray)	Stove 322, 324, 325, 328, 329	9.90
62	310-262	Main Generator (Gas Tip Marked "A3")	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 323, 324, 325, 326, 327, 328, 330.....	2.40
03	.....	Connection (Preheater Fuel Tube to Preheater Generator).....	Stove 322 ('28), 323, 324, 325, 326, 327, 328, 329, 330....	.15
10	.....	Preheater Pan	Stove 323, 324, 325, 326, 327, 328, 329, 330.....	.30
19	.....	Preheater Bracket	Stove 323, 324, 325, 326, 327, 328, 329, 330.....	.12
23	A0023 AG23	Burner Cap	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 322, 323, 324, 325, 326, 327, 328, 329, 330, 600, 601, 602, 620, 621, 622, 623, 624, 625.....	1.20
26	.....	Burner Manifold (Casting Only)	Stove 324, 325, 327, 330.....	2.70
53	.....	Preheater Tank Valve Stem Complete	Stove 322, 323, 324, 325, 326, 327, 328, 329, 330 Heater 5	.30
57	.....	Preheater Tank Valve Complete (Fuel Tip Marked "F").....	Stove 322, 323, 324, 325, 326, 327, 328, 329, 330.....	.90
83	.....	Preheater Complete (Less Preheater Fuel Tube).....	Stove 323, 324, 325, 326, 327, 328, 329, 330.....	.75

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
324 - 389	.....	Preheater Generator (Less Jamb Nut) (Gas Tip Marked "S")	Stove 322, 323, 324, 32 327, 328, 329, 330
324 - 440	.....	Splasher	Stove 324, 325, 330
324 - 441	.....	High Shelf	Stove 324, 325
324 - 442	.....	High Shelf Support (Right)	Stove 324, 325, 329
324 - 443	.....	High Shelf Support (Left)	Stove 324, 325, 329
324 - 444	.....	High Shelf Trim (Right)	Stove 324, 325, 329, 3
324 - 445	.....	High Shelf Trim (Left)	Stove 324, 325, 329, 3
324 - 454	.....	Grate (No Burn Type)	Stove 120, 121, 210, 21 213, 214, 224, 225, 323 325, 326, 327, 328, 329 620, 621, 622, 623, 624
324 - 648	.....	Indicator Handle & Screw (Right Hand Tank)	Stove 322, 323, 324, 325 327, 328, 329, 330
324 - 649	.....	Indicator Handle & Screw (Left Hand Tank)	Stove 322
324 - 653	.....	Tank Fuel Valve Stem Complete	Stove 322, 323, 324, 325 327, 328, 329, 330
324 - 657	.....	Tank Fuel Valve Complete	Stove 322, 323, 324, 325 327, 328, 329, 330
326 - 191	.....	Tank Complete (With Fittings) (Black)	Stove 326, 327, 330
326 - 407	.....	Stove Top (Less Name Plate)	Stove 323, 326
326 - 411	.....	Burner Manifold Bracket	Stove 323, 326
327 - 409	.....	Drip Pan (Porcelain)	Stove 327, 330
328 - 172	.....	Preheater Fuel Tube (12" Long)	Stove 323, 324, 325, 327 329, 330
328 - 173	.....	Fuel Tube (17" Long) (Tee to Oven Generator)	Stove 328
328 - 175	.....	Fuel Tube (2½" Long) (Tank to Tee or Tee to Main Generator)	Stove 328
328 - 263	318-263	Oven Generator (Gas Tip Marked "AO")	Stove 224, 225, 322, 328, 625
328 - 326	.....	Burner Manifold (Casting Only)	Stove 224, 225, 328
328 - 327	.....	Hood For Oven Burner Pilot Lighter	Stove 224, 225, 328, 624,
328 - 380	A0270 318-348	Oven Burner Complete (With Drain Plug, Pilot Lighter, Hood. Bolt & Nuts)	Stove 224, 225, 328, 624,
328 - 417	.....	Oven Door Catch (Casting)	Stove 328
328 - 423	.....	High Leg	Stove 328
328 - 425	.....	Oven Back Lining	Stove 328
328 - 431	.....	Oven Door Handle	Stove 328

Complete Parts List

Numerically Arranged by New Numbers

...y No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
2	.....	Oven Door Spring	Stove 328	.09
4	.....	Oven Door Catch (Steel)	Stove 328	.15
5	.....	Oven Door Spring Bar	Stove 328	.15
6	.....	Oven Top Lining	Stove 328	.90
9	.....	Oven Rack	Stove 328	.60
5	.....	Floor Baffle	Stove 328	.60
6	.....	Oven Door Lining	Stove 328	1.50
7	.....	Oven Door Front	Stove 328	4.20
8	.....	Oven Door Hinge (Right)	Stove 328	.36
9	.....	Oven Door Hinge (Left)	Stove 328	.36
	.....	Oven Thermometer	Stove 322, 328	1.35
	.....	Oven Door Hinge Bar (Right)	Stove 328	.45
	.....	Oven Door Hinge Bar (Left)	Stove 328	.45
	.....	Oven Door Spring Hook	Stove 328	.06
	.....	Oven Drip Pan	Stove 328	.45
	.....	Oven Floor Baffle Complete (Baffle, Drip Pan & Mirror)	Stove 328	1.35
	.....	Oven Bottom Complete (With Liner & Baffle)	Stove 328	2.40
	.....	Oven Door Complete	Stove 328	7.50
	.....	Oven Side Lining	Stove 328	1.20
	324-653 324-655 328-655	Valve Stem Complete	Stove 322, 328	.30
	322-657	Fuel Tube Fuel Valve Complete	Stove 322, 328	.90
	A6062 D0062 R4062 312-262	Main Generator (Gas Tip Marked "A4")	Stove 322, 329, 620, 621, 622, 623, 624, 625	2.40
	.....	Splasher	Stove 329	3.60
	.....	High Shelf	Stove 329	2.25
	.....	High Leg	Stove 330	.60
	.....	Low Shelf	Stove 330	1.80
	.....	High Shelf	Stove 330	1.35
	.....	High Shelf Support (Right)	Stove 330	.75
	.....	High Shelf Support (Left)	Stove 330	.75
	323-191	Tank Complete (With Fittings) (Zinc Plated)	Stove 323	9.90
	.....	High Shelf	Stove 328	2.10
	.....	High Shelf Support (Right)	Stove 328	.75

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
361 - 443	.....	High Shelf Support (Left)	Stove 328 .....
361 - 444	.....	High Shelf Trim (Right)	Stove 328 .....
361 - 445	.....	High Shelf Trim (Left)	Stove 328 .....
362 - 340	.....	Mixing Chamber	Stove 328 .....
362 - 345	.....	Oven Burner Drop Supply Tube (⅞"—No. 27)	Stove 328 .....
362 - 346	.....	Iron Pipe Ell With Lug (90° Outlets—½" I. P. S. Threads & ⅞" No. 27)	Stove 328 .....
362 - 350	.....	Preheater Valve Stem Extension	Stove 324, 328.....
362 - 376	.....	Preheater Bracket	Stove 324, 328.....
362 - 383	.....	Preheater Complete (Less Preheater Fuel Tube)	Stove 324, 328.....
364A467	.....	Tank Bracket (2 Piece) (Gray)	Stove 322 ('29).....
366 - 118	.....	Fuel Tip (Marked "F")	Stove 322, 323. 324, 32 327, 328, 329, 330.....
366 - 172	.....	Preheater Fuel Tube (26⅞" Long	Stove 322 .....
366 - 174	.....	Fuel Tube (6" Long)	Stove 322 .....
366 - 250	.....	Wheel & Nut (Mahogany, Bake-Lite)	Stove 322 ('29).....
366 - 303	.....	Flame Conductor	Stove 322 ('29).....
366 - 320	.....	Mixing Chamber (R. H. Oven)	Stove 322 ('29).....
366 - 321	.....	Mixing Chamber (L. H. Oven)	Stove 322 ('29).....
366 - 323	.....	Simmering Burner Cap	Stove 322 ('29).....
366 - 326	.....	Burner Manifold (Casting Only) (R. H. Oven)	Stove 322 ('29).....
366 - 327	.....	Burner Manifold (Casting Only) (L. H. Oven)	Stove 322 ('29).....
366 - 332	.....	Coupling Gasket	Stove 322 ('29).....
366 - 340	.....	Mixing Chamber (R. H. Oven)	Stove 322 ('29).....
366 - 341	.....	Mixing Chamber (L. H. Oven)	Stove 322 ('29).....
366 - 344	.....	Oven Burner Rear Bracket	Stove 322 ('29).....
366 - 346	.....	Oven Burner Ell	Stove 322 ('29).....
366 - 347	.....	Oven Burner Front Bracket	Stove 322 ('29).....
366 - 350	.....	Preheater Valve Stem Extension	Stove 322 ('29).....
366 - 353	.....	Preheater Valve Stem Complete (Less Extension)	Stove 322 ('29), 324,
366 - 354	.....	Preheater Valve Body	Stove 322 ('29), 324,
366 - 357	.....	Preheater Valve & Generator Complete (Less Extension)	Stove 322 ('29), 324,

Numerically Arranged by New Numbers

r by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
368	.....	Sub-flame Burner & Drain Plug (R. H. Oven)	Stove 322 ('29)	1.35
372	.....	Oven Burner	Stove 322 ('29)	2.40
373	.....	Oven Burner Pilot Lighter	Stove 322 ('29)	.36
375	.....	Sub-flame Burner & Drain Plug (L. H. Oven)	Stove 322 ('29)	1.35
376	.....	Preheater Bracket	Stove 322 ('29)	.48
379	.....	Tank Preheater Ell Body Assembly	Obsolete Supply No. 324-357	.....
383	.....	Preheater Complete (Less Preheater Fuel Tube)	Stove 322 ('29)	2.10
385	.....	Auxiliary Burner Valve Stem Complete (Short)	Stove 322 ('29)	.75
399	.....	Preheater Generator (With Needle) (Less Jamb Nut) (Gas Tip Marked "S")	Stove 322, 324, 328	.36
439	.....	Oven Burner Lighter Baffle (R. H. Oven)	Stove 322 ('29)	.15
440	.....	Oven Burner Lighter Baffle (L. H. Oven)	Stove 322 ('29)	.15
164	CS64	Filler Plug Complete	Camp Stove 2C, 2D, 9C, 9D, 10	.36
417	.....	Stove Bolt Nut ($\frac{5}{16}$" Square)	Water Heater 1	.03
457	CS57 CS57B 2C57 2CS57	Oven Baffle	Camp Stove 2C, 2D	.15
489	CS89	Key & Ring (Only)	Camp Stove 2C, 2D, 9C, 9D	.09
259	CS8 2CS8	Generator Screen	Camp Stove 2C, 2D, 9C, 9D	.06
328	2CS28Z	Auxiliary Valve Core	Camp Stove 2C, 9C	.24
329	2CS55	Auxiliary Valve Shift	Camp Stove 2C, 9C	.18
459	CS59 2CS59	Key Chain (Only)	Camp Stove 2C, 2D, 9C, 9D	.09
490	.....	Key, Ring & Chain	Camp Stove 2C, 2D, 9C, 9D	.15
556	CS56 CS56B 2CS56B	Generator Valve Stem Complete	Camp Stove 2C, 2D, 9C, 9D	.45
570	9C71 2CS71C 9CS71C	Fuel Tube ($8\frac{13}{16}$" Long)	Camp Stove 2C, 9C	.36
575	2CS66C 9CS66C	Tank & Generator Complete Assembled	Camp Stove 2C, 9C	6.00
621	3CS21Z	Adapter Ring (For Burner)	Camp Stove 2C, 9C	.30

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
403 - 326	2CS26C 9CS26C	Burner Manifold	Camp Stove 2C, 9C
403 - 365	CS23 2CS23 9CS23	Burner Cap (3 Piece, Bolt & Nut)	Camp Stove 2C, 9C
403 - 489	9CS19C 9D19	Lid, Baffles & Support Assembled	Camp Stove 9C, 9D
404 - 434	2CS34C	Grate	Camp Stove 2C
405 - 118	2D27	Generator Clamp (With Bolt & Nut)	Camp Stove 2D, 9D
405 - 170	2D71	Fuel Tube (5⅜" Long)	Camp Stove 2D, 9D
405 - 175	2D66	Tank & Generator Complete Assembled	Camp Stove 2D, 9D
405 - 239	CS18 2D18	Gas Tip & Holder (Gas Tip Marked "B")	Camp Stove 2C, 2D,
405 - 262	CS62 2CS62 2D62	Generator (Gas Tip Marked "B")	Camp Stove 2C, 2D,
405 - 315	.....	Rocker Arm Pin	Camp Stove 2D, 9D
405 - 326	2D26	Burner Manifold	Camp Stove 2D, 9D
405 - 357	2D28 2D28-29	Auxiliary Burner Valve Stem Complete	Camp Stove 2D, 9D
405 - 361	2D30	Rocker Arm	Camp Stove 2D, 9D
405 - 365	2D23	Burner Cap (2 Piece, Bolt & Nut)	Camp Stove 2D, 9D, Burner 454 Furnace 456
405 - 370	2D70	Burner Complete Assembled (Manifold, Caps, Auxiliary Valve, Rocker Arm & Pin)	Camp Stove 2D, 9D
405 - 434	9D34	Grate	Camp Stove 9D
406 - 434	2D34	Grate	Camp Stove 2D
406 - 489	2CS93C 2D93	Oven Complete (Less Oven Rack & Baffle)	Camp Stove 2C, 2D
406 - 492	2CS96 2CS96C 2D96	Oven Rack	Camp Stove 2C, 2D
409 - 118	2CS27 9CS18F	Generator Clamp (With Bolt & Nut)	Camp Stove 2C, 9C
409 - 327	CS63 9CS63	Stove Bolt (3/16"x3/8" R. H.)	Iron 3, 4, 5
409 - 434	9CS34	Grate	Camp Stove 9C
409 - 509	CS9	Pump Leather	Lantern E20, L427 (Camp Stove 2C, 9C
409 - 520	CS17 2CS17 9CS17	Pump Plunger Complete (Less Air Stem)	Camp Stove 2C, 9C

Complete Parts List

Numerically Arranged by New Numbers

by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
171	407-171	Fuel Tube (3 13/16" Long)	Camp Stove 10	.24
175	407-175	Tank (With Filler Plug, Air Stem & Tank Bracket)	Camp Stove 10	3.00
218	407-218	Gas Tip (Marked "GS")	Camp Stove 10	.15
256	407-256	Generator Valve Stem Complete	Camp Stove 10	.60
262	407-262	Generator (Gas Tip Marked "GS")	Camp Stove 10	1.20
309	407-309	Hot Blast Deflector	Camp Stove 10	.12
313	407-313	Hot Blast Deflector Lever	Camp Stove 10	.12
314	407-314	Auxiliary Burner Control Lever	Camp Stove 10	.12
322	407-322	Mixing Chamber Shield	Camp Stove 10	.15
324	.....	Stove Bolt (3/16"x1/4" R. H.)	Camp Stove 10	.03
326	407-326	Burner Manifold	Camp Stove 10	1.80
328	407-328	Auxiliary Burner Control	Camp Stove 10	.09
370	407-370	Burner Complete Assembled (Manifold, Caps & Auxiliary Burner Control)	Camp Stove 10	2.70
8	407-479	Cabinet, Lid, Baffles & Grate	Camp Stove 10	3.00
5	.....	Pump	Camp Stove 10 Iron 3, 4, 5	.45
4	HGP4T	Iron Pipe Nipple (3/8"x4")	H. G. P. 5052	.12
2	HGP29	Tank Fuel Valve Complete	H. G. P. 5052	1.20
1	.....	Filler Plug Cap (Only)	Heater 2	.45
2	A0032 HGP32	Filler Plug Air Stem	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 600, 601, 602, 620, 621, 622, 623, 624, 625 H. G. P. 5052 Heater 2	.18
9	A0038 HGP38	Filler Plug Core & Gasket	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 600, 601, 602, 620, 621, 622, 623, 624, 625 H. G. P. 5052 Heater 2	.30
	A0040 D0540 HGP40 2H40 310-140	Filler Plug Complete	Stove 120, 121, 200, 201, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 600, 601, 602, 620, 621, 622, 623, 624, 625 H. G. P. 5052 Heater 2	.75
.....		Burner Base	H. G. P. 5052	1.35
HGP72		Grate & Brackets	H. G. P. 5052	1.50
.....		Burner, Generator & Grate	H. G. P. 5052	9.75

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
451 - 504	.....	Pump Barrel Top Plug.....	Lantern E20 Stove 120, 121, 200, 20 203, 204, 210, 211, 212 214, 224, 225, 600, 601 620, 621, 622, 623, 624 H. G. P. 5052 Heater 2 Pump 627-590, 628.....
451 - 509	AGP HGP D0809 H0809	Pump Leather	Lantern E20 Stove 120, 121, 200, 20 203, 204, 210, 211, 212 214, 224, 225, 600, 601 620, 621, 622, 623, 624 H. G. P. 5052 Heater 2 Pump 627-590, 628.....
451 - 522	AGP A0103 D0803 H105	Jumbo Pump	Lantern E20 Stove 120, 121, 200, 20 203, 204, 210, 211, 212 214, 224, 225, 600, 601 620, 621, 622, 623, 624 H. G. P. 5052 Heater 2 .....
452 - 171	.....	Fuel Tube (7" Long).....	H. G. P. 5052.....
452 - 189	.....	Tank Complete (With Fittings).....	H. G. P. 5052.....
454 - 118	.....	Fuel Tip (Marked "Y").....	Burner 454 Furnace 456 .....
454 - 148	.....	Fuel Wire (Fuel Tip) (Marked "Y")	Burner 454 Furnace 456 .....
454 - 158	.....	Connection (Fuel Wire to Fuel Tube)	Burner 454 Furnace 456 .....
454 - 165	.....	Fount Complete	Burner 454 .....
454 - 171	.....	Fuel Tube (3⅛" Long).....	Burner 454 Furnace 456 .....
454 - 218	.....	Gas Tip (Marked "T").....	Burner 454 Furnace 456 .....
454 - 238	.....	Cleaning Needle & Holder.....	Burner 454 Furnace 456.....
454 - 256	.....	Generator Valve Stem Complete	Burner 454 Furnace 456 .....
454- 262	.....	Generator (Gas Tip Marked "T")	Burner 454 Furnace 456 .....
454 - 326	.....	Burner Manifold (Less Burner Cap)	Burner 454 Furnace 456 .....
454 - 370	.....	Burner Manifold & Burner Cap....	Burner 454 Furnace 456 .....
454 - 404	.....	Baffle Brace	Burner 454 .....
454 - 413	.....	Generator Clamp	Burner 454 Furnace 456 .....

Complete Parts List

Numerically Arranged by New Numbers

er by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
423	.....	Bail	Burner 454	.09
427	.....	Base Lock Nut.....	Burner 454 Furnace 456	.06
444	.....	Grate	Burner 454	.45
460	.....	Baffle	Burner 454	.60
132	.....	Filler Plug Air Stem	Furnace 456	.18
164	.....	Filler Plug Complete.....	Furnace 456	.60
165	.....	Fount Complete	Furnace 456	6.60
462	.....	Iron Support Complete	Furnace 456	.45
465	.....	Frame & Bail Complete.....	Furnace 456	2.10
401	WH1 WH1M	Water Heater Jacket Top	Water Heater 1.....	.60
402	WH2 WH2M	Water Heater Jacket Door (With Latch)	Water Heater 1.....	3.00
403	WH3 WH3M	Water Heater Jacket Back	Water Heater 1.....	2.40
04	WH4 WH4M	Water Heater Jacket Door Latch	Water Heater 1.....	.30
05	WH5 WH5M	Water Heater Jacket Complefe ..	Water Heater 1.....	5.25
11	WH11 WH11M	Water Heater Coil & Two Gaskets (3/8") (Takes 4).....	Water Heater 1.....	2.10
15	WH15 WH15M	Manifold, Four Gaskets & Lock Nut	Water Heater 1.....	1.50
27	WH27	Burner Bracket	Water Heater 1.....	.15
24	WH24	Coils & Manifolds (Two) Lock Nuts (Two) Assembled.....	Water Heater 1.....	8.25
7	RH19	Tank Air Valve & Air Gauge Complete	Heater 1	2.55
6	RH65	Tank Complete (With Fittings)...	Heater 1	10.50
9	RH24-25	Drip Pan & Baffle Plate Complete Assembled (With Gen. Clamp, Bolts & Nuts).....	Heater 1	2.40
1	RH71	Fuel Tube (8½" Long).....	Heater 1	.48
3	RH72	Air Tube (24" Long).....	Heater 1	.54
5	RH66	Tank, Pump, Drip Pan, Baffle Plate & Generator Complete Assembled	Heater 1	18.00

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
471 - 238	RH9	Cleaning Needle & Holder	Stove 224, 225, 322, 32 625 Water Heater 1 Camp Stove 2C, 2D 9D, 10 H. G. P. 5052 Heater 1 Urn Burner 505
471 - 262	RH62	Generator (Gas Tip Marked "AO")	Heater 1
471 - 302	RH2	Radiant Back (Clay)	Heater 1
471 - 303	RH3	Radiant	Heater 1
471 - 322	H22 RH22	Sub-flame Burner Cap (5/8")	Heater 1, 2, 4, 5, 5A,
471 - 370	RH70	Burner Manifold (With Main & Sub-flame Burner Caps)	Heater 1
471 - 517	RH51	Pump Plunger Complete	Heater 1
471 - 530	RHP	Pump	Heater 1
471 - 653	AGT55-16	Tank Fuel Valve Stem Complete	Stove 120, 121, 200, 201 203, 204, 210, 211, 212 214, 224, 225, 600, 601 620, 621, 622, 623, 624 Heater 1
471 - 657	RH29	Tank Fuel Valve Complete	Heater 1
471 - 906	TW	Alcohol Torch Wick	Stove 200, 201, 202, 203 600, 601, 602 Heater 1, 2
471 - 955	RD	Drain Cup	Heater 1
472 - 125	AG A0104 D0504 H104	Air Gauge	Stove 120, 121, 200, 201 203, 204, 210, 211, 212 214, 224, 225, 600, 601, 620, 621, 622, 623, 624, Heater 1, 2, 4
472 - 128	.....	Stove Bolt (5/16"x16" R. H.)	Heater 2, 4, 5, 5A, 7
472 - 169	.....	Drip Pan & Brackets	Heater 2
472 - 170	2H67	Drip Pan, Brackets, Gen. Clamps, Bolts & Nuts	Heater 2
472 - 171	2H71	Fuel Tube (6½" Long)	Heater 2
472 - 189	2H65	Tank Complete (With Fittings)	Heater 2
472 - 193	2H99	Tank, Drip Pan & Generator Complete Assembled	Heater 2
472 - 233	2H22	Generator Clamps, Bolt & Nut	Heater 2, 4, 5, 5A, 7
472 - 238	A2309 2RH9	Cleaning Needle & Holder	Heater 2, 4, 7 Urn Burner 404
472 - 262	2H62	Generator (Gas Tip Marked "4B")	Heater 2
472 - 303	2RH3	Radiant	Heater 2, 4

Numerically Arranged by New Numbers

by o.	Old No.	Name of Part	Products on Which Used	Net Retail Price
08	A0246 A3046 R4046	Drain Plug Stem	Stove 120, 121, 224, 225, 322, 323, 324, 325, 326, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625 Heater 2	.09
67	A0245 2H45	Drain Plug Complete	Stove 120, 121, 224, 225, 322, 323, 324, 325, 326, 327, 328, 329, 330, 620, 621, 622, 623, 624, 625 Heater 2	.24
70	2H70	Burner Manifold (With Drain Plug, Main & Sub-flame Burner Caps)	Heater 2	3.00
03	2RH2	Radiant Back (Aluminum)	Heater 2, 4	2.10
05	2H05	Front Foot	Heater 2, 4	.30
06	2H06	Post Top Cap	Heater 2, 4	.18
07	2H07	Post Top	Heater 2, 4	.18
08	2H27R	Frame Trim (Right)	Heater 2, 4	.60
09	2H27L	Frame Trim (Left)	Heater 2, 4	.60
10	.....	Post Bolt	Heater 2, 4	.09
15	2H74	Door Trim	Heater 2, 4	1.50
17	2RH	Top (Porcelain)	Heater 2, 4	1.20
18	2H37R	Top Trim (Right)	Heater 2, 4	.60
19	2H37L	Top Trim (Left)	Heater 2, 4	.60
20	.....	Radiant Holder (Top)	Heater 2, 4, 7	.36
21	2H59	Key Chain (Only)	Heater 2	.12
23	2H79	Door Handle Name Plate	Heater 2, 4	.36
35	.....	Top Tie Rod	Heater 2, 4, 5, 5A, 7	.09
36	.....	Top Tie Rod Nut	Heater 2, 4, 5, 5A, 7	.03
73	2H80	Bail	Heater 2, 4	.24
80	2H20	Guard	Heater 2, 4, 7	1.05
89	2H89	Key & Ring	Heater 2	.12
91	2H75	Door Complete	Heater 2	3.00
51	2H28	Tank Fuel Valve Stem Complete	Heater 2	.30
57	2H29	Tank Fuel Valve Complete	Heater 2	.90
20	H102	Alcohol Bottle Cap & Wick	Stove 200, 201, 202, 203, 204, 600, 601, 602 Heater 1, 2	.75
25	H100	Alcohol Torch Complete (Bottle, Cap, Wick, Chain & Snuffer)	Stove 200, 201, 202, 203, 204, 600, 601, 602 Heater 1, 2	.96

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
474 - 109	.....	Air Stem Spring	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 169	.....	Drip Pan & Brackets	Heater 4
474 - 171	.....	Fuel Tube (4⅝" Long)	Heater 4
474 - 191	.....	Tank Complete (With Fittings)	Heater 4
474 - 193	.....	Tank, Drip Pan & Generator Complete Assembled	Heater 4
474 - 218	4H	Gas Tip (Marked "4H")	Heater 4, 5, 5A, 7
474 - 262	.....	Generator (Gas Tip Marked "4H")	Heater 4, 7
474 - 310	.....	Preheater Pan	Heater 4
474 - 370	.....	Burner Manifold (With Main & Sub-flame Burner Caps)	Heater 4
474 - 389	.....	Preheater Generator (Gas Tip Marked "N")	Heater 4
474 - 491	.....	Door Complete	Heater 4
474 - 503	.....	Hexagon Brass Nut (⅜", No. 27)	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 509	.....	Pump Leather	Stove 322, 323, 324, 327, 328, 329, 330 Heater 1, 4, 5, 5A,
474 - 510	.....	Pump Plunger Lower Washer	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 512	.....	Pump Handle	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 515	.....	Air Stem	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 517	.....	Handle Nut	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 555	.....	Pump Plunger Complete (Less Air Stem)	Stove 322, 323, 324, 327, 328, 329, 330 Heater 4, 5, 5A, 7
474 - 657	.....	Tank Fuel & Preheater Valve Complete	Heater 4
475 - 115	.....	Combination Fuel & Air Gauge	Heater 5, 5A
475 - 118	.....	Fuel Tip (Marked "E")	Heater 5, 5A, 7
475 - 170	.....	Drip Pan, Brackets, Gen. Clamps, Bolts & Nuts	Heater 5
475 - 171	.....	Fuel Tube (3⅜" Long)	Heater 5, 5A, 7

Complete Parts List

Numerically Arranged by New Numbers

r by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
191	.....	Tank Complete (With Fittings)..	Heater 5	9.30
193	.....	Tank, Drip Pan & Generator Complete Assembled	Heater 5, 5A.....	12.60
262	.....	Thermo-Safety Generator (Gas Tip Marked "4H").....	Heater 5, 5A.....	3.30
303	.....	Radiant .....Heater 5, 5A, 7.....		.30
310	.....	Preheater Pan .....Heater 5, 5A, 7.....		.45
318	.....	Gas Tip (Marked "S").....	Stove 322, 323, 324, 325, 326, 327, 328, 329, 330 H. G. P. 5052 Water Heater 1 Heater 5, 5A, 7 Urn Burner 404, 505, 707.....	.06
323	RH23	Main Burner Cap (⅞").....	Heater 1, 2, 4, 5, 5A, 7..... .....2 for	.09
357	.....	Preheater Tank Valve Complete (Fuel Tip Marked "E").....	Heater 5	1.20
370	.....	Burner Manifold (With Main & Sub-flame Burner Caps).....	Heater 5, 5A, 7.....	3.00
389	.....	Preheater Generator (Gas Tip Marked "S")	Heater 5, 5A, 7.....	.30
403	.....	Radiant Back (Aluminum).....	Heater 5, 5A, 7.....	1.05
404	.....	Foot (Right)	Heater 5	.75
405	.....	Foot (Left) .....Heater 5		.75
407	.....	Post Top .....Heater 5		.24
408	.....	Frame Trim (Right).....	Heater 5	.45
409	.....	Frame Trim (Left).....	Heater 5	.45
410	.....	Post Bolt	Heater 5, 5A.....	.09
415	.....	Door Trim .....Heater 5, 5A, 7.....		.60
417	.....	Top (Porcelain)	Heater 5, 5A.....	1.20
418	.....	Top Trim (Right).....	Heater 5	.45
419	.....	Top Trim (Left).....	Heater 5	.45
420	.....	Radiant Holder (Top).....	Heater 5, 5A.....	.36
423	.....	Bail .....Heater 5, 5A, 7.....		.30
430	.....	Guard .....Heater 5, 5A.....		1.05
431	.....	Door Complete	Heater 5	2.25
433	.....	Tank Fuel Valve Stem Complete	Heater 5	.30
437	.....	Tank Fuel Valve Complete	Heater 5	.75
446	.....	Tank Bracket (Right)	Heater 5A, 7.....	.15
447	.....	Tank Bracket (Left)	Heater 5A, 7.....	.15

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
475A170	.....	Drip Pan (Only)	Heater 5A, 7
475A191	.....	Tank Complete (With Fittings)	Heater 5A
475A357	.....	Preheater Tank Valve Complete (Fuel Tip Marked "E")	Heater 5A, 7
475A404	.....	Foot (Right)	Heater 5A
475A405	.....	Foot (Left)	Heater 5A
475A407	.....	Post Top	Heater 5A, 7
475A408	.....	Frame Trim (Right)	Heater 5A, 7
475A409	.....	Frame Trim (Left)	Heater 5A, 7
475A418	.....	Top Trim (Right)	Heater 5A
475A419	.....	Top Trim (Left)	Heater 5A
475A491	.....	Door Complete	Heater 5A
475A648	.....	Indicator Handle & Screw	Heater 5A, 7
475A653	.....	Valve Stem (Less Indicator Handle & Screw)	Heater 5A, 7
475A657	.....	Tank Fuel Valve Complete	Heater 5A, 7
476 - 140	.....	Filler Plug Complete	Burner 454
476 - 520	.....	Pump Plunger Complete (Less Air Stem)	Burner 454 Furnace 456
477 - 125	.....	Air Gauge	Heater 7
477 - 191	.....	Tank Complete (With Fittings)	Heater 7
477 - 193	.....	Tank, Drip Pan & Generator Complete Assembled	Heater 7
477 - 405	.....	Front Foot	Heater 7
477 - 410	.....	Post Bolt	Heater 7
477 - 417	.....	Top (Porcelain)	Heater 7
477 - 418	.....	Top Trim (Right)	Heater 7
477 - 419	.....	Top Trim (Left)	Heater 7
477 - 491	.....	Door Complete	Heater 7
480 - 171	.....	Fuel Tube (5" Long)	Heater 480
480 - 361	.....	Vaporizing Tube	Heater 480
480 - 362	.....	Burner Cap Complete	Heater 480
480 - 364	.....	Filler Rod & Wick	Heater 480
480 - 374	.....	Radiant	Heater 480
480 - 399	.....	Burner Unit Complete (With Generator)	Heater 480
480 - 407	.....	Reflector	Heater 480
480 - 450	.....	Lock Wheel	Heater 480

Numerically Arranged by New Numbers

y No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
0	.....	Guard	Heater 480	.45
0	.....	Burner Unit, Radiant & Reflector Complete	Heater 480	7.50
3	.....	Valve Stem Complete.....	Heater 480	.30
4	.....	Valve Body	Heater 480	.75
7	.....	Fuel Valve Complete.....	Heater 480	1.35
3	.....	Alcohol Bottle (Only).....	Heater 480	.15
3	.....	Alcohol Torch (Only).....	Heater 480	.18
0	.....	Alcohol Torch & Bottle Complete	Heater 480	.30
3	SB17	Generator Clean-Out Plug.....	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 505, 707	.09
3	MB19 SB19 4SB19 5SB19	Filler Coil & Asbestos Cord.....	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 505 ...	.15
5	BBTC25	Tip Cleaner Complete.....	Generator 501-262, 502-262..	.48
7	NBB1-17	Generator Tee & Bushing.....	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 707....	.30
8	BB9	Cleaning Needle & Holder.....	Generator 501-262, 502-262 .	.09
2	5BB62	Generator (Gas Tip Marked "AO")	Urn Burner 505.....	3.30
8 .	BB18-4 H2 4BB18 4SB18 2H18 501-218-4	Gas Tip (Marked "4B").....Heater 2	Urn Burner 4, 404.....	.12
2	4BB62	Generator (Gas Tip Marked "4B")	Urn Burner 404.....	3.30
3	5BB19-7 501-223-7	Filler Coil & Asbestos Cord.....	Urn Burner 707.....	.15
8	MB18	Gas Tip (Marked "MB").....	Urn Burner 707.....	.12
1	SB1	Generator Connection	Urn Burner 4, 5.....	.15
5	SB25 SBTC25	Tip Cleaner Complete.....	Urn Burner 4, 5.....	.48
8	SB9	Cleaning Needle & Holder.....	Urn Burner 4, 5.....	.09
2	5SB62	Generator (Gas Tip Marked "AO")	Urn Burner 5.....	3.30
3	SB56 SB56B	Generator Valve Stem Complete	Urn Burner 4, 5.....	.48
2	4SB62	Generator (Gas Tip Marked "4B")	Urn Burner 4.....	3.30

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
514 - 211	SBTC11	Generator Valve Clean-Out Plug	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 707
514 - 262	514-5B	Generator (Gas Tip Marked "AO")	H. G. P. 5052 Water Heater 1 Urn Burner 505
514 - 263	514-4B	Generator (Gas Tip Marked "4B")	Urn Burner 404
515 - 262	515-7B	Generator (Gas Tip Marked "MB")	Urn Burner 707
540 - 326	5BB26	Burner Base	Water Heater 1 Urn Burner 505
540 - 923	4BB23	Burner Cap	Urn Burner 404
540 - 926	4BB26	Burner Base	Urn Burner 404
542 - 323	7BB23	Burner Cap	Urn Burner 707
542 - 326	7BB26	Burner Base	Urn Burner 707
542 - 329	7BB29	Preheater Fuel Tube (12¾" Long)	Urn Burner 707
543 - 323	MB23 5BB23	Burner Cap	H. G. P. 5052 Water Heater 1 Urn Burner 505
543 - 328	MB28Z	Generator Clamp	Urn Burner 404, 505, 70
544 - 289	HB99	Preheater Generator (Gas Tip Marked "S")	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 70
544 - 329	HB29 NBB29 NBB29Z	Preheater Fuel Tube (10¼" Long)	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505
544 - 375	HB11	Preheater Nipple & Screen	Urn Burner 404, 505, 70
544 - 377	HB9-10	Preheater Pan (With Flame Deflector)	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 707
544 - 383	HB	Preheater Complete (Less Preheater Fuel Tube)	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 70
544 - 657	HB57 HB57N	Preheater Valve Complete	H. G. P. 5052 Water Heater 1 Urn Burner 404, 505, 70
545 - 301	.....	Hexagon Brass Nut (3/16") (12-24)	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 707 2
545 - 302	SB2	Stove Bolt (3/16"x¾" R. H.)	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 707 2
545 - 303	SB3	Stand Base	Urn Burner 4, 5, 404, 707

Complete Parts List

Numerically Arranged by New Numbers

Old No.	Name of Part	Products on Which Used	Net Retail Price
SB4	Iron Pipe Nipple (3/8"x3")	Urn Burner 4, 5, 404, 505, 707	.12
SB10	Preheater Pan	Urn Burner 4, 5	.18
4SB23	Burner Cap	Urn Burner 4	1.20
SB24	Stove Bolt (3/16"x3/4" F. H.)	H. G. P. 5052 Water Heater 1 Urn Burner 4, 5, 404, 505, 707 ....2 for	.06
4SB26	Burner Base	Urn Burner 4	1.20
2CS63 2D63 9CS63 9CS63C	Stove Bolt (3/16"x1/2" F. H.)	Camp Stove 10....2 for	.06
5SB23	Burner Cap	Urn Burner 5	1.50
5SB26	Burner Base	Urn Burner 5	1.35
AO118	Gas Tip (Marked "N")	Stove 120, 121, 210, 211, 212, 213, 214, 224, 225, 620, 621, 622, 623, 624, 625 Heater 4	.06
10	Camp Stove High Stand	Camp Stove 2C, 2D, 9C, 9D, 10	2.40
.....	Filler Plug Gasket (Special Filler Plug)	Special ....2 for	.09
.....	Hollow Wire (Only) (No. 2)	Special ....per foot	.09
.....	Special Filler Plug Complete (With Hollow Wire Connection)	Special	1.05
.....	Valve Stem Complete	Special	.30
47	Wall Valve Complete	Special	.75
1	Hollow Wire Male Plug (Open)	Special	.06
1B	Hollow Wire Male Plug (Blind)	Special	.06
7	Hollow Wire Splicing Sleeve	Special	.03
8	Hollow Wire Nipple	Special	.12
13J Blind	Hollow Wire Jamb (Blind)	Special	.03
13J	Hollow Wire Jamb	Special	.03
13 13N	Hollow Wire Jamb Nut	Special	.03
14	Hollow Wire Ell	Special	.12
15	Hollow Wire Corner Tee	Special	.18
16	Hollow Wire Tee (With Drop)	Special	.24
17	Hollow Wire Tee	Special	.18
20	Hollow Wire Ell (With Nail Plate)	Special	.18

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
599 - 921	21	Hollow Wire Tee (With Nail Plate)	Special
599 - 923	23	Hollow Wire Cross (With Drop)	Special
599 - 924	24	Hollow Wire Cross	Special
599 - 925	25	Reducing Nipple (⅛" I. P. S. Thread Male to Hollow Wire)	Special
599 - 926	26	Reducing Coupling-Nipple (⅛" I. P. S. Thread Male to Hollow Wire)	Special
599 - 927	27	Reducing Nipple (¼" I. P. S. Thread Male to Hollow Wire)	Special
599 - 928	28	Reducing Coupling-Nipple (¼" I. P. S. Thread Male to Hollow Wire)	Special
599 - 930	A0750 WC30 WC30J	Reducing Coupling-Nipple (¼" S. A. E. Female to Hollow Wire Jamb Nut)	Special
599 - 931	A0753 931	Reducing Coupling-Nipple (¼" S. A. E. Female to 3/16" S. A. E. Male)	Special
599 - 932	A0021 A0122 A0713 2H21	Jamb Nut (3/16" S. A. E.)	Special
599 - 933	813	Hollow Wire Nipple (With Jamb & Nut Drop)	Special
599 - 934	A0030 A0751	Reducing Coupling-Nipple (3/16" S. A. E. Female to Hollow Wire Jamb Nut)	Special
599 - 935	A0752	Reducing Nipple (¼" S. A. E. Male to Hollow Wire Jamb Nut)	Special
599 - 936	A0717	Tee (3/16" S. A. E.)	Stove 224, 225, 323, 328, 625 Special
599 - 937	A0754	Reducing Nipple-Coupling (¼" S. A. E. Male to 3/16" S. A. E. Female)	Special
599 - 940	4717	Tee (3/16" S. A. E. Nickel Plated)	Special
600 - 399	.....	Burner, Valve, Generator & Fount Complete Assembled	Iron 1
600 - 657	2	Valve & Generator Complete Assembled	Iron 1
601 - 136	7 236	Filler Plug Gasket	Iron 1, 2
601 - 159	14 244	Fount (Less Filler Plug)	Iron 1, 2
601 - 164	8 231	Filler Plug Complete	Iron 1, 2
601 - 370	12 270	Burner	Iron 1, 2

Numerically Arranged by New Numbers

by No.	Old No.	Name of Part	Products on Which Used		Net Retail Price
99	222	Burner, Valve, Generator & Fount Complete Assembled	Iron 2		3.45
14	5 214	Valve Stem	Iron 1, 2		.24
16	4 216	Pack Nut	Iron 1, 2		.24
20	3 2120	Valve Stem Packing	Iron 1, 2	2 for	.09
53	.....	Valve Stem Complete	Iron 1, 2		.60
57	299	Valve & Generator Complete Assembled	Iron 2		1.50
0	11 2WJ	Wrench	Iron 1, 2		.15
2	.....	Filler Plug Air Stem	Iron 3, 4, 5		.18
6	.....	Filler Plug Gasket	Iron 3, 4, 5	2 for	.06
9	.....	Filler Plug Core & Gasket	Iron 3, 4, 5		.18
7	.....	Lock Nut	Iron 3, 4, 5		.06
9	.....	Fount (Less Filler Plug)	Iron 3, 5		1.26
4	.....	Filler Plug Complete	Iron 3, 4, 5		.48
9	.....	Fount, Valve & Generator Complete Assembled	Obsolete. Supply No. 604-190		.....
8	.....	Gas Tip (Marked "I")	Iron 3, 4		.06
9	603-289	Generator, Cleaning Needle & Holder (Gas Tip Marked "I")	Iron 3, 4		.36
5	.....	Burner Manifold (Less Plug)	Iron 3, 4		.90
9	.....	Burner Plug	Iron 3, 4		.06
5	.....	Burner Manifold & Plug	Iron 3, 4		.96
1	.....	Base	Iron 3, 4, 5		1.20
2	.....	Body	Obsolete. Supply No. 604-402		.....
5	.....	Lid Plate (Lower)	Iron 3, 4, 5		.36
7	.....	Lid Plate (Upper)	Iron 3, 4, 5		.45
0	.....	Fount Bracket	Iron 3, 4, 5		.12
5	.....	Locator Pin	Iron 3, 4, 5,	2 for	.06
0	.....	Pilot Flame Baffle Plate	Iron 3, 4, 5		.09
0	220	Stand	Iron 1, 2, 3, 4, 5		.24
1	.....	Iron Handle	Obsolete. Supply No. 604-445		.....
5	15 25	Handle Bracket	Iron 1, 2, 3		.15

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
603 - 451	13 26	Handle Bolt ($\frac{11}{16}$"x5" Carriage)	Iron 1, 2, 3, 4, 5
603 - 455	.....	Lid Plate to Base Screw (1¾"—No. 12 O. H. M. S.)	Iron 3, 4, 5
603 - 457	.....	Stove Bolt ($\frac{1}{4}$"x$\frac{11}{16}$" R. H.)	Iron 3, 4, 5
603 - 605	.....	Air Wire	Obsolete. Supply No. 604-604
603 - 638	.....	Cleaning Needle & Holder	Iron 3, 4
603 - 644	.....	Fuel Intake & Screen	Iron 3
603 - 653	.....	Generator Valve Stem & Pack Nut (Less Needle & Holder)	Iron 3, 4
603 - 657	.....	Generator, Valve, Fuel Intake & Air Wire Complete Assembled	Obsolete. Supply No. 604-657
603 - 940	19 219	Funnel	Iron 1, 2, 3, 5
604 - 159	.....	Fount (Less Filler Plug)	Iron 4
604 - 189	.....	Fount, Valve & Generator Complete Assembled	Iron 4
604 - 190	.....	Assembly (Includes 604-190 Fount, Valve & Generator Complete Assembled, 604-930 Fuel Measuring Cup and Directions for Model No. 4 Iron)	Iron 3
604 - 402	.....	Body (Blue Porcelain)	Iron 3, 4
604 - 445	10 212	Iron Handle	Iron 1, 2, 3, 4
604 - 446	.....	Handle Bracket	Iron 4
604 - 604	.....	Air Wire	Iron 3, 4
604 - 618	.....	Fuel Intake (Marked "AZ")	Iron 4
604 - 648	.....	Fuel Intake & Air Wire (Fuel Intake Marked "AZ")	Iron 4
604 - 654	.....	Valve Body	Iron 4
604 - 657	.....	Generator, Valve, Fuel Intake & Air Wire Complete Assembled	Iron 3, 4
604 - 659	.....	Fuel Intake Protector & Screen	Iron 4
604 - 930	604-920	Fuel Measuring Cup	Iron 4
605 - 189	.....	Fount, Valve & Generator Complete Assembled	Iron 5
605 - 210	.....	Jamb Nut	Iron 5
605 - 218	.....	Gas Tip (Marked "D")	Iron 5
605 - 299	.....	Generator, Cleaning Needle & Holder (Gas Tip Marked "D")	Iron 5

Complete Parts List

Numerically Arranged by New Numbers

Y	Old No.	Name of Part	Products on Which Used	Net Retail Price
0	.....	Burner Manifold & Burner Tube Complete	Iron 5	.90
2	.....	Body (Green Porcelain)	Iron 5	.90
5	.....	Iron Handle	Iron 5	.21
6	.....	Handle Bracket	Iron 5	.15
8	.....	Cleaning Needle & Holder	Iron 5	.15
3	.....	Generator Valve Stem Complete (Less Cleaning Needle & Holder)	Iron 5	.60
4	.....	Valve Body	Iron 5	.60
7	.....	Valve & Generator Complete Assembled	Iron 5	1.50
4	.....	Alcohol Bottle (Only)	Iron 5	.09
3	.....	Alcohol Torch (Only)	Lamp C331 Iron 5	.15
0	.....	Alcohol Torch & Bottle Complete	Lamp C331 Iron 5	.24
0	.....	Wrench	Lamp C331, 117, 118, 119 Lantern E20, L227, L427 ('26), L427 ('27), 220, 228 Stove 120, 121, 200, 202, 203, 204, 210, 211, 212, 213, 214, 224, 225, 322, 323, 324, 325, 326, 327, 328, 329, 330, 600. 601, 602, 620, 621, 622, 623, 624, 625 H. G. P. 5052 Burner 454 Furnace 456 Water Heater 1 Heater 1, 2, 4, 5, 5A, 7, 480 Iron 3, 4, 5 Tank 652C	.15
	PP1P	Pump Base	Pump 625	.75
4	ATP4P	Pump Barrel Top Plug	Pump 625	.09
9	SP9P	Pump Leather	Pump 625	.06
3	2SP31P	Connection (Hose to Pump Base)	Pump 625	.15
	.....	Hose Clamp	Pump 625, 628	2 for .06
3	91	Connection (Hose to Air Valve)	Pump 625, 628	.24
2	CV	Check Valve	Pump 625	.15
	SP55P	Pump Handle, Clamp & Bushing	Pump 625	.45
	.....	Pump Plunger Complete	Pump 625	1.20
	.....	Hose, Connection & Clamps	Pump 625	1.20
	.....	Pump Plunger Complete	Pump 627-590	.45

Complete Parts List

Numerically Arranged by New Numbers

Order by New No.	Old No.	Name of Part	Product on Which Used
627 - 587	.....	Suction Tube & Jamb Nut	Pump 627-590
627 - 590	627	Suction Pump	Special
628 - 501	.....	Pump Base (5/8" Center Hole)	Pump 628
628 - 512	.....	Pump Handle	Pump 628
628 - 526	.....	Hose Connection Body	Pump 628
628 - 538	.....	Check Valve	Pump 628
628 - 570	.....	Pump Plunger Complete	Pump 628
628 - 580	.....	Hose, Connection, Check Valve & Clamps	Pump 628
628A501	.....	Pump Base (1" Center Hole)	Pump 628
630 - 509	.....	Pump Leather	Siphon 630-545
630 - 545	630 FS11	Siphon	Special
650 - 125	.....	Air Gauge	Tank 652C
650 - 131	TK31	Filler Plug Cap (Only)	Stove 322, 323, 324, 325, 327, 328, 329, 330 Heater 1, 4, 5, 5A, 7 Tank 652C
650 - 135	.....	Filler Plug Disc, Gasket & Screw	Stove 322, 323, 324, 325, 327, 328, 329, 330 Heater 1, 4, 5, 5A, 7 Tank 652C
650 - 136	A0036 HGP36 TK36	Filler Plug Gasket	Stove 120, 121, 200, 201, 203, 204, 210, 211, 212, 214,. 224, 225, 322, 323, 325, 326, 327, 328, 329, 600, 601, 602, 620, 621, 623, 624, 625 H. G. P. 5052 Heater 1, 2, 4, 5, 5A, 7 Tank 652C
650 - 140	T40 TK40	Filler Plug Complete	Stove 322, 323, 324, 325, 327, 328, 329, 330 Heater 1, 4, 5, 5A, 7 Tank 652C
650 - 157	T19	Air Valve Complete	Tank 652C
650 - 651	TK9	Valve Stem Complete	H. G. P. 5052 Tank 652C
650 - 657	.....	Tank Fuel Valve Complete	Tank 652C

Numerically Arranged by Old Numbers

Old No.	Name of Part	Products on Which Used	Net Retail Price
	Silver Solder	Special ..... Per Oz.	1.80
	Pad For No. 0 Funnel	Special	.30
	Pad For No. 1 Funnel	Special	.60
0	Filtering Funnel	Special	.60
1	Filtering Funnel	Special	1.20
1	Body Base	Iron 1	1.32
2	Valve & Generator Complete Assembled	Iron 1	1.50
2WJ	Wrench	Iron 2	.15
3	Valve Stem Packing	Iron 1 ..... 2 for	.09
4	Pack Nut	Iron 1	.24
5	Valve Stem	Iron 1	.24
6	Lid Set Screw	Iron 1	.12
7	Filler Plug Gasket	Iron 1 ..... 2 for	.06
8	Filler Plug Complete	Iron 1	.24
9	Deflector Plate	Iron 1	.30
10	Camp Stove High Stand	Camp Stove 2C, 2D, 9C, 9D, 10	2.40
10	Iron Handle	Iron 1	.21
11	Wrench	Iron 1	.15
12	Burner	Iron 1	.60
13	Handle Bolt (3/16"x5" Carriage)	Iron 1	.06
14	Fount (Less Filler Plug)	Iron 1	1.26
15	Handle Bracket	Iron 1	.15
16B	Lid Plate (Lower)	Iron 1	.45
16T	Lid Plate (Upper)	Iron 1	.36
17	Lid Plate Asbestos Liner	Iron 1	.18
18	Bolt (Handle Bracket to Lid Plate) (Lower) (1/4"x5/8" U. S. S. R. H.)	Iron 1	.12
19	Funnel	Iron 1	.18
21	Deflector Plate	Iron 2	.30
22	Lid Plate (Lower)	Iron 2	.45
23	Lid Plate Asbestos Liner	Iron 2	.18
24	Lid Plate (Upper)	Iron 2	.36
25	Handle Bracket	Iron 2	.15
26	Handle Bolt (3/16"x5" Carriage)	Iron 2	.06
27	Lid Extension Arm	Iron 2	.12

Complete Parts List

Numerically Arranged by Old Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
28	28	Bolt (Handle Bracket to Lid Plate) (Lower) (¼"x⅝" U. S. S. R. H.)	Iron 2
102-3-13-16	102-3-13-16	Fuel Valve Complete	Lamp 1
103 - 16	103-16	Valve Stem Complete	Lamp 1
107-8-9	107-8-9	Generator Barrel & Asbestos Wick	Lamp 1
108	108	Asbestos Wick (Tied)	Lamp 1
118	118	Gas Tip (Marked "1")	Lamp 1
122	122	Burner Tube	Lamp 1
123 - 25	123-25	Burner Cap & Screens	Lamp 1
199	199	Generator Barrel, Wick, Fuel Valve & Gas Tip (Gas Tip Marked "1")	Lamp 1
210	210	Lid Set Screw	Iron 1, 2
604 - 445	212	Iron Handle	Iron 2
601 - 614	214	Valve Stem	Iron 2
601 - 616	216	Pack Nut	Iron 2
603 - 940	219	Funnel	Iron 2
603 - 440	220	Stand	Iron 2
601 - 399	222	Burner, Valve, Generator & Fount Complete Assembled	Iron 2
601 - 164	231	Filler Plug Complete	Iron 2
601 - 136	236	Filler Plug Gasket	Iron 2
242	242	Oven Rack	Stove 322
601 - 159	244	Fount (Less Filler Plug)	Iron 2
266	266	Body Base	Iron 2
601 - 370	270	Burner	Iron 2
285	285	Broiler Pan Rack	Stove 322
601 - 657	299	Valve & Generator Complete Assembled	Iron 2
408	408	Oven Door Catch (Steel)	Stove 322
535	535	Top Guard Holder	Stove 322
645	645	Broiler Door Spring	Stove 322
646	646	Oven Door Spring Hook	Stove 322
647	647	Broiler Door Spring Hook	Stove 322
661	661	Oven Door Spring	Stove 322
1030	1030	Broiler Pan	Stove 322
1103 - 16	1103-16	Valve Stem Complete	Lamp 11

Complete Parts List

Numerically Arranged by Old Numbers

Y	Old No.	Name of Part	Products on Which Used	Net Retail Price
-42	1103-16-42	Fuel Valve Complete	Lamp 11	1.20
9	1107-8-9	Generator Barrel & Asbestos Wick	Lamp 11	1.20
	1108	Asbestos Wick (Tied)	Lamp 11	.18
	1118	Gas Tip (Marked "11")	Lamp 11	.30
5	1123-25	Burner Cap & Screens	Lamp 11	.24
	1124	Burner Tube	Lamp 11	.15
	1126	Globe Holder Complete	Lamp 11	1.05
9	1129-19	Mixing Chamber	Lamp 11	.75
1	1146-11	Air Intake Complete	Lamp 11	.75
	1193	White High Shelf	Stove 322	2.70
	1199	Generator Barrel, Wick, Fuel Valve & Gas Tip (Gas Tip Marked "11")	Lamp 11	2.70
	1246	White End Shelf	Stove 322 ('28)	1.50
	1575	Front Leg White (18" Over All)	Stove 322	1.80
	1575	Rear Leg Black (18" Over All)	Stove 322	1.80
	1744	White Base Band	Stove 322 ('28)	4.80
	1744	Black Base Band	Stove 322 ('29)	4.80
	1745	Black Body Side	Stove 322 ('28)	4.80
	1745	White Body Side	Stove 322 ('29)	4.80
	1746	White Side Splasher	Stove 322	4.20
	1749	Oven Body Back	Stove 322	2.10
	1751	White Main Front	Stove 322	4.50
	1754	Burner Box Bottom	Stove 322	2.10
	1755	White Top Guard	Stove 322	2.10
	1756	Side Lining (Body Side)	Stove 322	5.40
	1758	Top Lining	Stove 322	2.70
	1759	White Service Drawer Front	Stove 322	1.80
	1760	Back Lining	Stove 322	2.70
	1761	Broiler Bottom	Stove 322	1.95
3	1762-63	Oven Bottom Complete	Stove 322	5.40
	1765	White Broiler Door Panel	Stove 322	3.00
	1767	Broiler Door Lining	Stove 322	1.50
	1771	Service Drawer Body (Less Front)	Stove 322	3.75
	1801	Oven Door Channel	Stove 322	.75
	1802	Broiler Door Channel	Stove 322	.60

Complete Parts List

Numerically Arranged by **Old Numbers**

Order by New No.	Old No.	Name of Part	Products on Which Used	N
1804	1804	White Drip Pan	Stove 322	
1842	1842	Lining Support	Stove 322	
1886	1886	White Oven Top	Stove 322	
2015	2015	Semi-Angle Frame	Stove 322 ('28)	
2016	2016	White Back Splasher	Stove 322	
2017	2017	Burner Box Back	Stove 322 ('28)	
2080	2080	Burner Box Tank End	Stove 322 ('28)	
2081	2081	Burner Box Oven End	Stove 322 ('28)	
2082	2082	Side Lining (Splasher Side)	Stove 322	
2084	2084	White Oven Door Panel	Stove 322	
2085	2085	Oven Door Lining	Stove 322	
601 - 620	2120	Valve Stem Packing	Iron 2	2 f
2236	2236	Burner Box Back	Stove 322 ('29)	
2237	2237	Burner Box Tank End	Stove 322 ('29)	
2238	2238	Burner Box Oven End	Stove 322 ('29)	
2363	2363	Full Angle Frame	Stove 322 ('29)	
2476	2476	Front Leg White (19½" Over All)	Stove 322 ('29)	
2476	2476	Rear Leg Black (19½" Over All)	Stove 322 ('29)	
140 - 401	2501	Connecting Ring	Lamp 25	
140 - 904	2504	Heat Baffle	Lamp 25	
140 - 208	2508	Asbestos Wick (Tied)	Lamp 25	
140 - 218	2518	Gas Tip (Marked "25")	Lamp 25	
112 - 323	2523R	Burner Cap & Screens	Lamp 25	
140 - 324	2524	Burner Tube	Lamp 25	
208 - 326	2526	Mixing Chamber	Lamp 25	
112 - 438	2535	Pipe Hanger (5" Long)	Lamp 25	
112 - 444	2540	Casing (4½" Long)	Lamp 25	
112 - 443	2543	Ceiling Plate	Lamp 25	
112 - 419	2547	Canopy & Screw	Lamp 25	
140 - 953	2553	Chain & Ring (6" Long)	Lamp 25	
140 - 651	2555	Valve Stem Complete	Lamp 25	
140 - 660	2557R	Fuel Valve Complete (With Lever)	Lamp 25	
140 - 299	2599	Generator (6¼" Long) (Gas Tip Marked "25")	Lamp 25	
140 - 401	2701	Connecting Ring	Lamp 27	
140 - 904	2704	Heat Baffle	Lamp 27	

Complete Parts List

Numerically Arranged by Old Numbers

r by No.	Old No.	Name of Part	Products on Which Used	Net Retail Price
208	2708	Asbestos Wick (Tied)	Lamp 27	.15
218	2718	Gas Tip (Marked "27")	Lamp 27	.15
323	2723R	Burner Cap & Screens	Lamp 27	.18
324	2724	Burner Tube	Lamp 27	.24
326	2726	Mixing Chamber	Lamp 27	.60
438	2735	Pipe Hanger (5" Long)	Lamp 27	.12
444	2740	Casing (4½" Long)	Lamp 27	.18
443	2743	Ceiling Plate	Lamp 27	.36
419	2747	Canopy Screw	Lamp 27	.45
953	2753	Chain & Ring (18" Long)	Lamp 27	.18
651	2755	Valve Stem Complete	Lamp 27	.30
660	2757R	Fuel Valve Complete (With Lever)	Lamp 27	.90
299	2799	Generator (7⅜" Long) (Gas Tip Marked "27")	Lamp 27	.48
	5488	White Door Handle	Stove 322	.60
	5489	Door Hinge (Right)	Stove 322	.45
	5490	Door Hinge (Left)	Stove 322	.45
	5494	Door Hinge Bar (Right)	Stove 322	.36
	5495	Door Hinge Bar (Left)	Stove 322	.36
	5498	Spring Bar	Stove 322	.30
	5533	Oven Door Catch (Casting)	Stove 322	.15
	5596	Black High Shelf Trim (R. H. Oven)	Stove 322	.90
	5597	Black High Shelf Trim (L. H. Oven)	Stove 322	.90
	5684	White End Shelf	Stove 322 ('29)	2.40
	5686	Grate	Stove 322	3.60
	5756	White Front Strip	Stove 322 ('29)	.90
	A65	Fount Complete	Obsolete. Supply No. E	
	E	Fount Complete	Lamp A, AA	6.00
524	L400	Pump Barrel Complete	Lantern L427 ('26)	.90
520	L401	Pump Plunger Complete (Less Air Stem)	Lantern L427 ('26)	.60
532	L402	Air Stem	Lantern L427 ('26)	.15
530	L404	Pump Complete	Lantern L427 ('26)	1.50
140	L464B	Filler Plug Complete	Lantern L427 ('26)	.48
165	L465	Fount Complete	Obsolete. Supply Nos.	

Complete Parts List

Numerically Arranged by Old Numbers

Order by New No.	Old No.	Name of Part	Products on Which Used
101 - 299	NA	Valve, Handle & Generator Complete	Lamp A, AA
101 - 522	NA	Pump	Lamp A, AA
101 - 950	NA	Wrench	Lamp A, AA
104 - 469	NA	Hanger	Lamp A, AA
104 - 905	NA	Gas Tip Cleaning Needle	Lamp A, AA
140 - 903	NA	Alcohol Torch	Lamp A, AA
216 - 509	NA	Pump Leather	Lamp A, AA 2
101 - 310	NA10	Air Intake Coupling	Lamp A, AA
NA11	NA11	Air Intake Tube	Lamp A, AA
101 - 218	NA18	Gas Tip	Lamp A, AA
101 - 322	NA22	Bunsen Tube	Lamp A, AA
101 - 324	NA24	Burner Tube	Lamp A, AA
112 - 325	NA25	Burner Cap Screen	Lamp A, AA 2
104 - 326	NA26	Mixing Chamber	Lamp A, AA
101 - 154	NA32	Filler Plug Air Stem	Lamp A, AA
NA34	NA34	Valve Core	Lamp A, AA
101 - 935	NA35	Handle Metal Washer	Lamp A, AA 2
101 - 136	NA36	Filler Plug Gasket	Lamp A, AA 2
NA39	NA39	Heat Bell	Lamp A, AA
NA40	NA40	Heat Bell Stem	Lamp A, AA
104 - 341	NA41	Shade Holder Screw	Lamp A, AA
101 - 145	NA45	Fibre Lamp Handle	Lamp A, AA
101 - 946	NA46	Handle Fibre Washer	Lamp A, AA
NA48	NA48	Set Collar & Screw	Lamp A, AA
101 - 258	NA58	Asbestos Wick (Tied)	Lamp A, AA 2
101 - 259	NA59	Gas Tip Screen	Lamp A, AA 2
101 - 363	NA63	Shade Holder	Lamp A, AA
NA66	NA66	Heat Bell Plate & Spring	Lamp A, AA
101 - 370	NA70	Burner Complete	Lamp A, AA
112 - 323	NA23-25	Burner Cap & Screens	Lamp A, AA
101 - 653	NA55-16	Valve Stem Complete	Lamp A, AA

Numerically Arranged by Old Numbers

	Old No.	Name of Part	Products on Which Used	Net Retail Price
7	NA57-16-55	Fuel Valve Complete	Lamp A, AA	.75
5	NA58-12	Generator Barrel & Asbestos Wick	Lamp A, AA	1.05
4	NA64½	Filler Plug Complete	Lamp A, AA	.75
4	NA54A	Filler Plug Air Stem	Lamp A, AA	.18
9	Q77	Straight Generator (Gas Tip Marked "J")	Lamp 117, 118. 119 Lantern 220, 228	.20
9	Q99	Coil Generator (Gas Tip Marked "Q")	Lamp B, C. C331. P Lantern E20, L227, L327, L427 ('26), L427 ('27)	.35
9	R55	Rotary Generator (Gas Tip Marked "J")	Heater 480	.50
	T23	Filler Plug Complete (Male)	Special	.75
3	T656	Valve Stem Complete	Lamp 117, 118, 119 Lantern 220, 228	.45
7	T657	Valve & Generator Complete	Lamp 117, 118, 119 Lantern 220, 228	1.05

Complete Double Number List

For Cross Reference Use

Left Hand Columns Show **Old Numbers** in Numerical Order

Right Hand Columns Show Corresponding **New Numbers**

Old No.	New No.
.007	104-905
0	0
1	1
1	599-901
1B	599-902
2	600-657
2CS8	402-259
2CS17	409-520
2CS23	403-365
2CS26C	403-326
2CS27	409-118
2CS28Z	402-328
2CS32	216-532
2CS34C	404-434
2CS55	402-329
2CS56B	402-656
2CS57	401-457
2CS59	402-459
2CS62	405-262
2CS63	545-329
2CS66C	403-175
2CS71C	403-170
2CS93C	406-489
2CS96	406-492
2CS96C	406-492
2D17	216-520
2D18	405-239
2D23	405-365
2D26	405-326
2D27	405-118
2D28	405-357
2D28-29	405-357
2D30	405-361
2D34	406-434
2D62	405-262
2D63	545-329
2D66	405-175
2D70	405-370
2D71	405-170
2D93	406-489
2D96	406-492
2H05	472-405
2H06	472-406
2H07	472-407
2H11	307-930
2H18	502-218
2H20	472-480
2H21	599-932
2H22	472-233
2H27L	472-409
2H27R	472-408
2H28	472-651
2H29	472-657
2H37L	472-419
2H37R	472-418
2H40	451-140
2H45	472-367
2H59	472-421
2H62	472-262
2H65	472-189
2H67	472-170
2H70	472-370
2H71	472-171
2H74	472-415
2H75	472-491
2H79	472-423
2H80	472-473
2H89	472-489
2H99	472-193
2RH	472-417
2RH2	472-403
2RH3	472-303
2RH9	472-238
2SP31P	625-513
2WJ	601-950
3	601-620
3CS21Z	403-321
4	601-616
4AG618	308-218
4BB18	502-218
4BB23	540-923
4BB26	540-926
4BB62	502-262
4H	474-218
4SB18	502-218
4SB19	501-223
4SB23	545-323
4SB26	545-326
4SB62	507-262
5	601-614
5BB18	318-218
5BB19-7	503-223
5BB23	543-323
5BB26	540-326
5BB62	501-262
5SB18	318-218
5SB19	501-223
5SB23	546-323
5SB26	546-326
5SB62	506-262
6	210
7	599-907
7	601-136
7BB23	542-323
7BB26	542-326
7BB29	542-329
8	599-908
8	601-164
9	9
9C71	403-170
9CS17	409-520
9CS18F	409-118
9CS19C	403-489
9CS23	403-365
9CS26C	403-326
9CS32	216-532
9CS34	409-434
9CS63	409-327
9CS63	545-329
9CS63C	545-329
9CS66C	403-175
9CS71C	403-170
9D19	403-489
9D34	405-434
10	591-499
10	604-445
11	601-950
12	601-370
13	59
13	60
13J	59
13J Blind	59
13N	59
14	59
14	60
15	59
15	60
16	59
16B	16
16T	16
17	17
17	59
18	18
19	60
20	59
21	21
21	59
22	22
23	23
23	59
24	24
24	59
25	59
25	60
26	59
26	60
27	27
27	59
28	28
28	59
47	59
91	62
102-3-13-16	102
103-16	103
107-8-9	107
108	108
118	118
122	122
123-25	123
199	199
210	210
212	604
214	601
216	601
219	603
220	603
222	601
231	601
236	601
242	242
244	601
266	266
270	601
285	285
299	601
408	408
514-4B	514
514-5B	514
515-7B	515
535	535
627	627
630	630

Complete Double Number List

For Cross Reference Use

Left Hand Columns Show **Old Numbers** in Numerical Order

Right Hand Columns Show Corresponding **New Numbers**

No.	New No.
	645
	646
	647
	661
	599-933
	599-931
	1030
-16	1103-16
-16-42	1103-16-42
-8-9	1107-8-9
	1108
	1118
-25	1123-25
	1124
	1126
-19	1129-19
-11	1146-11
	1193
	1199
	1246
	1575
	1744
	1745
	1746
	1749
	1751
	1754
	1755
	1756
	1758
	1759
	1760
	1761
63	1762-63
	1765
	1767
	1771
	1801
	1802
	1804
	1842
	1886
	2015
	2016
	2017
	2080
	2081
	2082
	2084
	2085
	601-620
	2236
	2237
	2238
	2363
	2476
	140-401
	140-904
	140-208
	140-617
	140-218
	112-323
	112-323

Old No.	New No.
2526	208-326
2535	112-438
2540	112-444
2543	112-443
2547	112-419
2553	140-953
2555	140-651
2557R	140-660
2599	140-299
2701	140-401
2704	140-904
2708	142-208
2718	142-218
2723R	142-323
2724	142-324
2726	142-326
2735	112-438
2740	112-444
2743	112-443
2747	112-419
2753	142-953
2755	140-651
2757R	140-660
2799	142-299
4717	599-940
5488	5488
5489	5489
5490	5490
5494	5494
5495	5495
5498	5498
5533	5533
5596	5596
5597	5597
5684	5684
5686	5686
5756	5756
310-140	451-140
310-262	324-262
310-407	321-407
312-262	329-262
318-263	328-263
318-348	328-380
318-427	318-473
322-657	328-657
323-191	331-191
324-653	328-653
324-655	328-653
328-655	328-653
407-171	410-171
407-175	410-175
407-218	410-218
407-256	410-256
407-262	410-262
407-309	410-309
407-313	410-313
407-314	410-314
407-322	410-322
407-326	410-326
407-328	410-328
407-370	410-370
407-479	410-488
501-218-4	502-218

Old No.	New No.
603-289	603-299
604-920	604-930
A23-18	318-218
A36	101-136
A64½	101-164
A65	E
A0	318-218
A0102	310-189
A0103	451-522
A0104	472-125
A0105	310-115
A0111	310-360
A0112	310-310
A0113	310-353
A0114	310-307
A0115	310-357
A0116	310-305
A0118	549-218
A0119	310-389
A0120	310-383
A0121	310-371
A0122	599-932
A0219	310-171
A0220	318-173
A0221	310-371
A0222	316-175
A0224	318-376
A0245	472-367
A0246	104-132
A0246	472-308
A0270	328-380
A0602	314-442
A0602	314-443
A0603L	314-445
A0603R	314-444
A0713	599-932
A0717	599-936
A0750	599-930
A0751	599-934
A0752	599-935
A0753	599-931
A0754	599-937
A009	310-171
A0011	307-930
A0015	310-215
A0019	310-171
A0021	599-932
A0022	310-233
A0023	324-323
A0027	310-410
A0027	313-410
A0029	310-657
A0030	599-934
A0032	451-132
A0036	650-136
A0038	451-139
A0040	451-140
A0044	305-444
A0045	310-345
A0002L	310-443
A0002R	310-442
A0003L	310-445
A0003R	310-444

Complete Double Number List

For Cross Reference Use
Left Hand Columns Show **Old Numbers** in Numerical Order
Right Hand Columns Show Corresponding New Numbers

Old No.	New No.
A0008	310-418
A2001	321-407
A2004	310-441
A2005	310-440
A2009	307-238
A2018	307-218
A2026	310-326
A2027	307-459
A2271	321-322
A2309	472-238
A2318	318-218
A2604	314-441
A2605	314-440
A2674	321-345
A3045	310-345
A3046	104-132
A3046	472-308
A6004	312-441
A6005	312-440
A6009	308-238
A6018	308-218
A6054	312-409
A6062	329-262
A6072	312-326
A6318	318-218
A6604	315-441
A6605	315-440
A6623	318-369
A6671	312-322
A6672	318-326
A6673	318-340
A6674	318-345
A6675	316-345
A6676	318-343
A6678	318-346
AG	472-125
AG2	307-189
AG18-15	307-233
AG23	324-323
AG28Z	307-350
AG45	307-345
AG202	307-423
AG202	307-440
AG202	307-441
AG202	307-442
AG202	307-443
AG202	307-444
AG202	307-445
AG209	307-238
AG218	307-218
AG226	307-326
AG227	307-459
AG253	307-409
AG255	307-355
AG262	307-262
AG271	307-171
AG600	308-407
AG602	308-440
AG602	308-441
AG609	308-238
AG618	308-218
AG626	308-326
AG626½	308-322

Old No.	New No.
AG655B	308-355
AG655F	307-355
AG662	308-262
AG671	308-171
AGP	451-509
AGP	451-522
AGT27	313-410
AGT29	307-657
AGT55-16	471-653
AGX15	307-325
AGX28	307-350
AGX28Z	307-350
AGX255	307-355
AGX655B	308-355
AGX655F	307-355
ATP4P	625-504
B	102-165
B17	102-117
B42	102-446
B43	102-143
B65	102-165
BB9	501-238
BB18-4	502-218
BB18-5	318-218
BBTC25	501-225
C5	104-105
C35	101-935
C45	104-145
C46	101-946
C47	104-147
C65	104-165
C69	104-469
CS8	402-259
CS9	409-509
CS17	409-520
CS18	405-239
CS23	403-365
CS36	104-136
CS56	402-656
CS56B	402-656
CS57	401-457
CS57B	401-457
CS59	402-459
CS62	405-262
CS63	409-327
CS64	401-164
CS89	401-489
CV	625-552
D0018	308-218
D0062	329-262
D0112	310-310
D0113	310-353
D0115	310-357
D0119	310-389
D0120	310-383
D0502	310-189
D0504	472-125
D0505	310-115
D0527	310-410
D0529	310-657
D0540	451-140
D0803	451-522
D0809	451-509

Old No.	New
D3602	314
D3602	314
D3603	314
D3603	314
D3604	314
D3605	314
D3644	305
D4603	314
D4603	314
D4604	315
D4605	315
D4644	305
E	E
FS11	630
H2	502
H22	471
H100	472
H101	307
H102	472
H104	472
H105	451
H0809	451
HB	544
HB9-10	544
HB11	544
HB29	544
HB56B	305
HB57	544
HB57N	544
HB99	544
HGP	451
HGP4T	451
HGP29	451
HGP32	451
HGP36	650
HGP38	451
HGP40	451
HGP72	451
HHS	MV
HS44	305
HST56	305
HST56B	305
HV	101
HV	104
HV	208
HV	216
HV13	208
HV18	208
HV24	208
HV25	112
HV26	208
HV28B	208
HV36	101
HV41	208
HV55-16	203
HV55-16-57	208
HV58	208
HV59	208
HV64½	101
HV65	208
HV73	208
HV82	208
HV85	208

Complete Double Number List

For Cross Reference Use

Left Hand Columns Show **Old Numbers** in Numerical Order

Right Hand Columns Show Corresponding **New Numbers**

Old No.	New No.
HV93	208-493
HV99	208-299
HV423-25	112-323
HV425	112-325
J37	112-437
J40	112-440
L400	204-524
L401	204-520
L402	216-532
L404	204-530
L433	204-139
L436	115-136
L464B	204-140
L465	204-165
LQ19	203-409
LQ20	203-420
LQ26	104-326
LQ40	203-340
LQ41	203-441
LQ55	203-653
LQ55-16	203-653
LQ57	203-657
LQ65	203-165
LQ70	203-399
LQ85	204-485
LQ85V	204-485
LQ89	203-489
LQ98	203-498
MB18	504-218
MB19	501-223
MB23	543-323
MB28Z	543-328
NA	101-299
NA	101-522
NA	101-950
NA	104-469
NA	104-905
NA	140-903
NA	216-509
NA10	101-310
NA11	NA11
NA18	101-218
NA22	101-322
NA23-25	112-323
NA24	101-324
NA25	112-325
NA26	104-326
NA32	101-154
NA34	NA34
NA35	101-935
NA36	101-136
NA39	NA39
NA40	NA40
NA41	104-341
NA45	101-145
NA46	101-946
NA48	NA48
NA54A	101-154
NA55-16	101-653
NA57-16-55	101-657
NA58	101-258
NA58-12	101-265
NA59	101-259
NA63	101-363

Old No.	New No.
NA64½	101-164
NA66	NA66
NA70	101-370
NBB1-17	501-237
NBB29	544-329
NBB29Z	544-329
P37	112-437
P42½ & P47	113-450
P43	113-443
P45	112-440
P49	113-449
P65	113-165
P74	113-475
PL57	212-657
PL65	212-189
PL89	212-489
PL401	213-520
PL402	213-532
PL404	213-530
PL433	201-139
PL436	115-136
PL464	204-140
PL465	213-189
PP1P	625-501
Q	101-522
Q	104-905
Q	104-950
Q	216-509
Q10	104-210
Q11	104-322
Q17	104-317
Q18	104-218
Q23	112-323
Q23-25	112-323
Q24	101-324
Q25	112-325
Q26	104-326
Q32	104-132
Q33	101-522
Q36	104-136
Q41	104-341
Q56B	101-653
Q57	104-657
Q63	101-363
Q64B	104-164
Q69	104-469
Q70	104-399
Q77	199-299
Q99	104-299
QW	104-950
R55	155-299
R0119	310-389
R4018	308-218
R4045	310-345
R4046	104-132
R4046	472-308
R4062	329-262
R4120	310-383
R4310	316-345
R4318	318-218
R4521	316-175
RD	471-955
RH2	471-302

Old No.	New No.
RH3	471-303
RH9	471-238
RH18	318-218
RH19	471-157
RH22	471-322
RH23	475-323
RH24-25	471-169
RH29	471-657
RH51	471-517
RH62	471-262
RH65	471-166
RH66	471-175
RH70	471-370
RH71	471-171
RH72	471-173
RHP	471-530
SB1	506-201
SB2	545-302
SB3	545-303
SB4	545-304
SB9	506-238
SB10	545-310
SB17	501-203
SB19	501-223
SB24	545-324
SB25	506-225
SB56	506-653
SB56B	506-653
SBTC11	514-211
SBTC25	506-225
SP9P	625-509
SP55P	625-555
SS36	115-136
SS64	115-164
T19	650-157
T23	T23
T40	650-140
T656	118-653
T657	118-657
TB	307-901
TK9	650-651
TK31	650-131
TK36	650-136
TK40	650-140
TW	471-906
WC30	599-930
WC30J	599-930
WH1	461-401
WH1M	461-401
WH2	461-402
WH2M	461-402
WH3	461-403
WH3M	461-403
WH4	461-404
WH4M	461-404
WH5	461-405
WH5M	461-405
WH11	461-411
WH11M	461-411
WH15	461-415
WH15M	461-415
WH24	462-424
WH27	461-427

NOTES

Always Use Good GASOLINE

1. Always keep gasoline (to be used as fuel for lighting, heating and cooking devices) in a closed container in a cool dark place. If gasoline is exposed to air, sunlight or heat it becomes sour and develops a gummy deposit which quickly stops up generators, gas and fuel tips.

2. **Buy a fresh supply often**—do not keep gasoline until it is old and "sour."

3. **Clean out the fount or fuel tank occasionally.** This is easily done with a Coleman Suction Pump. A good thorough draining will remove all dirt, water and "sour" gasoline.

4. **Thoroughly preheat** the generator of the lamp, stove or heater. Follow filling, pumping, preheating, and lighting directions carefully.

5. **Keep the gas tip open.** Clean occasionally with the small special gas-tip cleaning needle furnished with or attached to each Coleman appliance.

6. **Use only clean gasoline,** any good grade, but be sure to strain it through a finely woven cloth or, better still, use a Coleman *(Schuyler Patent)* Filter Funnel, which removes water and other impurities from the fuel.

7. **Use only regular motor gasoline.** Most motor fuel sold as anti-knock or high compression, whether colored or not, contains substances which gum up generators, gas and fuel tips.

How to Know Good Gasoline

Gasoline, good for use in pressure appliances, must be clean and without offensive odor. It will evaporate quickly and completely without leaving a gummy residue. A simple test for these qualities may be made by placing 8 or 10 drops of different gasolines on pieces of white paper. The best gasoline will evaporate quickly, will have very little odor, and, if not dyed, will leave little, if any, stain on the paper.

Approved lists of gasolines for use in gasoline pressure appliances are issued by the United Laboratories, at 240 North St. Francis St., Wichita, Kans. This laboratory is maintained by the leading gasoline appliance manufacturers for your benefit. Write for the latest free bulletin covering your state.

Exercising care in the selection of approved gasolines and properly filtering, (See Paragraph 6 above), will insure the utmost service and economy in the operation of your gasoline pressure appliance.

Ethyl gasoline must not be used in gasoline pressure appliances, as it clogs generators rapidly and gives off dangerous fumes.