


**PARTS LIST**

**442, 442A**


**INSTANT LIGHTING GASOLINE  
ALUMINUM CAMP STOVE  
(TWO BURNER)**

**COLEMAN STOVES**

**STOVES**



**Model 442, 442A**  
(Discontinued)



**MODEL 442A SHOWN**

MODEL	BURNERS	DISTANCE BETWEEN CENTERS	TANK CAPACITY	DIMENSION (Folded — in Inches)		
				Height	Width	Depth
442 442A	2	11"	3½ Pints	5¼	22¼ <sub>16</sub>	13¾

PART NO.	DESCRIPTION	USED ON	PART NO.	DESCRIPTION	USED ON
8B147	Red Lacquer — Pressurized Spray . . . . . Tank		413A5621	Generator	
118B1361	Filler Cap Gasket — Used only with 220B1401, 220C1401 Cap with Disc		413A6461	Tube Assembly (Fuel and Air)	
200 - 533	Air Stem		413A6531	Stem Assembly	
200 - 6491	Valve Wheel		413B6601	Valve and Generator, Complete	
216 - 5091	Pump Cup		413C3021	Master Burner Bowl	
220 - 6361	Filler Cap Gasket & Disc Ass'y. — Discontinued		413C3061	Aux. Burner Bowl	
220C1401	Filler Cap, Complete		413C3451	Master Burner Cap and Fillers	
220B175	Self-Tapping Screw (#4 — 40 x 5/16")		413C3461	Aux. Burner Cap and Fillers	
242 - 6201	Valve Stem Packing		413C3601	Valve Stem (Aux. — Br. Body with Valve)	
242B5381	Check Valve		413E1651	Tank (Less Generator and Valve)	
401 - 2181	Gas Tip (Marked "B")		413E3191	Manifold Pipe	
412 - 3531	Lighter Stem		413E4051	Leg — Not Available	
413 - 130	Screw		425 - 3451	Master Burner Cap and Fillers	
*413 - 5281	Manifold Assembly		442 - 3261	Master Burner Body — Replaced by 413-5281	
413 - 6401	Block and Needle Assembly		442A3261	Master Burner Body — Replaced by 413-5281	
413 - 6561	Valve with Stem Assembly		442A4341	Grate	
413A2191	Generator Coil		479 - 217	Tip Protector	
413A2511	Needle Assembly		530A5071	Pump Cap Clip	