




PART NO.	DESCRIPTION	USED ON	PART NO.	DESCRIPTION	USED ON
220C1401	Filler Cap Gasket (for cap with disc)		502-1651	Fount, Complete	
200-6381	Check Valve and Stem		502-4891	Collar Assembly	
200-6491	Valve Wheel (Red)		502-5011	Bunsen, Complete	
216-5091	Pump Cup (Leather)		502-5201	Burner Support	
220C175	Self-Tapping Screw (#4 — 40 × 5/16")		502-5261	Burner Assembly	
220-6361	Filler Cap Gasket & Disc Ass'y		502-5601	Regulator Stem Assembly	
220C1401	Filler Cap, Complete		502-5891	Generator	
242-1071	Push-On Nut		502-6671	Regulator Assembly	
242D5201	Pump Plunger Assembly		502A5571	Shut-Off Valve Assembly, Complete	
500-147	Lock Nut		530A5071	Pump Cap Clip	
501-215	Direction Disc		605-210	Jamb Nut	
501-5411	Valve Stem Assembly, Complete		1016D0816	Screw (Burner Support) (#8 — 32 × 1" Rd. Hd.)	
501-5461	Feed Tube Assembly		1123D0805	Screw (Grate) (#8 × 5/16", Type B, Pan Hd., Sheet Metal)	
501-6481	Needle Spring and Fuel Tube Assembly		1131D0608	Screw (Burner)	
501A5101	Grate Assembly with Screws				
501B3181	Gas Tip				
502-1221	Burner Bowl				